




<b>Project Type</b> Instructions	Date: December 23 2020 Customer: Thermor Ltd Job Number: TH6774 Item Number: SC404 Designer: Alex Vranjesevic	Revision: A	 Contact: Graphic's Department graphics@thermor-ins.com
UPC (For Reference Only)  0 57475 93404 0	Reason For Project: New Item: X New Branding: Design Update: N/A:	Artwork is not to be amended or scaled. If any changes are required please send through Thermor office with instructions, and we will amend here and resend artwork through. <b>PLEASE RETURN WITH SIGNATURE</b>	Colour Breakdown 




# BIOS living

## Premium Analog Scale

Instruction Manual

SC404



<b>Project Type</b> <b>Instructions</b>	<b>Date:</b> December 23 2020 <b>Customer:</b> Thermor Ltd <b>Job Number:</b> TH6774 <b>Item Number:</b> SC404 <b>Designer:</b> Alex Vranjesevic	<b>Revision:</b> A	 <b>Contact:</b> Graphic's Department graphics@thermor-ins.com
UPC (For Reference Only)  0 57475 93404 0	<b>Reason For Project:</b> New Item: X New Branding: Design Update: N/A:	Artwork is not to be amended or scaled. If any changes are required please send through Thermor office with instructions, and we will amend here and resend artwork through. <b>PLEASE RETURN WITH SIGNATURE</b>	<b>Colour Breakdown</b> 

## Introduction

Thank you for purchasing the BIOS Living Premium Analog Scale. This scale is equipped with an easy to read dial and has a capacity of 330 lbs / 150 kg.

## Features

- Easy to read 7" / 17.7 cm dial
- Solid steel construction
- Easy to clean non-slip platform
- Accurate to 330 lbs / 150 kg

## Operation

1. Place the scale on a hard, flat surface (avoid carpet or other soft surfaces).

**NOTE:** If the scale is placed on a soft surface, such as a carpet, the results may be inaccurate.

2. Step onto the scale slowly and gently (do not jump onto the scale). Stand vertically without swaying and place your feet evenly apart - the dial will display your weight.

## Advice for Use and Care

- Avoid using platform when wet - platform will be slippery when wet. Keep scale dry.
- Avoid excessive impact or vibration to the unit.
- Clean the scale with a damp cloth and avoid water getting inside scale.
- Store scale in horizontal position.

## Five Year Warranty

The Premium Analog Scale has a 5 year warranty to be free of manufacturing defects in materials and workmanship under normal applications for 5 year of the original owner. If this product becomes inoperable due to defect and requires repair, return the product with all component pieces and proof of purchase to the address listed below. This warranty does not cover any shipping/transport costs. This warranty does not apply if the product is subject to misuse, neglect, rough handling or damage.

Ship the unit prepaid and insured (at owners option) to:

### **Thermor Ltd.**

Attn: Repair Department  
16975 Leslie Street  
Newmarket, ON L3Y 9A1

www.biosmedical.com  
Email: support@biosmedical.com