# **USER INFORMATION SHEET**



# CARE INSTRUCTIONS FOR YOUR EYEWARE

- Store at room temperature and transport in a sealed package.
- Clean or disinfect in warm water, rinse then dry with lint free cloth.
- Make regular checks to ensure all parts are secure.
- Should the lens be marked or scratched it must be replaced immediately.

### PRODUCT LIFE

- If stored at ambient room temperature, the product would have a shelf life of over 2 years.
- The stock would be replaced should there be any sign of deterioration.

### **FITTING**

• The product must be comfortable and close fitting, ensuring good vision.

### PRODUCT MARKINGS

- Should the symbols **S** (increased robustness), **F** (low energy impact) or **B** (medium energy impact) not be common to both ocular and the frame holder, then it is the lowest level, which is applied to the complete eye protector.
- For a goggle to comply with symbol **9**, both the ocular and the frame holder must show this symbol in conjunction with one of the symbols **F** or **B**.
- As far as we know the materials used would not cause allergic reactions.
- These goggles should not be used in extreme temperatures.
- Should the lens be marked or scratched, IT MUST BE REPLACED.

### **SYMBOLS**

SYMBOL	DESCRIPTION OF MARKING/FIELD OF USE	WARNINGS
S	Increased Robustness	*1 Impacts can be
F	High-Speed particles. Low energy impact *1,2	transmitted to eyewear worn underneath, which could create a hazard.
В	High-Speed particles. Medium energy impact *1,2	
1	Optical class 1	
3	Liquid (droplets or splashes)	
4	Dust with particle size of greater than 5um	*2 Applicable at room temperature only
5	Gases, smoke, dust with particle size less than 5um	
9	Splashes of molten metals and penetration of hot solids	
EN166	European standard number for personal eye protection	
K	Resistance to abrasion by fine particle	In the event of the product causing skin
N	Resistance to fogging	
\$	Kitemark product	irritation, it's use should be discontinued and
3	B-Brand identification	medical advice sought.

# **USER INFORMATION SHEET**



# CARE INSTRUCTIONS FOR YOUR EYEWARE

- Store at room temperature and transport in a sealed package.
- Clean or disinfect in warm water, rinse then dry with lint free cloth.
- Make regular checks to ensure all parts are secure.
- Should the lens be marked or scratched it must be replaced immediately.

### PRODUCT LIFE

- If stored at ambient room temperature, the product would have a shelf life of over 2 years.
- The stock would be replaced should there be any sign of deterioration.

# **FITTING**

• The product must be comfortable and close fitting, ensuring good vision.

### PRODUCT MARKINGS

- Should the symbols **S** (increased robustness), **F** (low energy impact) or **B** (medium energy impact) not be common to both ocular and the frame holder, then it is the lowest level, which is applied to the complete eye protector.
- For a goggle to comply with symbol **9**, both the ocular and the frame holder must show this symbol in conjunction with one of the symbols **F** or **B**.
- As far as we know the materials used would not cause allergic reactions.
- These goggles should not be used in extreme temperatures.
- Should the lens be marked or scratched, IT MUST BE REPLACED.

# **SYMBOLS**

SYMBOL	DESCRIPTION OF MARKING /FIELD OF LICE	WARNINGS
STMBOL	DESCRIPTION OF MARKING/FIELD OF USE	WANININGS
S	Increased Robustness	*1 Impacts can be transmitted to eyewear worn underneath, which could create a hazard.
F	High-Speed particles. Low energy impact *1,2	
В	High-Speed particles. Medium energy impact *1,2	
1	Optical class 1	
3	Liquid (droplets or splashes)	
4	Dust with particle size of greater than 5um	*2 Applicable at room temperature only
5	Gases, smoke, dust with particle size less than 5um	
9	Splashes of molten metals and penetration of hot solids	
EN166	European standard number for personal eye protection	
K	Resistance to abrasion by fine particle	In the event of the
N	Resistance to fogging	product causing skin
\$	Kitemark product	irritation, it's use should be discontinued and
3	B-Brand identification	medical advice sought.



