Installation Instructions



PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

- To prevent personal injury or product damage only licensed electricians should install.
- To avoid electric shock or component damage disconnect power before attempting installation or servicing.
- This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local electric codes and safety standards.
- Disconnect product and allow cooling prior to servicing.
- Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.
- To prevent product malfunction and/or electrical shock this product must be properly grounded.
- This luminaire is designed to operate in ambient temperatures ranging from -40°C to 50°C and to be horizontally mounted with the LEDs facing down.
- This product must be installed in accordance with the applicable installation code by a Person familiar with the construction and operation of the product and the hazards involved.
- In 75°c supply conductors
- This product is not available for several special environments, such as places with corrosive gas liquids or high pressure water vapor

Installation

1. Hook installation


- 1. Remove line cord protector the open-type plastic grommet before installation.
- Take out the hook from accessory package, thread the power cord through the hole of hook (make sure the gasket is kept inside of the hole of fixture for waterproofing).
- 3. Thread the hook into 3/4" hole on fixture tightly.
- 4. Thread the hook onto the desired place and tighten the screw to lock the hook.

 Connecting the wiring according to the wiring diagram. Then installation is done.

Hook M4x30mm Screw Sealing Kits Attention: Locker End Up Locker end Accessory pocket M4x8mm Screw M4x8mm Screw


2. Trunnion installation

- 1. Remove the line cord protector firstly.
- 2. Wire locker end and hook, while make sure the locker end toward the hook to ensure water does not enter fixture.
- 3. Thread the hook onto the 3/4" NPT conduit until tight.
- 4. Tighten the M4X8 screw in the luminaire.
- 5. Using the sealing kits will ensure a watertight seal.



3. Pendent mounting with 3/4" conduit(by others)

- 1. Remove the line cord protector firstly
- 2. Thread the led luminaire onto the ¾" NPT conduit until tight , secure the M4X8 screw and make wire connections.
- 3. Caulk the conduit openings such as sealing kits, to ensure water does not enter fixture through 3/4 NPT conduit.
- 4. Silicone rubber is needed to ensure water does not enter fixture through 1/2" fitter.



Wire Connection Black Line White Neutral Green/Yellow Green Ground Purple Gray

Note:Two dimming wire in the driver box