

APPLICATION NOTE

# How to use Fluke T6 Electrical Testers to take accurate measurements

Those who use electrical testers to capture measurements such as voltage and current know that the process is traditionally time-consuming and carries the potential for risk. Fluke T6 Electrical Testers provide a faster and safer method for taking electrical readings on distribution panels and junction boxes, among other applications. These tools sense an electrical field in the open fork, allowing you to take the measurement with ease.

Thanks to the new FieldSense technology, the T6 makes work safer as you can measure voltage up to 1000 V ac through its open fork. Having the capability to measure voltage and current at the same time, together with eliminating the need to open covers or remove wire nuts, allows you to be faster and more efficient when taking measurements. In addition, the open fork is the widest available in the industry and can measure wires up to AWG 4/0 (120 mm<sup>2</sup>) carrying as much as 200 A.

Commercial and light industrial electricians can use T6 Electrical Testers for basic troubleshooting, verifying voltage and continuity values as well as testing individual circuits while quickly checking current and voltage measurements without test leads. These devices easily fit in your pocket, making them easy to access on the front-line for electricians of all industries. Common applications include testing:

- Wire runs in conduit and junction boxes
- Feed circuits coming into motors (up to 200 amps)
- Distribution panels (will go around 4/0 wire)
- HVAC equipment
- Disconnects
- Conduit cases (using the black test lead)

## How does the T6 work?

Typically, electricians encounter junction boxes crowded with wires, so finding the right connection point poses a challenge. With the T6-600 or T6-1000 you take measurements by sliding a single conducting wire into the open fork.



T6 Electrical Testers go beyond simple detection. They actually measure ac voltage, current and frequency without test leads. With the use of the provided test leads, the tools are also able to measure ac/dc voltage, resistance and continuity. The T6 testers use proprietary FieldSense technology, which makes measuring the voltage source safer for the electrician or technician performing the test. The FieldSense technology measures the voltage through the cable's insulation, reducing user hazard to exposed metallic conductors and reducing the likelihood for errors or accidentally contacting the wrong conductors. The technology injects a known signal to accurately derive the unknown ac voltage. This allows for an actual ac voltage measurement, versus simply sensing a magnetic field found in traditional non-contact voltage detectors.

Traditionally, a metal-to-metal connection has been necessary when probing with test leads or attaching alligator clips to a circuit. The FieldSense technology allows the T6 to measure ac voltage, current and frequency without making electrical contact to live voltage. Note that this requires a capacitive path to ground through the user by contacting the round touch point on the back of the battery cover – this will be adequate in many applications. In some applications where a user does not have a clear path to ground, a ground connection via the attached test lead may be required.



To measure ac voltage and ac current using FieldSense Technology:

1. Turn the dial knob to the second position, or 'FieldSense' function. The tester measures and simultaneously displays both ac voltage and ac amps on the T6-1000 while the T6-600 will default to ac amps and must be toggled to ac voltage using the yellow toggle button.
2. When using the touch pad to complete the ground, insert the black test probe into the storage dock on the back of the unit. If using insulated gloves, standing on an insulated ladder or otherwise insulated from ground, place the black test lead on a ground conductor or attach it to ground with an alligator clip.
3. View the reading, making note of the units of measurement.
4. Press the HOLD button to momentarily freeze the reading for a quick snapshot of the screen readout.

Remember, the attached test leads must be used when measuring ac/dc voltage through the traditional metallic contact method and when making phase to phase voltage measurements. Touch the probe tips to the circuit across the load or power source in parallel to the circuit.

The T6-600 is rated 600 V CAT III and the T6-1000 is dual rated 1000 V CAT III/600 V CAT IV.

### Take stable readings

The optimal position for a hot or neutral conductor, when taking FieldSense measurements, is centered at the bottom of the open fork. When positioning the fork, with one hand, simply slide the open fork over the conductor. For the T6-1000, the LCD display simultaneously shows the voltage and current measurements while the frequency can be manually selected with the press of a button. There's no need to reconfigure the tool or search for metallic test points.

The display screen will turn green to indicate that FieldSense has a reliable electrical signal. The triangle-shaped voltage indicator light, marked with the lightning bolt icon, turns red if the voltage present is greater than 30 V.

Be aware that the reading may not be as accurate when the user is wearing insulated gloves, highly insulated boots or standing on an insulated ladder. These scenarios will require an external grounded lead to be connected in order to confirm a reliable reading. This is accomplished by simply touching the attached black lead to a grounded conductor, such as a conduit or a junction box.

### Measuring resistance and continuity

The T6-1000 measures resistance 1Ω to 100 kΩ, while the T6-600 measures 1Ω to 2000 Ω. To take a measurement:

1. Turn off power in the circuit to be tested.
2. Turn the selector to Ω.
3. Touch the probe tips across the designated component or portion of the circuit.
4. View the reading.
5. If the reading is less than 40 ohms, you will obtain an audible continuity alert.

### Non-operating circuitry

With an energized circuit not under load, you can measure the hot leg of an ac circuit. T6 Electrical Testers help you troubleshoot, as they empower you to find out which wires are hot, even while the circuit—whether for a light, motor, or lamp—is non-operational. This gives electricians the ability to test wires with voltage potential and troubleshoot where the circuit is open.

## Staying protected

Notwithstanding the T6 Electrical Testers' improvements to safely taking electrical measurements, workers should still wear appropriate personal protective equipment (PPE). This means electricians should still wear arc-rated clothing and protective equipment including gloves, safety glasses or goggles, hearing protection and leather footwear. In lower voltage areas, measurements can be taken wearing minimal PPE, including gloves and protective eyewear. However, measuring without test leads does not mean you can skip wearing the required PPE.

A complete list of PPE categories, as defined by the National Fire Protection Association (NFPA) Standard 70E, are available in Table 130.7( C)(16). Greater electrical hazards require PPE with a higher arc rating that is able to withstand an arc-flash incident.



**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**Fluke Europe B.V.**  
PO Box 1186, 5602 BD  
Eindhoven, The Netherlands

**For more information call:**  
In the U.S.A. (800) 443-5853 or  
Fax (425) 446-5116  
In Europe/M-East/Africa +31 (0) 40 2675 200 or  
Fax +31 (0) 40 2675 222  
In Canada (800)-36-FLUKE or  
Fax (905) 890-6866  
From other countries +1 (425) 446-5500 or  
Fax +1 (425) 446-5116  
Web access: <http://www.fluke.com>

©2017 Fluke Corporation.  
Specifications subject to change without notice.  
Printed in U.S.A. 10/2017 6009616b-en

**Modification of this document is not permitted without written permission from Fluke Corporation.**