FARMHOUSE 16 Ft x 12 Ft MODEL FH1612












plaque




Cedarshed plaque





Hasp



Hinges





Barrel bolt

Roofstrut porch brackets Fasteners

2" screws 1 ¾" nails 2" nails 1 1/8" nails




FH1612

PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS
	ACCESSORIES		
P-H-PLAQSL	Square CS plaque	square plaque	1
P-H-PLAQNL	peak plaque	peak plaque	2
P-FW-001	window box	window box	2
P-SH-001	shutters	shutters	4
PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS
	FASTENERS		
P-H-NL1.125	nails	1 1/8" nails	40
P-H-NL1.75	nails	1 3/4" nails	400
P-H-NL2	nails	2" nails	75
P-H-SC2	2" Screws	2" Screws	550-850
P-H-SC3	3" screw	3 " Screws	600

PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS
	DOOR AND HARDWARE		
C-DR-001	double doors (incl. hinges)	double doors	2
P-1371C	door stop	1 x 3 x 71 1/4	1
P-1262G	door stop	1 x 2 x 62 1/2	1
P1271I	door stop	1 x 2 x 71 5/8	2
P-H-BBLT4	barrel bolt	4 " barrel bolt	2
P-H-DHAND	door handle	door handle	2
P-H-HASP	hasp	hasp	. 1
Instruction m	anual, questionaire and drive	er bit	

BEARING POINTS FOR 1612 AND BUILDING THE FLOOR JOIST BOXES




Each bearing point represents a spot where the joist boxes intersect each other. Using a cement block at each of these points, level the joist structure once the joist boxes have been affixed together. Use the diagram above to plot the bearing points on your building site. Please note that these are the minimum number of bearing points and you may wish to use additional cement blocks as need would justify.

DECIDING ON THE ORIENTATION OF YOUR


WRAP AROUND PORCH

The wrap around porch can be oriented to wrap around the right or left side of your shed. The assembly of the joist boxes will dictate which side the gable porch will be located.

Please see the two diagrams below for details. The remainder of the diagrams in this manual will show the gable porch being wrapping around the right side of the shed. If you desire to have the gable porch wrap around the left side please make the required adjustments.



RIGHT WRAP AROUND JOIST BOX CONFIGURATION



FLOOR JOIST PARTS

1612


PART#	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS
	JOIST PARTS		
P-2423	joist	2 x 4 x 23	4
P-2424	joist	2 x 4 x 24	8
P-2443G	joist	2 x 4 x 43 1/2	18
P-2445	joist	2 x 4 x 45	27
P-2446G	joist	2 X 4 x 46 1/2	8
P-2469	joist	2 x 4 x 69	12
P-G4B46G	joist trim board	1/2 x 4 1/8 x 46 1/2	2

BUILDING JOIST BOXES

By using the joists parts outlined above and the instructions in the next few pages, assemble the joist boxes accordingly. There are various sizes of joist boxes that make up the joist structure. The number of each joist box is outlined in the table below.

JOIST BOXES REQUIRED FOR THIS MODEL				
JOIST BOX #	Joist Box Size	# of Boxes Reg'd		
P1	69" x 48"	3		
P2	24" x 48"	3		
P7	69" x 46 1/2"	1		
P8	24" x 46 1/2"	1		
P9	46 1/2" x 46 1/2"	2		
P11	46 1/2" x 72	1		
P12	46 1/2" x 24	1		


Lay the joist parts out as per Fig P1 - 1. Using 2 - 3" screws per joint, assemble the joist box together as per Fig P1 - 2. The completed joist box is pictured in Fig P1 - 3.




69" x 45" floor panel layout. Fig. P1 - 1

WWW.CEDARSHED.COM

email: sales@cedarshed.com







Completed floor panel


TOLL FREE: 1-800-830-8033

Lay the joist parts out as per Fig P2 - 1. Using 2 - 3" screws per joint, assemble the joist box together as per Fig P2 - 2. The completed joist box is pictured in Fig P2 - 3.



24" x 45" floor panel layout. Fig. P2 - 1






WWW.CEDARSHED.COM


email: sales@cedarshed.com

TOLL FREE: 1-800-830-8033


Lay the joist parts out as per Fig P7 - 1. Using 2 - 3" screws per joint, assemble the joist box together as per Fig P7 - 2. The completed joist box is pictured in Fig P7 - 3.




Lay the joist parts out as per Fig P8 - 1. Using 2 - 3" screws per joint, assemble the joist box together as per Fig P8 - 2. The completed joist box is pictured in Fig P8 - 3.



Lay the joist parts out as per Fig. P9-1. Using 2-3" screws per joint, assemble the joist box together as per Fig P9-2. The completed joist box is pictured in Fig. P9-3.




Lay the joist parts out as per Fig P11-1. Using 2-3" screws per joist assemble the joist box together as per Fig. P-11-2. The completed joist box is pictured in Fig. P11-3




46 1/2" X 26" Joist Box - P12

JOIST BOX ASSEMBLY

Lay the joist parts out as per Fig. P12-1. Using 2-3" screws per joist assemble the joist box together as per Fig 12-2. The completed joist box is pictured in Fig. P12-3.



46 ½" x 26" floor panel layout Fig P12-1








Fig. P12-3



COMPLETING THE FLOOR JOIST STRUCTURE


Take the joist boxes and affix them as per the diagram above. Make sure you keep the orientation of the ridge and gable porch in mind when doing this. Use 3" screws every 12" to affix all the joist boxes together. Once complete, lay the joist structure on top of the building site and level the joist structure on top of the cement blocks. Please use the cedar packaging blocks to assist in the levelling process. Make sure when level the joist structure clears the ground. This will allow the proper air circulation to prevent dry rot occurring on the joist structure.

There may be a need to affix joist trims on your specific model. If it is needed the diagram below will show details of how this is to be done.




INSTALLATION OF PLYWOOD FLOORING & ADDITIONAL JOIST FOR GABLE PORCH SECTIONS

Now lay the plywood sheets over top of the joist frame. Each sheet of plywood (based on size) will lay over top of the various floor boxes that have been built and attached together. Then by using the 2" screws provided, affix each sheet using a screw every 12" on centre on each of the joist members (rows). As an example, to affix a 69" by 48" sheet to the joist frame would require 30 screws (6 joist members by 5 screws per row. See Fig 3 for details



An extra joist needs to be installed in the gable porch joist boxes to give the porch decking a good nailing point. $$_{\rm 4}$\,{\rm ft}$\,{\rm deep}$$



INSTALLATION OF PLYWOOD PANELS AND RIDGE AND GABLE PORCH DECKING


The next few pages will outline the steps to install the plywood flooring and the deck boards to the ridge and gable porch areas.


	PL-I4824		
PL-16948	PL-I6948	PL-16948	GABLE PORCH
PL-14824		PL-14824	
	RIDGE	PORCH PG	

PART#	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS		
FLOOR F	FLOOR PLYWOOD AND DECK BOARD PARTS				
P-1224	deck boards	1 x 2 x 24	1		
P-1269	deck boards	1 x 2 x 69	1		
P-1424	deck boards	1 x 4 x 24	13		
P-1469	deck boards	1 x 4 x 69	13		
P-1446G	deck boards	1 x 4 x 46 1/2	54		
P-PL-I6948	plywood	5/8 x 48 x 69	3		
P-PL-I46G48	plywood	5/8 x 46 1/2 x 48	3		

Lay the $46 \frac{1}{2}$ " long deck boards over top of the level floor joist structure. Use 2-2" screws to attach the ends of each board and 1-2"screw to affix to the interior joist. The number of deck boards will vary based on the width of each board.


Size of deck	No of boards in 2 ½" wid	th No. of boards in 3 ½" width
9x4	44	31
12x4	(6) 57	41
12x4	(8) 57	41
16x4	76	54
20x4	95	67








4. Lay the deck boards over top of the porch joist structure. See table below for the correct number of pieces. Refer to Fig. 4 for details.




		# of boards based on width of:							
	2	1/2" wid	de	3	1/2" wid	le	5	1/2" wic	le
length of boards	69"	46 1/2"	24"	69"	46 1/2"	24"	69"	46 1/2"	24"
SIZE OF PORCH									
6 ft wide-3 ft deep	14	0	0	10	0	0	6	0	0
8 ft wide-4 ft deep	18	0	14	10	0	10	6	0	6
10 ft wide-4 ft deep	18	14	0	10	10	0	6	6	0






NOTE: SHADED PANELS WILL BE INSTALLED IN STEP 2 – WALL INSTALLATION STEP.




			P-2386K	
IW-005	IW-002	IW-002	IW-002	IW-002
PR-001	BW-002	BW-002	BW-002	BW-002




GW-001	-GW-001	GW-013
IW-003	IW-003	
BW-003	BW-003	
		PR-001-


STAGE 1 - WALL INSTALLATION

STAGE 1 - WALL INSTALLATION				
PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
P-2334G	header	2 x 3 x 34 1/2	4	not shown
P-2346G	header	2 x 3 x 46 1/2	4	not shown
C-BW-002	wall panel	34 1/2" wall panel	4	BW-002
C-BW-003	wall panel	46 1/2" wall panel	4	BW-003
C-IW-003	in-fill wall	12" x 46 1/2"	4	IW-003
C-IW-002	in-fill wall	12" x 34 1/2"	8	IW-002
P-2386K	filler stud	2 x 3 x 86 3/4	1	P-2386K
P-2312	filler stud	2 x 3 x 12	1	P-2312
C-DF-020	door frame (vertical)	door frame	2	DF-020
C-DF-021	door frame (horizontal)	door frame	1	DF-021
C-WW-005	window wall	34 1/2" window panel	2	WW-005






WALL A



STAGE 1 - TRIM INSTALLATION

PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
P-13C91	corner trim	1 x 3 1/4 x 87	2	CODE
P-1292C	trim	1 x 2 x 88 1/4	3	





W	
W A	
, 	

WALL C

GW-001	GW-001	GW-013
IW-003	IW-003	
BW-003	BW-003	
		PR-001
	9 5 Se C	


WALL D






GW-013	GW-001	GW-001
	IW-003	IW-003
PR-001	PR-001	PR-001
		2 2 8 1
		B:

ST	AGE 2 - WALL INSTALLATI	ON		
PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
C-PR-001	porch section	45 3/4 × 74 3/4	6	PR-001
C-PR-004	porch section	33 3/4 x 74 3/4	2	PR-004
P-2372C	door post	2 x 3 x 72 1/4	2	P-2372C
C-DF-019	horizontal door frame	2 1/2 x 72 3/4	1	DF-019
C-IW-003	in-fill wall	12" x 46 1/2"	2	IW-003
C-IW-005	in-fill wall	12" x 43 1/4"	1	IW-005
C-GW-013	gable walls	12" x 46 1/2"	2	GW-013
P-1312	trim	1 x 3 x 12	1	P-1312




TOP PLATE INSTALLATION

		IOI I LAIL MOTALLATIO	17		
	PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
Ī	P-2343C	top plate	2 x 3 x 43 1/4	2	
Ī	P-2346G	top plates	2 x 3 x 46 1/2	3	
Ī	P-2355C	top plates	2 x 3 x 55 1/4	6	
Ī	P-2372C	top plates	2 x 3 x 72 1/4	6	





STAGE 1 - ROOF INSTALLATION **DIMENSIONS** (where app.) # OF PCS PART# DESCRIPTION CODE P-2371KYb gusset 2 x 3 x 71 3/4 6 shed gable 6 GW-001 C-GW-001 gable wall 42 3/4 x 54 7/8 4 RF-005 C-RF-005 roof panel 4 C-RF-006 roof panel 46 1/2 x 54 7/8 RF-006 RF-004 24 x 54 7/8 2 C-RF-004 roof panel 1/2 x 4 x 24 2 P-B-G424 soffits 1/2 x 4 x 37 4 P-B-G437 soffits 1/2 x 4 x 46 1/2 4 P-B-G446G soffits 1 x 4 x 42 4 P-1442 fascia 1 x 4 x 46 1/2 2 P-1446G fascia 1 x 4 x 70 1/2 2 र तम जह P-1470G fascia 1 ft x 5 ft 7 sq ft P-H-RFLT12 roofing felt not shown P-H-RCAP24 24" 27 not shown ridge caps 3" x 12" P-H-MFLASS 68 not shown roof flashing gable locations

GW-001	GW-001	GW-013
IW-003	IW-003	
		28 (4)
BW-003	BW-003	
	≡ 14 ⊝	
	2 17	14 R 2
	e 0 m a	PR-001
	1 1 1	1000
	50 20 m st	



WALL D







WALLE

RF-027	RF-029	RF-028	RF-029	RF-027


STAGE 2 - ROOF INSTALLATION

SIA	GE 2 - ROOF INSTALLA	TION		
PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
C-GW-013	gable wall	small ridge porch gable	2	GW-013
C-RF-027	roof panel	42 3/4 x 47	2	RF-027
C-RF-028	roof panel	24 X 47	1	RF-028
C-RF-029	roof panel	46 1/2 x 47	2	RF-029
P-1442	fascia	1 x 4 x 42	2	4
P-1446G	fascia	1 x 4 x 46 1/2	1	连续数据
P-1470G	fascia	1 x 4 x 70 1/2	1	
P-1312	trim	1 x 3 x 12	1	on At You





WALL A




STAGE 2 - TRIM INSTALLATION

SIA	GE Z - I RIIVI INSTALLA	TION		
PART #	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
	Trim			E A More
P-1221C	gable trim	1 x 2 x 21 1/4	1	
P-1210K	trim	1 x 2 x 10 3/4	2	
P-1310K	trim	1 x 3F x 10 3/4	1	
P-B-G433	skirting	1/2 x 4 x 33	4	
P-B-G633	skirting	1/2 x 6 x 33	2	
P-B-G645	notched bevel	1/2 x 6 x 45	2	
P-B-G645	skirting	1/2 x 6 x 45	2	
P-1472	door trim	1 x 4F x 72	1	

WALL C


W
A
L
L
D


IW-005	IW-002	IW-002	IW-002	IW-002
		0 100 000	8 65 8	S 8 90
	2 2 2	u u		U E V E
	BW-002	BW-002	BW-002	BW-002
PR-001			e il unes	
6 V C				




STAGE 3 - TRIM INSTALLATION

PART#	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
	Trim			
P-1221C	gable trim	1 x 2 x 21 1/4	1	
P-13C91	corner trim	1 x 3 1/4 x 91	2	V.
P-1291	trim	1 x 2 x 91	2	OF THE STATE OF
P-1391	wide trim	1 x 3F x 91	1	
P-1292C	trim	1 x 2 x 92 1/4	3	展工灣
P-13C13G	porch trim	1 x 3 1/4 x 13 1/2	1	
P-1113G	porch trim	1 x 1 x 13 1/2	1	
P-B-G445	skirting	1/2 x 4 x 33	4	
P-B-G633	skirting	1/2 x 6 x 33	8	
P-B-645	skirting	1/2 x 6 x 45	6	
P-B-G441K	skirting	1/2 x 4 x 41 3/4	1	P. 1 1 2 2 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1
P-B-G641K	skirting	1/2 x 6 x 41 3/4	1	TOTA TOTAL
P-B-G446G	skirting	1/2 x 4 x 46 1/2	1	V
P-14B46G	porch skirting	1 x 4 1/8 x 46 1/2	1	- BERRY
P-14B45K	porch skirting	1 x 4 1/8 x 45 3/4	1	Emm
P-1458GYa	gable fascia	1 x 4 x 58 1/2	2	लेक की के व
P-1448GYg	gable porch fascia	1 x 4 x 48 1/2	1	







STA	GE 4 - TRIM INSTALLA	ΓΙΟΝ		
PART#	DESCRIPTION	DIMENSIONS (where app.)	# OF PCS	CODE
	Trim			
P-1221G	gable trim	1 x 2 x 21 1/2	1	
P-1215	porch trim	1 x 2 x 15	3	
P-1412Fx	porch trim	1 x 4F x 12	3	
P-1312Fx	porch trim	1 x 3F x 12	2	
P-B-645	skirting	1/2 x 6 x 45	4	
P-B-646G	skirting	1/2 x 4 x 46 1/2	1	5-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0-0
P-14B46G	porch skirting	1 x 4 1/8 x 46 1/2	4	Tavaragas.
P-14B47C	porch skirting	1 x 4 1/8 x 47 1/4	2	OTHER DE
P-14B53	porch skirting	1 x 4 1/8 x 53	1	TTYRIATE.
P-1458GYa	gable fascia	1 x 4 x 58 1/2	2	建筑是
P-1448GYg	gable porch fascia	1 x 4 x 48 1/2	1	