

BBK PERFORMANCE LLC
3060 Performance Circle
Deland, FL 32724

For any questions, email us:
TECH@BBKPERFORMANCE.COM



INSTALLATION INSTRUCTIONS - INS184

COLD AIR INDUCTION KIT

Part # 1831 // 2010 - 2014 Ford F-150 Raptor SVT 6.2L V8



Special Tools required: T-20 Torx



Install Time: Approximately 1 hour.



Difficulty: Easy.



MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

HARDWARE INCLUDED

BKT265 Filter Housing (1pc)
SCP072 Sponge Trimming (1pc)
SCP098 Air Filter (1pc)
SCP219A Rubber trimming (1pc)
CHD172 3-1/2" Blue Coupler (1pc)
HDW195 3/8" Heater Hose (1pc)
KIT1800/31 // SCP254 Plastic Plug (1pc),
HDW042 Hose Clamp (2pcs), HDW102 BHCS Screw M4-7x10 (2pcs),
SCP088 Rubber Grommet 3/8" ID, 7/8" OD (1pc),
SCP261 Black Straight Fitting 3/8" (1pc)

STEP 2



Remove the two vent hoses going into the factory intake system.

STEP 1



The clip needs to be pushed back then rotated down while pulling on the hose to release it from the fitting.

Disconnect the Mass Air Flow (MAF) Sensor.

STEP 3



MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 3 (CONT.)



Loosen the two 10mm mounting bolts that secure the factory intake system to the vehicle. Also remove the clip on the passenger side of the stock intake system using pliers.

STEP 4 (CONT.)



Unclip the three clips at the air box and remove the entire system out of the vehicle.

NOTE! The rubber coupler also needs to be removed from the throttle body.

STEP 4



STEP 5



Remove the MAF Sensor from the stock intake system using a T-20 Torx and install it into the BBK Cold Air Tube using the supplied hardware.

NOTE! The Air Flow of the sensor needs to be going towards the throttle body, the sensor should only fit one way because of the stagger in the hole pattern.

 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 6



Install the supplied rubber grommet and straight fitting into the BBK Cold Air Tube.

STEP 8



Place the cold air shield into the vehicle on the bottom half of the factory air box and use the three original clamps to secure the shield.

STEP 7



Install the sponge trimming onto the BBK Cold Air Intake shield and install the supplied plug into the BBK Air Filter.

STEP 9



Install the blue BBK Coupler and BBK Intake Tube to the throttle body.

 MADE IN U.S.A. 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 10



Remove the factory vent hose and replace it with the supplied 3/8" hose. Connect the supplied 3/8" hose to the plastic straight fitting on the BBK Intake Tube. The Valve Cover vent hose with the clip will be connected to the larger welded tube coming off the BBK Intake Tube.

NOTE! Be sure that the clipped vent hose is pushed onto the welded tube until it clicks into place.

STEP 11



Install the supplied Air Filter, plug in the MAF Sensor and be sure all the clamps are tight.

STEP 12

Start the vehicle and let idle for a few minutes to ensure that there are no leaks and that the check engine light doesn't come on.

 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019