SIDE STEP

User Manual

2007-2018 Jeep WRANGLER JK 4 Door



Model:	NJK02C105
Material:	Q235A
Product Dimensions:	69 x 8.5 x 4.7 inch
Package Dimensions:	72x 11.8 x 10.2 inch
Product Weight:	23.5 lbs


*Thank you for purchasing the SIDE STEP. Please read this manual carefully and keep it properly if you need to refer to it afterward. If you need any support or assistance, please contact us with your product model number and order number, and our support team will help you solve problems.

A WARNING

X This product is designed primarily to enhance the appearance of the vehicle.
Do not rely in any way on the components of this product to protect against injury or death in the event of an accident. To reduce the risk of serious injury or property damage, please read all safety messages and understand all instructions and procedure notices before attempting to install or use this product.

A CAUTION

※ Properly torque and recheck fasteners and security of step tread after 250 miles and inspect frequently. Do not use if damaged.



Parts Information

	NO.	Parts Name	Size	Line Graph	Qty	Color
1	/	Side Step L/R	1		1	Black
2	/	Front & Mid Barkects L & R	1	00000	2	Black
3	/	Rear Barkects L & R	1		1	Black
4	/	Support Barkects L & R	1		3	Black
⑤	B42	Hex Flange Bolts	M8x25		26	Blue Zinc Plating
6	W30	Spring Washers	Ф8		38	Blue Zinc Plating
7	W31	Flat Washers	Ф8		56	Blue Zinc Plating
8	N25	Hex Flanges Nuts	M8		32	Blue Zinc Plating


^{*}Note: spare parts such as B42, W30, W31 and N25 are provided with 2PCS each (included in the number of parts details).

Installation Instructions


X Note: This installation manual takes a single side as a sample, please repeat the steps for the other side.

Step 1: Open the carton and take out the parts. Check whether the number of components is complete.


Step 2: Differentiate the direction of side step and brackets




Step 3: Install the Brackets.







Step 4: Install the Side Step.



Step 5: Adjust the balance of the Side Step and the car side, and tighten the corresponding bolts.

Step 6: Adjust the balance of the pedal to the ground and tighten the corresponding bolts.

Tips: Use a stretch ruler to measure and balance the left and right sides of the pedal. Please ensure that the pedal has the same distance to the ground on both sides.

Step 7: Installation of a Side Step is complete. Please do periodic inspections of the Side Step to make sure that all hardware is secure and tight.