



## Class III Receiver Hitch Part No. 69556C




Fits:

SPRINTER 2500 & 3500 VAN (ALL) W/ FACTORY
STEP BUMPER 144" & 170" WHEEL BASE (EXCEPT 3500 144"







## **INSTALLATION STEPS**

- 1) Remove all existing nuts from bumper mounting bracket bolts.(3 per side) **Note:** Only remove nuts at this time. Removal of all bolts and nuts at the same time will cause the step bumper to fall and possibly cause step bumper and personal injury.
- 2) One at a time, remove bolt and reverse placement, inserting bolt from inside of frame outward. Push bolt into bumper mounting bracket hole and three-quarters of the way through frame. Repeat this for all existing bolts.
- 3) Place hardware provided into existing holes as shown.
- 4) Raise hitch into position aligning holes as shown. Push the remainder of each bolt through holes and fasten using nuts.
- 5) Torque all M12 fasteners to 79 lb-ft.

## PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C.

Regulation V-5 and SAE J684. For Technical & Warranty Support: 1-877-544-4449 Fax- 1-855-242-8922 <a href="https://www.huskytow.com">www.huskytow.com</a>