


INSTALLATION ON TILES:


- Drill a 6mm hole and 4mm hole as shown.
- Push in Wall Plug into 6mm hole.
- Align pin with Ø4mm Hole
- Fasten Robe Hook to the wall using the Screw provided.
- Firmly push on End Cap.

INSTALLATION ON PLASTERBOARD:

- Drill a 6mm hole and 4mm hole as shown.
- Carefully screw in Plasterboard* Anchors until the face is flush with the finished wall.
- *Maximum 15mm thickness.
- Align pin with Ø4mm Hole
- Fasten Robe Hook to the wall using the Screw provided.
- Firmly push on End Cap.



To remove cap, place pin or wire into hole shown and push firmly



WARRANTY:

Please refer to the full warranty statement enclosed with the product before installing. Or visit www.phoenixtapware.com.au to download a copy.

MAINTENANCE AND CARE:

- Products should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.

DISCLAIMER:

While we aim to ensure the specifications shown are correct at the time of printing, Phoenix Tapware reserves the right to make modifications without prior notice. Always use the physical product measurements for mark-ups and roughing-in as the line drawing shown may differ from the actual product over time.

*All measurements are shown in millimeters.