


Assembly Instructions



Console Table

Model No.
HOGA-JW1193

Contact Us




We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.



















⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List

1  1pc	2  1pc	3  1pc	4  1pc
5  1pc	6  1pc	7  1pc	8  1pc
9  1pc	10  2 pcs	11  2 pcs	



Hardware List

A	B	C	D	E	F
					
Ø6X35 mm	Ø15X12 mm	Ø8X30 mm	Ø7X37 mm	N4X64 mm	M6X12 mm
46+1pcs	46+1pcs	16+1pcs	4+1pcs	1pc	8+1pcs


G	H	I	J	K
				
3.5X14 mm	4X35 mm	Ø8X40 mm	L250 mm	26X13 mm
2+1 pcs	2+1 pcs	2 pcs	2 pcs	4 pcs

Installation of Cams and Pins



Read each step carefully before starting. Each step of instruction should be performed in the correct order. If these steps are not followed in sequence, assembly difficulties may occur.




Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.





1





A

Ø6X35 mm
34 pcs

2





A

Ø6X35 mm
12 pcs

3





B
Ø15X12 mm
4 pcs

4




B
Ø15X12 mm
8 pcs

5





B
Ø15X12 mm
4 pcs

6






D	E
Ø7X37 mm	M4X64 mm
4 pcs	1 pc

7





B	C
	
Ø15X12 mm	Ø8X30 mm
14 pcs	4 pcs



8



9




10



F


M6X12 mm
8 pcs

11





G	K
	
3.5X14 mm	26X13 mm
2 pcs	2 pcs

12



H	I	K
		
4X35 mm	Ø8X40 mm	26X13 mm
2 pcs	2 pcs	2 pcs

13



J

L250 mm
2 pcs

Thank you for your support!

