



INSTALLATION INSTRUCTIONS

www.vikingbags.com



888-208-1949 |



support@vikingbags.com

VikingBags Odin Large Double Strap Brown Leather Motorcycle Saddlebags for Harley Softail Street Bob

Parts

Fat Bracket	x 4
8mm x 15mm Flip Head Bolts	x 4
10mm Washer	x 4
8mm Collar Nuts	x 4



Fig (A)

Tools Required

Adjustable wrench
Drill
Screw driver



Fig (B)

Instructions

Step 1

Hold the bag against the fender to find out suitable bag position to mount the bags.



Fig (C)

Step 2

Once the bag is in your desired position, continue holding the bag in the position and mark the fender bolt positions on the back of the bag. These points will be used to mount the bag.



Fig (D)



INSTALLATION INSTRUCTIONS

www.vikingbags.com



888-208-1949 |



support@vikingbags.com

Step 3

With the bag laying on the floor, place the fat bracket on the back of the bag such that the uppermost hole in the bracket is aligned with the marked point on the back of the bag and the bottom of the bracket is parallel to the bottom of the bag. With bracket in position, mark the position of the bottom most hole in the bracket. Repeat the same process for the second marked point.



Fig (E)

Step 4

Drill the marked points so that corresponding bolts can pass through.



Fig (F)

Step 5

Using washers, push a Hex Head Bolt (Long) from inside the bag through each of the two upper holes and then through the bracket. The flat side of the bracket should be towards the back of the bag.



Fig (G)

Step 6

With the brackets in position, push a smaller bolt (using washers) through each of the two lower holes in the back of the bag and then through the bottom holes of both brackets. Tighten the small bottom bolts using the provided nuts.

Step 7

Now place the saddlebags against the fender and push the Hex Head Bolts into the fender holes and tighten. Your bags are now mounted and ready for a ride



Fig (H)



INSTALLATION INSTRUCTIONS

www.vikingbags.com



888-208-1949 |



support@vikingbags.com

Note

In case the bolts are too long and there is a risk that they may hit the tire, pass the Upper Hex Head Bolts through a spacer first before passing them through the back of the bag and the bracket.

Warnings

- ✓ Avoid usage of any mounting part that is impaired or is not working properly.
- ✓ Sporadically check for shifting of the bag and verify that no part of the mounting system is interfering with any part of the motorcycle while riding. This includes the drive train, suspension, brakes or wheels.
- ✓ It is important to note that if you do not mount these saddlebags properly damage may be caused to the saddlebags and/or motorcycle.
- ✓ If bags are securely installed, no part of the mounting system or bags should touch the motorcycle while in operation.
- ✓ Do not attempt to use these saddlebags if the mounting instructions are unclear. It is important that you seek professional assistance from a qualified mechanic or dealer.