

# Installation Instructions

Gardall 2hr Fire Safe Models 1612/2-3018/2

## *Tools Required:*

### For Concrete Floor Installation:

5/8" Masonry Drill Bit  
1/2" Electric (Hammer) Drill  
9/16" Socket w/Drive

### For Wood Floor Installation:

1/4" Drill Bit  
1/4" Electric Drill  
9/16" Socket w/ Drive

## Instruction for Concrete Floor Installation

1. Determine where you want to install your safe. Remember to leave clearance to open the door.
2. Place the safe where you want to mount it and mark the spot on your floor where the center of the bolt down hole in the safe will be positioned.
3. Move the safe to allow room to drill your hole. Using a 5/8" masonry drill bit and a 1/2" electric drill (preferably a hammer or percussion drill), drill your hole to a depth of 4" in the concrete floor.
4. Blow the hole clean of any dust or other material. Insert the anchor in the hole until the top is flush with the floor.
5. Remove rubber feet with 5/16" socket.
6. Return the safe to the position where it will be mounted, centering the bolt down hole in the safe over the anchor you have just placed in the floor.
7. Place the flat washer on the lag bolt and insert the screw into the mounting hole in the safe so the tip of the bolt rests in the lag anchor. Tighten the bolt using your 9/16" socket and socket drive.

## Instructions for Wood Floor Installation

1. Follow steps 1 & 2 for concrete floor installation above.
2. Move the safe to provide room to drill your hole. Using your 1/4" (or smaller) drill bit and electric drill, drill your hole through the wood floor.
3. Return the safe to where you are going to install it, centering the bolt down hole in the safe with the hole in the floor.
4. Place the washer on the lag bolt and insert the bolt in the bolt down hole in the safe with tip of the bolt in the hole in the floor. Tighten the bolt using your 9/16" socket and drive.