

60" Cable Management Desk Organizer

SKU: DESK-SKIRT-60 Instruction Manual



A CAUTION! A

If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.

We're Here for You

Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



Give us a Call: **309-278-5303**

AVG. RESOLUTION TIME (within office hrs): 5M 4S



Chat Us:

www.vivo-us.com

AVG. RESOLUTION TIME (within office hrs): < 15 M




Email Us:

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr

Package Contents



Included Hardware



W-A (x1) 3/4" Screw

Tools Needed:



Phillips Screwdriver



Power Drill




Pencil


ASSEMBLY STEPS


STEP 1

Connect the centers of the T Joiners (C) to the ends of the Middle Bars (F).



Connect the Upper/Lower Bars **(E)** to the sides of the T Joiners **(C)**, then connect the Joiners **(G)** and Side Bars **(B)** to the sides to complete the frame assembly. Lighty tap each joint against a hard surface to ensure all bars and joiners are full pressed in.






4

STEP 2

Open the flap and straps of the Panel **(A)** and insert the frame, making sure the frame is fully inserted and the material is tightly stretched around it.

Note: Confirm that frame pieces are fully secure into each other before sliding into panel.







Snug Fit:

Fabric on Panel has a tight fit around the frame and may need to be stretched before inserting the frame.

Fasten Straps (A1) on inside of Panel (A) to secure the frame.






STEP 3

Place the plastic Mounting Clips **(D)** in the center of each exposed portion of the steel bars.

NOTE: Make sure the wire management flap on the Panel **(A)** is facing the inside of the desktop.






S-A (x1)


STEP 4

Center the assembled panel under the desktop and use a pencil to mark the locations of Plastic Mounting Clips **(D)**. **NOTE:** Desktop must be at least 1" thick to prevent screws from poking out through the top and damaging the surface.




STEP 5

Drill pilot holes using a 1/8" (3mm) bit. Mount the assembled panel to the underside of the desk using 3/4" Screws **(W-A)** as shown into Plastic Mounting Clips **(D)**.



Route and organize the cables and secure them using the flap on Panel (A).





Need Help? Get In Touch

Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com
Chat live with an agent!



309-278-5303

