


Pneumatic Arm Single Ultrawide Monitor Wall Mount Instruction Manual



SKU: MOUNT-V101G1/W



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/mount-v101g1

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



B

www.vivo-us.com Chat live with an agent!



🚹 WARNING!


If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.

AUTION!

DO NOT INSTALL INTO DRYWALL ALONE. VERIFY YOUR WALL CONSTRUCTION. USE WOOD STUDS TO MOUNT. We include mounting for brick and concrete walls. If unsure, please contact us at vivo-us. com, email at help@vivo-us.com, or call us at 309-278-5303.

🖄 WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.




ASSEMBLY STEPS

STEP 1 (Option A)

OPTION A: Wood Wall Installation


Use Wall Bracket **(A)** to mark drilling locations on the wall where a stud is located. Use of a level and stud finder is recommended. Using a 3/16" (4.5mm) bit, drill 2.2" (55mm) deep holes into marked locations. Secure Wall Bracket **(A)** to the wall using ST6.3x55 Screws **(W-A)** with M6 Washers **(W-C)** and a 10mm socket wrench. Insert Round Screw Cap **(E)** and Oval Screw Cap **(F)** into the mounting holes.




STEP 1 (Option B)

OPTION B: Concrete/Brick Wall Installation

Use Wall Bracket **(A)** to mark drilling locations on the wall. Use of a level is recommended. Using a 3/8" (10mm) bit, drill 2.4" (60mm) deep holes into marked locations. Insert Concrete Anchors **(W-B)** into predrilled holes. Secure Wall Bracket **(A)** to the wall using ST6.3x55 Screws **(W-A)** with M6 Washers **(W-C)** and a 10mm socket wrench. Insert Round Screw Cap **(E)** and Oval Screw Cap **(F)** into the mounting holes.





Assemble Lower Arm (**B**) and Gas Spring Arm (**C**) to Wall Bracket (**A**). Tighten set screws on Wall Bracket (**A**) and Lower Arm (**B**) using 3mm Allen Wrench (**T-A**).



STEP 3


Connect VESA Plate (**D**) to Gas Spring Arm (**C**) using Keyed Spacer (**S-A**), M8x25mm Screw (**S-B**), and 6mm Allen Wrench (**T-B**). Ensure that hexagon side of Keyed Spacer (**S-A**) is facing upward towards VESA Plate (**D**). Remove Thumbscrew (**D1**) from back of VESA Plate (**D**). Separate Front VESA Plate (**D2**) from Back VESA Plate (**D3**). Set aside.






STEP 5


To mount the monitor, begin by lining up the tabs on Front VESA Plate (**D2**) with the slots on Back VESA Plate (**D3**). Insert tabs into slots and re-install Thumbscrew (**D1**) into Back VESA Plate (**D3**) to secure.






STEP 7

Remove the cable management cover from Gas Spring Arm (C) using a Phillips screwdriver. Slide The cable management cover from Lower Arm (B) off. Route cables and reattach cable management covers.







Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

