INSTALLATION GUIDE
Switch Dry Bar Table Frame

jason.l
your office furniture mate

Sizes

3600 x 1200 mm

3000 x 1200 mm

Tools Required: Power screwdriver.

Note: Please ignore any pre-drilled holes or nut inserts that maybe present in your top(s). They will not match your particular table/desk base and woods screws will be required to be screwed directly into the underside of the top.

Note: It is important to fully tighten all bolts and screws before attaching the top(s) so that the frame is sufficiently rigid. Failure to do this may affect stability once the tops are attached.

Switch Dry Bar Table Frame

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

COMPONENTS

1   Table Top x3
2   Leg x6
3   Leg Bracket x6
4   Beam L-Bracket x8
5   Beam T-Bracket x2
6   Long Beam x4 (1440mm)
7   Short Beam x3 (580mm)
8   L-Bracket x14

SCREWS

9   Hex Nut x6
10 L-Bracket screws x14
11 Hex Head screws x12
12 M8x25mm Dome Head x6

T-beam bracket

INSTALLATION GUIDE
# Switch Dry Bar Table Frame

www.jasonl.com.au

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

01

Join Leg Brackets to each Leg using screws to secure them, as follow.

02

Join 2 L-Bracket through each 580mm Beam
and 2 L-Bracket through each 1440mm Beam

03

Securely connect each Beam to each Beam Bracket. Screw to secure.

04

Insert Hex Nut on each Beam Bracket.

**jason.l**
your office furniture mate

05

Position as presented, and proceed to screw to ensure each corner of the frame.

If this bolt does not drop into the joint use the Allen key to screw it all the way in so that it creates its own thread. This will ensure a nice, tight joint.

06

For the 2 central legs, attach as presented, using T Beam Bracket.

Need help!
Call us on
1300 527 665

jason.l
your office furniture mate

> **Note:** It is important to fully tighten all bolts and screws before attaching the top(s) so that the frame is sufficiently rigid. Failure to do this may affect stability once the tops are attached.

07

Directly screw into table tops, using L-Bracket screws through each L-Bracket.