


- $\textcircled{\sc A}$  Total length of tub
- $\ensuremath{\textcircled{B}}$  Total width of tub
- $\ensuremath{\mathbb{C}}$  Inside length of tub at top
- $\ensuremath{\mathbb{D}}$  Inside length of tub at bottom of seating area
- E Inside width of tub at top
- $\ensuremath{\mathbb{E}}$  Inside width of tub at bottom
- $\ensuremath{\mathbb{G}}$  Edge of tub to center of drain & overflow
- $\ensuremath{\boldsymbol{\Theta}}$  Edge of tub to center of drain
- ① Overflow to bottom of tub at deepest point
- $\bigcirc$  Top of tub deck to tub floor at deepest point
- $\bigotimes$  Bottom of tub lip to bottom of base rail
- $\bigcirc$  Top of tub deck to bottom of base rail

## A7343 ELITE AIR TUB





INSTALLATION: Add 1/2" to 1" height of tub at point (k) to allow space for bedding compound. All Watertech Whirlpool Baths require mortar to be placed under tub for tub bedding. Please measure tub before building tub cabinet. Drawing shows standard pump location for this tub. Custom pump locations available - please call Watertech Whirlpool Baths for details. Measurements are plus or minus 1/2", and are subject to change without notice. Filling this tub to the maximum may require an above average size or dedicated water heater. This data sheet supersedes all specifications published prior to this publication date.