
## S A C R É D B U N D L E

LUXE ESSENTIALS | FOR YOUR MINI

### Zali

Teak Cot



# IMPORTANT PLEASE READ THE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

Sacred Bundle Pty Ltd. ABN 47631902479

5/108 Dover Drive, Burleigh Heads, QLD, 4220.

Phone: +61 4 34362219 +61 4 23688138

Email: bubinfo@sacredbundle.com.au

www.sacredbundle.com.au


#### Zali Teak Cot - ZA10010

Assembled Dimensions 1360L x 740D x 940H mm Mattress Dimensions 1320L x 700D x 110H mm Materials: Natural Teak

Internal Dimensions 1320L x 700D x 110H mm

## 


#### **Parts List**



#### Assembly




Screw in each leg to the base by matching the numbered stickers.




2


Attach both long cot sides by matching the numbered stickers.



A x 6







#### **AUSTRALIAN STANDARDS COMPLIANCE**



#### WARNING

WARNING: TO PREVENT FALLS THE MATTRESS BASE OF THIS COT SHOULD BE ADJUSTED TO THE LOWEST POSITION BEFORE THE CHILD CAN SIT UP RECOMMENDED MATTRESS SIZE: 1320 MM LONG X 700 MM WIDE X NO MORE THAN 120 MM THICK

- Failure to follow these warnings and the assembly instructions could result in serious injury or death.
- Before each usage or assembly, inspect cot for damaged hardware, Loose joints, missing parts or sharp edges. Do not use cot if any parts are missing or broken. Contact Sacred Bundle Pty Ltd for replacement parts and instructional literature if needed. Do not substitute parts.
- When child is able to climb out or reach the height of 90 cm, the cot shall no longer be used.
- Do not place cot near window where cords from blinds or drapes may strangle the child.
- If refinishing, use a non-toxic finish specified for children's products.
- Do not use a water mattress with this cot
- Upon completion of assembly, be sure all screws and bolts have been tightened securely.
- A periodic check should be made of all screws and bolts and tightened if necessary.
- Never use plastic shopping bags or other plastic film as mattress covers or pillow case as they can cause suffocation.
- Do not drag cot.
- After cot has been completely assembled, store instruction sheet in a safe place for future reference.
- Under no circumstances should the warning labels be removed from mattress support and removable base!



#### WARNING

WARNING: TO PREVENT FALLS, THE MAXIMUM MATTRESS THICKNESS SHOULD NOT EXCEED 120 MM.

## IMPORTANT SAFETY INFORMATION FOR TODDLER CONVERSION KIT



#### **WARNING: ENTRAPMENT / STRANGULATION HAZARD**

- Infants have died in toddler beds from entrapment and strangulation.
- Failure to follow these warnings and the assembly instructions could result in serious injury or death.
- A child using the toddler or day bed shall be at least 18 months of age and shall not weigh more than 22kgs.
- DO NOT place bed near windows where cords from blinds or drapes may strangle a child.
- DO NOT place items with a string, cord, or ribbon around a child's neck, such as hood strings or pacifier cords.
- If guardrails are used as the mattress containment means, guardrail(s) provided must be used to avoid the formation of a gap between the mattress and the bed that could cause an entrapment.
- The mattress intended for use on the bed shall be a full-size cot mattress having minimum dimensions of 1320mm in length, 700mm in width and 120mm in thickness, not exceeding 152mm in thickness.

#### **CARE & MAINTENANCE**

Congratulations and thank you for choosing Sacred Bundle product(s). The furniture you have purchased is constructed from high quality materials for strength and durability. Here are some tips on how you can preserve its beauty for a long time.

- Do not expose furniture to direct heat sources, extreme changes in temperature or moisture. The cot should not be placed directly next to airconditioning, outlets, fire places, radiators, space heaters, humidifiers, or dehumidifiers. Exposure to extreme variations of temperature and humidity can damage wood products.
- 2. Keep the cot out of direct sunlight. UV rays may fade colours and in some cases darken them. It can cause crazing or hair line cracks in the finish. Finishes will darken naturally over time and exposure to direct sunlight will hasten this natural process along with some wood darkening; this is not considered to be a quality defect.
- 3. Wipe up spills immediately with a soft, clean cloth.
- 4. Urine spills on furniture can cause discolouration.
- 5. Clean furniture by wiping the surface with a soft cloth dampened with water.
- 6. If necessary clean furniture using a mild soap solution and wipe clean with a soft cloth dampened with water and then dry with soft clean cloth.
- 7. Do not use strong household cleaners.
- 8. Always wipe in the direction of the grain in the wood do not wipe in a circular motion.
- 9. Avoid contact with sharp objects, or containers containing hot liquid.
- 10. When moving furniture do not drag always lift and place in position.
- 11. To remove any residue from assembly stickers, wipe off gently with a small amount of rubbing alcohol on a clean cloth.
- 12. In case of the appearance of mildew after storage, generously spray all affected areas with a mix of 1:10 part vinegar and water. Once the mix has been applied, let it sit for 10 minutes and wipe clean with a dry cloth. Place the affected parts outside in direct sunlight for 1 hour to air out and allow it to thoroughly dry.
- 13. Always check that the cot is free from damage before use. Do not use product if any damage is present.
- 14. Regularly check that all assembly fittings are always tightened properly and retighten as necessary.