



PiñaColadaVille Cream Ale



There exists a magical place burrowed deep in your imagination where the coconut palms sway in the breeze and the Calypso drummer taps out that tropical tune on the steel drums, and your worries of the day simply melt away like footsteps in the sand wiping clean with the ebbing tide of that miraculously blue sea. We call this place PiñaColadaVille, and it is the foreverland of warm sand and eternal sunshine, where the condensation runs clean down your frosty pint of this enchantingly golden ale, which is soft, smooth and creamy and dances with the hypnotic rhythm of coconut and the delightful zing of pineapple, tickling your tongue and lightening your senses so that you are transported to this dreamy land without a care in the world to relax evermore in your own personal PiñaColadaVille.

Just the Facts, Ma'am:

BJCP Style: 29A. Fruit Beer
 Recipe Size: 5 Gallons
 Original Specific Gravity: 1.050 - 1.054
 Final Specific Gravity: 1.011 - 1.015
 Alcohol by Volume: 5.1%
 Color: 5 SRM (Deep Creamy Golden)
 International Bittering Units: 16
 Yeast Starter: No
 Secondary: Optional (That means your choice.)
 Time to Awesome Drinkability: 4 Weeks!

Your recipe kit includes the freshest malt, hops and yeast. If you are not going to brew your recipe immediately, it is important to refrigerate your yeast and hops. If your recipe includes bags of malt syrup, these should be refrigerated too. Bags of dried malt do not require refrigeration. Also, all grains are best stored at dry room temperature.

Ingredients:

Fermentables:

1 lb Wheat Light Dry Malt Extract
 3.8 lbs Extra Light Malt Extract Syrup
 1 lb Corn Syrup Solids
 8 oz Lactose

Grains & Wort Additives:

6 oz Light Caramel Malt (Crushed)
 12 oz Flaked Oats

Hops:

¼ oz Polaris Hops (Bittering, 50 Minutes)

Yeast:

Liquid Yeast: Wyeast 2565 Kolsch Yeast or
 Wyeast 1010 American Wheat Yeast

Or

Dry Yeast: Safale K-97 Ale Yeast or
 Safale S-05 Ale Yeast

Brewing Supplies & Flavors:

2 oz Pina Colada Flavor Extract (Add 1 Day Before Bottling)
 1 Large Muslin Bag
 5 oz Priming Sugar

Brew Day Checklist:

On brew day, you will require the following equipment:

- Brew Pot - A 5 gallon brew pot is ideal, but never use a pot that is less than 4 gallons.
- Long-handled spoon or paddle for stirring the boiling wort.
- Primary Fermenter - A 6½ gallon (or greater) food-grade plastic bucket with lid, or a 6½ glass carboy.
- Airlock
- Stopper (if using a carboy)
- Funnel (if using a carboy)
- Hydrometer (Optional, if you want to measure your specific gravity)
- Sanitizing Solution
- Scissors

The Magical Procedure:

Liquid Yeast Activation Before Brewing:

If you are fermenting with liquid yeast, you must activate the yeast packet before it is ready to pitch. Always check the manufacturing date stamped on the yeast packet. Yeast that is less than 1 month old may be activated on brew day. A yeast that is more than 2 months old may require additional preparation time. Always make sure your yeast has been properly activated before using. For more information about yeast starters, please visit the 'Frequently Asked Questions' section on boomchugalug.com.

Time to Brew!

Total Boiling Time: 50 Minutes. While your wort is boiling, you should sanitize your fermentation equipment, such as your primary fermenter, airlock, scissors, stopper, etc. After you have sanitized your fermenter, fill it with 2 gallons of cold water, into which you will later add your hot boiled wort.

1. Place the crushed grains in the muslin bag and add to 2½ gallons of water. Measure the water volume carefully to ensure you extract the proper amount of hop bitterness during the boil.
2. Heat water until the temperature is between 150° and 170°F. Steep the grains between this temperature range for 30 minutes. Steeping longer than 30 minutes does not hurt.
3. Remove and discard the grains, and bring this mixture to a boil. Remove the pot from the heat and add 1 lb of wheat dried malt extract. Stir until completely dissolved. Do not add the malt extract syrup, corn syrup solids or lactose until step 4. To prevent scorching, stir until all of the malt is dissolved.
4. Bring this mixture back to a boil. When boiling begins again, add ¼ oz Polaris hops. Boil these hops for 50 minutes.

Boomchugalug.com

Flip the sheet to continue the magic. Also, this is a good time to pour a cold one! →





PiñaColadaVille Cream Ale



Page 2....Wow, this is good stuff. I wish there could be more!

5. With 5 minutes remaining in the 50 minute boil, pause the brew timer and remove the pot from the heat. Add the bag of malt extract syrup, the corn syrup solids and the lactose. Stir until dissolved and bring this mixture back to a boil. When boiling begins again, boil the wort for the last 5 minutes.

Chill out, Man! (Chill the Wort)

1. At the end of the 50 minute boil, cool the wort to approximately 75°F as quickly as possible. With extract brewing, the easiest way to quick-chill the wort is to place your brew pot into a sink full of ice. For more information about cooling your wort quickly, please see 'Fast Wort Chilling' in the 'Frequently Asked Questions' section on our website.
2. Add your chilled wort to the 2 gallons of water already in your fermenter.
3. Add any extra water needed to bring the total volume in your fermenter to 5 gallons.
4. If you would like to measure the specific gravity, now is a good time. To get an accurate reading, it is important to make sure all of the heavy wort extract you added to the fermenter has been completely mixed in the water.

Pitch the Yeast! (Into the Wort, But Not Out the Window!)

1. When your wort has cooled to approximately 75°F (70° - 78°F is okay), aerate the wort before adding the yeast. Simply close the fermenter and swirl around to mix in oxygen. If you are swirling a carboy, it is helpful to place the carboy on a thick, folded blanket to avoid damaging the vessel.
2. After aerating, pitch (add) the yeast. Use the sanitized scissors to cut open the yeast packet. If you are using liquid yeast, sanitize the pack before opening. If you are using dried yeast, simply sprinkle the yeast over the wort. No mixing is necessary.
3. Close the fermenter, attach the airlock, and keep the fermenter warm (between 70° - 78°F) until you see fermentation beginning, such as the airlock bubbling once every 30 seconds. Wrapping the fermenter with a blanket is an easy way to keep the fermenter warm.

Fermentation:

There are several ways to know when fermentation has begun. First, you will begin to see bubbling through the airlock. If you are using a carboy, then you will usually see the yeast begin to form a layer over the beer's surface.

1. Once fermentation begins, move the fermenter to a room with the proper temperature. The ideal temperature to ferment this beer is between 68° - 70°F. Do not let the temperature drop below the minimum specified temperature. If you do, fermentation may stop too soon. That's a bummer, man.
2. Active fermentation may take as long as two weeks after pitching the yeast, although fermentation may finish in 3 to 5 days.
3. If you choose to siphon the beer to secondary carboy for additional clearing and maturation, do so when fermentation begins to slow. If you will not be using a secondary, allow fermentation to complete in the primary fermenter.
4. On the day before you bottle your beer, add the complete bottle (2 oz) of the piña colada flavor to the fermenter. The flavor is added now to prevent possible beer over-carbonation if they are added on bottling day.

Time to Bottle!

There are several ways to tell when fermentation is complete (besides your drooling). If you correctly pitched the yeast and fermentation quickly began, and if the beer fermented vigorously and the fermenter was always within the correct temperature range (58° - 70°F), then fermentation should finish in two weeks or less. You should see virtually no activity in the airlock. For example, if the airlock only bubbles once a minute or longer, then fermentation should be complete. If you are unsure if fermentation has ended, you may use your hydrometer to measure the specific gravity. If your specific gravity does not change after two or more days, then fermentation is complete and you are ready to bottle!

1. Before bottling, sanitize your bottling bucket, auto siphon (or racking cane), hose, bottle filler, caps and bottles. Glass bottles may be sanitized one day in advance by baking them in the oven. More information about baking your bottles can be found under 'Baking Beer Bottles' in the 'Frequently Asked Questions' section on our website.
2. Dissolve 5 ounces (by weight) or 3/4 cup of corn sugar in 16 oz of water. Boil for 5 minutes. Corn sugar is sometimes called dextrose or priming sugar.
3. Place your fermenter on the counter and your bottling bucket on the floor. Pour the sugar solution into the bottling bucket, and siphon the beer from the fermenter into the bottling bucket. Siphon carefully, trying to minimize splashing and aeration of the beer. Also when siphoning, be sure to leave behind the sediment at the bottom of the fermenter. There's no problem if you should siphon up a little sediment. When you're done siphoning, gently stir the beer in the bottling bucket to make sure all of the sugar solution has been dissolved. Your racking cane makes a convenient stirring wand.
4. Place your bottling bucket on the counter, and attach your siphon hose and bottle filler to the bucket's spigot. Fill the bottles to about 1 inch from the top, and cap each bottle.

Carbonation and Maturation!

Now that your bottles are primed and capped, the remaining yeast will undergo a second fermentation in the bottle whereby they eat the priming sugar and produce carbon dioxide, which is trapped in the bottle to produce the carbonation. While your beer is carbonating, it will also be clearing and maturing - the young, rough undeveloped flavors develop into your magical beverage! Your wondrous elixir reaches awesome drinkability about 4 weeks from the day you began the brew, but don't be surprised if it keeps getting better as time goes on.

1. Place your bottles in a dark place at room temperature (62 °F - 75 °F), and wait at least two weeks for the beer to carbonate. It is important that you keep the beer between 62 °F - 75 °F for carbonation to develop. If the beer cools below 62 °F, it may not properly carbonate. In brewing, this is officially known as the buzzkill. Keep it warm, let it carbonate!
2. Get your bottle opener handy dude (or dudette), because it's time to drink a beer! When pouring the beer into your glass, be sure to leave the bottle's sediment behind. That sediment is the yeast which carbonated your beer, and if you pour it into your glass, you'll make the beer cloudy and taste yeasty.
3. Once your beer is carbonated, you may store it in a cool place. Keep in mind that home-brewed is unfiltered, and unfiltered beers actually continue to improve with time. If your beer seems rough-around-the-edges or tastes yeasty, these qualities usually morph into a smooth, clean beer over time. Cheers!



Boomchugalug.com

