







LIGHT ELASTIC VAPOUR CONTROL LAYER

Technical Data Sheet

Description	Standard	Performance
Weight	ISO 356	100 g/m²
Colour		White
SD Value	EN-1931	5 m
Reaction to Fire	EN 13501-1	E
Water Resistance	EN 1928	W1
Tensile strength MD/CD*	EN 12311-1	120 N/ 110 / 50mm
Elongation MD/CD*	EN 12311-1	70% / 70%
Nail Tear Resistance MD/CD*	EN 12310-1	80 N / 80 N
Temperature resistance		-40°C to 80°C
CE labelling	EN 13984	Available

Advantages

IZOPERM is a vapour check with an Sd value of 5 (US Perm of 0.69). This provides optimal vapour control for most constructions.

- √ Designed to be compatible with all conventional building systems
- √ Elastic and Durable
- $\sqrt{}$ Optimum Sd value for most constructions
- ✓ Optimal protection against humidity, ensures drying of the building structure

CE

*MD = longitudinal CD = transversal

"The information provided is based on current knowledge and experience. This data sheet may become invalid and we reserve the right to make changes to designs and processes as we continually improve quality. Processing instructions including full system component details should be adhered to. Visit partel.com for the most up to date information"





www.partel.co.uk sales@partel.co.uk P: 02037 401918



www.partel.com sales@partel.com P: 888 487 1012





Fields of Application

Partel **IZOPERM** can be used as an inner airtight membrane and vapour control layer for externally vapour open build-ups.

- Roof, wall, floor and ceiling
- Residential and commercial building
- Compatible with all insulation types and does not shrink

Application Process

IZOPERM should be installed with the printed side facing the installer in a taught manner with all creases, seams, overlaps, joints and penetrations completely sealed. It should be installed so that all overlaps are sealed by taping to the printed side, and can be installed parallel or perpendicular to the supporting structure with maximum distances between supports of 1000mm (40").

If installation is perpendicular to the supporting structures a batten is required or additional taping at 500mm strips perpendicular to overlap joints at 300mm (12") intervals. **IZOPERM** must overlap by 100mm (4") and perpendicular battens should be installed to support the weight of insulation and to protect the product from future damage.

Staple in a triangular pattern to ensure the membrane is taught but make sure membrane is relaxed at junctions to allow for movement. Staple at 75mm (3") intervals for blown in insulation or 300mm (12") generally. Staples should be 10 mm (0.4") wide and 8 mm (0.31") long.

Partel **CONDUO** can be used as an installation aid where staples cannot be used, Overlaps can then be sealed with **VARASEAL**, **CONIZO**, or **CONEXO**.

Penetrations should be sealed using **KABSEAL** or **CONLEX BUTYL** and edge connections can be sealed with **ACRABOND**, **ACRALINE** or Partel tapes.

In cold climates blown in insulation should be installed as soon as **IZOPERM** installation is complete and for loose fitted installation **IZOPERM** should be fitted immediately after installation. Installation of vapour control layers in cold temperatures should make allowance for necessary heating, ventilation as adhesives and primers are water based, and adhesives will not adhere to wet surfaces. In high humidity situations >70% and cold temperatures visible water could be seen on the internal surface of IZOPERM which prevents functionality.

"The information provided is based on current knowledge and experience. This data sheet may become invalid and we reserve the right to make changes to designs and processes as we continually improve quality. Processing instructions including full system component details should be adhered to. Visit partel.com for the most up to date information"





www.partel.co.uk sales@partel.co.uk P: 02037 401918



www.partel.com sales@partel.com P: 888 487 1012





General Information

Connection joints should be free from tensile strain. Acrylic base adhesive tapes are pressure activated, sufficient pressure is required to ensure a long lasting bond. A smoother physical substrate will result in optimum adhesion between tape and surface. It is the responsibility of the applicator to check the substrate for suitability, adhesion tests are recommended in non standard situations.

Use **ACRAPRIME** to prime all rough, porous or dusty surfaces.

"The information provided is based on current knowledge and experience. This data sheet may become invalid and we reserve the right to make changes to designs and processes as we continually improve quality. Processing instructions including full system component details should be adhered to. Visit partel.com for the most up to date information"





www.partel.co.uk sales@partel.co.uk P: 02037 401918



www.partel.com sales@partel.com P: 888 487 1012