


# 4. Adjustment



Loosen the adjusting knob to tilt the desired angle then tighten them.

### Maintenance

- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your distributor if you have any questions.




### INSTALLATION MANUAL

# **Tilting Wall Mount**


# - We Will Make It Stress Free -

Please reach out to us if you have any questions at all. 1-877-38-HUSKY(1-877-384-8759) We are here to help!










### NOTE: Read the entire instruction manual before you start installation and assembly.

# 


- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact the seller.
- This mounting bracket was designed to be installed and utilised ONLY as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- If mounting to wood wall studs, make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.
- Make sure that no electrical cable, water pipes or gas pipes are located within the mounting surface in the wall.
- We hereby disclaim any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


## Component Checklist

**IMPORTANT:** Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, please contact the seller for replacement.




## 1a. For Wood Stud Wall Mounting (do not use Concrete anchors W-B)





(24")


 $\checkmark$ 




# / WARNING

- Make sure that mounting screws are anchored into the center of the studs. The use of a stud finder is highly recommended.
- Installers are responsible to provide hardware for other types of mounting situations.
- Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

### **1b. For Solid Brick and Concrete Mounting** (the use of the concrete anchors W-B is necessary)



0






Mark the exact location of mounting holes



Drill pilot holes





00°00

 $\sim$ 




Screw the wall plate onto the wall


# / WARNING

Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

# 2. Installing the Adapter Brackets



### 2-1 For Flat Back Screens



# 2-2 For Recessed Back Screens or to Access A/V Inputs

Note: Choose the appropriate screws, washers and spacers (if necessary) according to the type of screen.
if the spacers are used, they should be placed between the mounting arms and the back of TV, and not between the mounting arms and the head of the screw.

wall

Ď

• Position the adapter brackets as close as possible to the center of the TV.

• Screw the adapter brackets onto the TV.



# 3. Hanging the TV onto the Wall Plate

