FULL CUTOFF WALL PACK


Installation Guide

MARNING


- 1. To avoid electric shock, disconnect power at source prior to installation.
- 2. The installation should be performed by qualified electricians or lighting technicians.
- 3. Before conducting any installation, maintenance, or removal, disable all power to the luminaries and wait until the fixture cool down.
- 4. Do not touch the fixture while it is in service.
- 5. Unless individual product specifications deem otherwise: Do not exceed fixtures maximum ambient temperature(-40°F to 104°F).
- 6. Keep combustible and other materials that can burn, away from lamp/lens.
- 7. If there is any problem with the fixture, DO turn off power and DO NOT attempt repair unless you are a qualified technician or the customer service member.
- 8. Make all electrical and grounded connections in accordance with the National Electrical Code (NEC) and any applicable local code requirements.
- 9. Wear gloves and safety glasses at all limes when removing luminaire from carton, installing, servicing or performing maintenance.
- 10. Avoid direct eye exposure to the light source while it is on.
- 11. This product is not available for several special environments, such as places with corrosive gas liquids or high pressure water vapor.

Mounting Plate Installation (Default)


1. Loosen two M6*20-SS screws until they level with the steps and remove the wall mounting plate.




3. Hang the fixture on the wall mounting plate with a wire rope, and pay attention to protect the surface of the fixture during installation to prevent scratches and damage to the surface. Ensure the line voltage at the fixture is correct, make all necessary wiring connections, and push



2. Stick EVA gaskets on the back of the wall mounting plate properly, which is very important for water proof. Fix the wall mounting plate on the junction box according to the arrow pointing upwards. Note that the wall mounting plate must be leveled before tightening the screws.




3. Hang the fixture on the wall mounting plate with a wire rope, and pay attention to protect the surface of the fixture during installation to prevent scratches and damage to the surface. Ensure the line voltage at the fixture is correct, make all necessary wiring connections, and push all the wires and wire nuts into the j-box.




PHOTOCELL INSTALLATION

Universal voltage driver permits operation at 50/60 Hz except fixtures factory ordered with a 120-277VAC (PO) photocell.

- 1. Install photocell and wire as per diagram.
- 2. Use photocell rated for your supply voltage.



EMERGENCY WIRE CONNECTION



TROUBLESHOOTING

- 1. Check that the line voltage at the fixture is correct. Refer to wiring directions.
- 2. Is the fixture grounded properly.

WIRING DIAGRAM

