
SEAVIEW// ELEVATE YOUR ELECTRONICS



INSTALLATION INSTRUCTIONS


For Seaview Light Bar Top:

LTB-U1A

Refer to website for most up to date instructions and videos.

WWW.SEAVIEWGLOBAL.COM

PARTS INCLUDED





TOOLS NEEDED

Sudbury Elastomeric Marine Sealant is recommended. To purchase call 800-655-7922 or visit










Refer to the appropriate set in instructions depending on your LTB-U1A


setup.



Mark the necessary holes to drill.

A2

Drill the holes that you just marked.






Mark the enter cable hole for drilling.




Drill the center cable hole.




Apply marine adhesive sealant around the holes that you drilled for the light assembly. Secure the light assembly. You may be able to use one of the provided screws.




Route the GPS cables through the top.




Apply marine adhesive sealant around the top of the Light bar as shown, then slide the LTB-U1A on to the Light Bar.



Apply marine adhesive sealant to the LTB-U1A mounting holes. Then insert the two plastic rivets into holes as shown.




Apply marine adhesive sealant into the groove of the LTB-U1A as shown.



A10


Use the remaining screws to finish securing the light assembly and the top onto the LTB-U1A.




Apply marine adhesive sealant around the top of the Light bar as shown, then slide the LTB-U1A on to the Light Bar.



Apply marine adhesive sealant to the LTB-U1A mounting holes. Then insert the two plastic rivets into holes as shown.







Apply marine adhesive sealant into the groove of the LTB-U1A as shown.


B4

Secure the light assembly and top to the LTB-U1A with the six screws.





Finish assembling the light assembly.





SEAVIEW//

Tel: 800-655-7922 www.seaviewglobal.com

EUROPEAN OFFICE

Tel: +33 4 94 53 27 70 www.seaviewprogress.com