

Product May Vary Slightly From Pictured.

CAUTION: Weight on this product should not exceed 300 lbs.

This Product is Distributed Exclusively by



2040 N Alliance Ave, Springfield, MO 65803 **Customer Care** 1 (800) 375-7520 www.staminaproducts.com

Exercise can present a health risk. Consult a physician before beginning any exercise program with this equipment. If you feel faint or dizzy, immediately discontinue use of this equipment. Serious bodily injury can occur if this equipment is not assembled and used correctly. Serious bodily injury can also occur if all instructions are not followed. Keep others and pets away from equipment when in use. Always make sure all bolts and nuts are securely tightened prior to each use. Follow all safety instructions in this manual.

When calling for parts or service, please specify the following numbers:

Model#: 65-1485A

S/N:

STAMINA PRODUCTS **MADE IN CHINA**

© 2020 Stamina Products, Inc. 2020, 12



Smart Audio Workouts for Your Rower



Go to the App Store on your device or scan the QR Code for quick access.



Download the app and get moving! Assembly video included in app.

TABLE OF CONTENTS

Safety Instructions	3
Before You Begin	5
Equipment Warning, Caution & Notice Labels	6
Hardware Identification Chart	7
Assembly Instructions	8
Set Up Instructions 1	2
Storage 1	13
Maintenance 1	13

Conditioning Guidelines	14
Warm-Up and Cool-Down	15
Workout Guide	16
Product Parts Drawing	18
Parts List	19
Warranty	20
Notes	21
Fax/Mail Ordering Form	22

SAFETY INSTRUCTIONS

A WARNING Cancer and Reproductive Harm www.P65Warnings.ca.gov

A WARNING Consult your physician before starting this or any exercise program. This is especially important if you are over the age of 35, have never exercised before, are pregnant, or suffer from any health problem. This product is for home use only. Do not use in institutional or commercial applications. Failure to follow all warnings and instructions could result in serious injury or death.

- A WARNING To reduce the risk of serious injury, read the following Safety Instructions before using the STAMINA® Outdoor Power Tower PRO.
- 1. Save these instructions and ensure that other exercisers read this manual prior to using the STAMINA® Outdoor Power Tower PRO for the first time.
- 2. Read all warnings and cautions posted on the STAMINA® Outdoor Power Tower PRO.
- 3. The STAMINA® Outdoor Power Tower PRO should only be used after a thorough review of the Owner's Manual. Make sure that it is properly assembled and tightened before use.
- 4. We recommend that two people be available for assembly of this product.
- 5. Keep children away from the STAMINA® Outdoor Power Tower PRO. Do not allow children to use or play on the STAMINA® Outdoor Power Tower PRO. Keep children and pets away from the STAMINA® Outdoor Power Tower PRO when it is in use.
- 6. It is recommended to operate the STAMINA® Outdoor Power Tower PRO on a hard, level surface and secure with bolts or anchors. Do not position the STAMINA® Outdoor Power Tower **PRO** on loose rugs or gravel, uneven surfaces, soft lawns, wet areas or any place where the unit can shift during use.
- 7. Make sure that adequate space is available for access to and around the STAMINA® Outdoor **Power Tower PRO.**
- 8. Before using, inspect the STAMINA® Outdoor Power Tower PRO for worn or loose components, and securely tighten or replace any worn or loose components prior to use.
- 9. Consult a physician prior to commencing an exercise program and follow his/her recommendations in developing your fitness program. If at any time during exercise you feel faint, dizzy, or experience pain, stop and consult your physician.
- 10. Always choose the workout which best fits your physical strength and flexibility level. Know your limits and train within them. Always use common sense when exercising.
- 11. Do not wear loose or dangling clothing while using the STAMINA® Outdoor Power Tower PRO.
- 12. Never exercise in bare feet or socks; always wear proper footwear such as running, walking, or cross training shoes that fit well, provide foot support, and feature non-skid rubber soles.
- 13. Be careful to maintain your balance while using, mounting, dismounting, or assembling the STAMINA® Outdoor Power Tower PRO, loss of balance may result in a fall and bodily injury.
- 14. The STAMINA® Outdoor Power Tower PRO should not be used by persons weighing over 300 pounds.
- 15. The STAMINA® Outdoor Power Tower PRO should be used by only one person at a time.
- 16. The STAMINA® Outdoor Power Tower PRO is for consumer use only. It is not for use in public or semipublic facilities.

EXTEND YOUR PARTS WARRANTY TO 180 DAYS FROM THE DATE OF PURCHASE, REGISTER YOUR PRODUCT.



NEED HELP? CONTACT US FIRST 1 (800) 375-7520 customer.care@staminaproducts.com

Hi! From all of us here at Stamina Products, thank you for your purchase. We know that you have big fitness goals in mind and we are here to help you along. Call us, email us, or send us a message on Facebook. Be sure to contact us if you have any questions on your new product. We look forward to hearing from you!

> With your body in mind, Stamina Customer Care

To enact your extended warranty and to help us better serve you, please go online and register your new product.

register.staminaproducts.com

It is quick and easy to register online, but if you're a little old school or just need a reason to raise that little flag on your mailbox, fill out the info on the last page of this manual and mail it in.



ONLINE customer.care@staminaproducts.com www.staminaproducts.com











ΜΑΙΙ Stamina Products, Inc. ATTN: Customer Care 2040 N Alliance Ave Springfield, MO 65803



facebook.com/StaminaProducts facebook.com/AeroPilates

CUSTOMER CARE HOURS: Monday-Thursday, 7:30 AM-5:00 PM, Central Time Friday, 8:00 AM-3:00 PM, Central Time

BEFORE YOU BEGIN

Thank you for choosing the **STAMINA® Outdoor Power Tower PRO**. We take great pride in this quality product and hope it will provide many hours of quality exercise to make you feel better, look better, and enjoy life to its fullest.

It's a proven fact that a regular exercise program can improve your physical and mental health. Too often, our busy lifestyles limit our time and opportunity to exercise. The **STAMINA® Outdoor Power Tower PRO** provides a convenient and simple method to begin your journey of getting your body in shape and achieving a happier and healthier lifestyle.


Before reading further, please review the drawing below and familiarize yourself with the parts that are labeled. Locate the serial decal on the product and write the serial number on the cover of the manual in the space provided. See the next page for an image of the serial decal. Model number and serial number are required when calling for assistance.

Read this manual carefully before using the **STAMINA® Outdoor Power Tower PRO.**

Providing you with a quality product is Stamina's top priority. However, sometimes there could be a missing or incorrectly sized part. If you have any questions or problems with the parts included with your **STAMINA® Outdoor Power Tower PRO**, please do not return the product. Contact us FIRST!

If a part is missing or defective, please contact Customer Care for assistance. Call us toll free at 1-800-375-7520 (in the U.S.) or live chat on staminaproducts.com. Our Customer Care Staff is available to assist you from 7:30 A.M. to 5:00 P.M. (Central Time) Monday through Thursday and 8:00 A.M. to 3:00 P.M. (Central Time) on Friday.

Be sure to have the name and model number of the product available when you contact us.



THE FOLLOWING TOOL IS INCLUDED FOR ASSEMBLY:

L-type Torx Wrench

EQUIPMENT WARNING, CAUTION & NOTICE LABELS

This chart is provided to help identify the warning, caution, and notice labels on the **STAMINA® Outdoor Power Tower PRO.** Please take a moment to familiarize yourself with all of the warning, caution, and notice labels.

CAUTION LABEL(25)



For consumer use only. Failure to follow all warnings and instructions could result in injury or property damage. Before assembling or using this product, read and follow the Owner's Manual and all other warnings and instructions that accompany this product. Replace this caution label if damaged, illegible, or removed. Keep others including children & pets away from equipment when in use.

Consult your physician before starting this or any exercise program. This is especially important if you are over the age of 35 or have any pre-existing health condition. Always make sure all nuts and bolts are securely tightened before using this product. This product should not be used by person weighing more than 250 lbs. unless otherwise stated in your Owner's Manual.

CAUTION DECAL(26)

ACAUTION

Place Tower on a Hard, Level Surface and Secure with Bolts.


SERIAL DECAL(27)



To best serve you, our Customer Care Representatives will need your serial number. For quick access, write in your serial number on the cover of the manual.

HARDWARE IDENTIFICATION CHART

This chart is provided to help identify the hardware used in the assembly process. Place the washers or the ends of the bolts or screws on the circles to check for the correct diameter. Use the small scale to check the length of the bolts and screws.



NOTE: Mounting Hardware NOT included. See page 11 for more information.

Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials from your area and place them back into the box. Do not dispose of the packing materials until assembly is completed. Read each step carefully before beginning. If you are missing a part, please go to staminaproducts.com under the Customer Care section and order the part needed, e-mail us at customer.care@staminaproducts.com, or call us toll free at 1-800-375-7520 (in the U.S.). Our Customer Care Staff is available to assist you from 7:30 A.M. to 5:00 P.M. (Central Time) Monday through Thursday and 8:00 A.M. to 3:00 P.M. (Central Time) on Friday.

Some product parts are fit tested at the factory to ensure proper fit and alignment. Marks in the paint may be noticeable, but are not an indication of damage.


NOTE: DO NOT SECURELY TIGHTEN ALL BOLTS UNTIL STEP 5.

STEP 1

Refer to the illustration below. Bolt the LEFT BASE(1), RIGHT BASE(2), and CROSS BAR(3) together with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and ARC WASHERS(M10)(23).

STEP 2

Attach the LEFT and RIGHT UPRIGHTS(4, 5) to the LEFT and RIGHT BASES(1, 2) with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and ARC WASHERS(M10)(23).




STEP 3

Insert the LEFT UPPER UPRIGHT(6) onto the LEFT UPRIGHT(4). Insert the RIGHT UPPER UPRIGHT(7) onto the RIGHT UPRIGHT(5). Bolt the CROSS BAR(3) to LEFT and RIGHT UPPER UPRIGHT(6, 7) with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and ARC WASHERS(M10)(23).

STEP 4

Refer to the illustration below. Attach the LEFT and RIGHT DIP FRAMES(8, 9) to the LEFT and RIGHT BASES(1, 2) with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and ARC WASHERS(M10)(23).




STEP 5

Refer to the illustration below. Bolt the LEFT UPPER UPRIGHT(6), LEFT UPRIGHT(4), LEFT DIP FRAME(8), and SUPPORT PLATE(12) together with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and ARC WASHERS(M10)(23). Repeat on right side. SECURELY TIGHTEN ALL OF THE BOLTS FROM STEP 1 TO STEP 5.

STEP 6


Attach the LEFT PULL-UP BAR(10) to the LEFT UPPER UPRIGHT(6) with BUTTON HEAD BOLTS(M10x1.5x25mm)(22), BUTTON HEAD BOLT(M10x1.5x55mm)(21), and ARC WASHERS(M10) (23). Press the DOME ENDCAP(18) into the LEFT UPPER UPRIGHT(6) to cover the bolt. Repeat on right side.



STEP 7

Refer to the detail view and illustration below. Attach the PLYOBOX SUPPORTS(13) to the PLYOBOX PLATFORM(14) with BUTTON HEAD BOLTS(M10x1.5x25mm)(22) and WASHERS(M10)(24). Hook the PLYOBOX PLATFORM(14) onto the desired lugs on the LEFT and RIGHT UPRIGHTS(4, 5) and secure with BUTTON HEAD BOLTS(M10x1.5x100mm)(20).


NOTE: There are six lugs on the LEFT and RIGHT UPRIGHTS(4, 5) to adjust the PLYOBOX PLATFORM(17) to different heights. Make sure the BUTTON HEAD BOLT(M10x1.5x100mm) (20) is fully engaged at all times.



SET UP INSTRUCTIONS

Place the **STAMINA® Outdoor Power Tower PRO** in the area where it will be used. Refer to the illustration below. It is recommended to secure the **STAMINA® Outdoor Power Tower PRO** with bolts or anchors on a hard, level surface. Of course other fasteners could be used as well depending on the type of surface the **STAMINA® Outdoor Power Tower PRO** is being used on.

CAUTION: Locate and read the CAUTION LABEL(25) and CAUTION DECAL(26) on the STAMINA® Outdoor Power Tower PRO. Make sure that all users read the CAUTION LABEL(25) and CAUTION DECAL(26) before using the product.



NOTE: Four concrete anchors (mounting hardware not included) are needed to secure the LEFT and RIGHT BASES(1, 2) of the STAMINA® Outdoor Power Tower PRO, two on each side.

STORAGE

- 1. To store the **STAMINA® Outdoor Power Tower PRO**, simply keep it in a clean dry place.
- 2. Remove the nuts which secured the **STAMINA® Outdoor Power Tower PRO** on the ground. Use two people to lift from the **CROSS BAR(3)** which on the **LEFT** and **RIGHT BASE(1, 2)** and the **LEFT** and **RIGHT PULL-UP BARS(10, 11)** to move the **STAMINA® Outdoor Power Tower PRO**.

MAINTENANCE

The safety and integrity designed into the **STAMINA® Outdoor Power Tower PRO** can only be maintained when the **STAMINA® Outdoor Power Tower PRO** is regularly examined for damage and wear. Special attention should be given to the following:

- 1. Verify that the CAUTION LABEL(25) and CAUTION DECAL(26) are in place and easy to read. Call Stamina Products immediately at 1-800-375-7520 for a replacement CAUTION LABEL(25) or CAUTION DECAL(26) if one is missing or damaged.
- 2. It is the sole responsibility of the user/owner to ensure that regular maintenance is performed.
- 3. Verify that all nuts and bolts are present and properly tightened. Replace missing nuts and bolts. Securely tighten loose nuts and bolts.
- 4. Worn or damaged components must be replaced immediately or the **STAMINA® Outdoor Power Tower PRO** removed from service until repair is made.
- 5. Only Stamina Products supplied components should be used to maintain/repair the **STAMINA® Outdoor Power Tower PRO.**
- 6. Keep your **STAMINA® Outdoor Power Tower PRO** clean by wiping it off with an absorbent cloth after use. Periodically check tubes for water or rust and clean as needed.

CONDITIONING GUIDELINES

How you begin your exercise program depends on your physical condition. If you have been inactive for several years or are severely overweight, start slowly and increase your workout time gradually. Increase your workout intensity gradually by monitoring your heart rate while you exercise.


Remember to follow these essentials:

- Have your doctor review your training and diet programs.
- Begin your training program slowly with realistic goals that have been set by you and your physician.
- Warm up before you exercise and cool down after you work out.
- Take your pulse periodically during your workout and strive to stay within a range of 60% (lower intensity) to 90% (higher intensity) of your maximum heart rate zone. Start at the lower intensity, and build up to higher intensity as you become more aerobically fit.
- If you feel dizzy or lightheaded you should slow down or stop exercising.

Initially you may only be able to exercise within your target zone for a few minutes; however, your aerobic capacity will improve over the next six to eight weeks. It is important to pace yourself while you exercise so you don't tire too quickly.

To determine if you are working out at the correct intensity, use a heart rate monitor or use the table below. For effective aerobic exercise, your heart rate should be maintained at a level between 60% and 90% of your maximum heart rate. If just starting an exercise program, work out at the low end of your target heart rate zone. As your aerobic capacity improves, gradually increase the intensity of your workout by increasing your heart rate.

Measure your heart rate periodically during your workout by stopping the exercise but continuing to move your legs or walk around. Place two or three fingers on your wrist and take a six second heartbeat count. Multiply the results by ten to find your heart rate. For example, if your six second heartbeat count is 14, your heart rate is 140 beats per minute. A six second count is used because your heart rate will drop rapidly when you stop exercising. Adjust the intensity of your exercise until your heart rate is at the proper level.



Age	Target Heart Rate Zone (55%-90% of Maximum Heart Rate)	Average Maximum Heart Rate 100%	
20 years	110-180 beats per minute	200 beats per minute	
25 years	107-175 beats per minute	195 beats per minute	
30 years	105-171 beats per minute	190 beats per minute	
35 years	102-166 beats per minute	185 beats per minute	
40 years	99-162 beats per minute	180 beats per minute	
45 years	97-157 beats per minute	175 beats per minute	
50 years	94-153 beats per minute	170 beats per minute	
55 years	91-148 beats per minute	165 beats per minute	
60 years	88-144 beats per minute	160 beats per minute	
65 years	85-139 beats per minute	155 beats per minute	
70 years	83-135 beats per minute	150 beats per minute	

Target Heart Rate Zone Estimated by Age*


* For cardiorespiratory training benefits, the American College of Sports Medicine recommends working out within a heart rate range of 55% to 90% of maximum heart rate. To predict the maximum heart rate, the following formula was used: 220 - Age = predicted maximum heart rate

WARM-UP and COOL-DOWN


Warm-Up The purpose of warming up is to prepare your body for exercise and to minimize injuries. Warm up for two to five minutes before strength training or aerobic exercising. Perform activities that raise your heart rate and warm the working muscles. Activities may include brisk walking, jogging, jumping jacks, jump rope, and running in place.

Stretching Stretching while your muscles are warm after a proper warm-up and again after your strength or aerobic training session is very important. Muscles stretch more easily at these times because of their elevated temperature, which greatly reduces the risk of injury. Stretches should be held for 15 to 30 seconds. Do not bounce.

Suggested Stretching Exercises



Lower Body Stretch Place feet shoulder-width apart and lean forward. Keep this position for 30 seconds using the body as a natural weight to stretch the backs of the legs. DO NOT BOUNCE! When the pull on the back of the legs lessens, gradually try a lower position.



Floor Stretch

While sitting on the floor, open the legs as wide as possible. Stretch the upper body toward the knee on the right leg by using your arms to pull your chest to your thighs. Hold this stretch 10 to 30 seconds. DO NOT BOUNCE! Do this stretch 10 times. Repeat the stretch with the left leg.





Bent Torso Pulls

While sitting on the floor, have legs apart, one leg straight and one knee bent. Pull the chest down to touch the thigh on the leg that is bent, and twist at the waist. Hold this position at least 10 seconds. Repeat 10 times on each side.




Bent Over Leg Stretch

Stand with feet shoulderwidth apart and lean forward as illustrated. Using the arms, **gently** pull the upper body towards the right leg. Let the head hang down. DO NOT BOUNCE! Hold the position a minimum of 10 seconds. Repeat pulling the upper body to the left leg. Do this stretch several times slowly.

Remember to always check with your physician before starting any exercise program.


Cool-Down The purpose of cooling down is to return the body to its normal, or near normal, resting state at the end of each exercise session. A proper cool-down slowly lowers your heart rate and allows blood to return to the heart. Your cool-down should include the stretches listed above and should be completed after each strength training session.

WORKOUT GUIDE




TRICEP DIP OFF PLYO BOX

WORKOUT GUIDE



PRODUCT PARTS DRAWING

FRONT



PARTS LIST

PART#	PART NAME	QTY
1	Left Base	1
2	Right Base	1
3	Cross Bar	2
4	Left Upright	1
5	Right Upright	1
6	Left Upper Upright	1
7	Right Upper Upright	1
8	Left Dip Frame	1
9	Right Dip Frame	1
10	Left Pull-Up Bar	1
11	Right Pull-Up Bar	1
12	Support Plate	2
13	Plyobox Support	2
14	Plyobox Platform	1
15	Non-skid Pad	2
16	Support Pad	2
17	Dome Plug (ø76mm)	4
18	Dome Endcap (ø76mm)	2
19	Oval Plug (30 x 70mm)	4
20	Bolt, Button Head, Torx Socket (M10 x 1.5 x 100mm)	2
21	Bolt, Button Head, Torx Socket (M10 x 1.5 x 55mm)	2
22	Bolt, Button Head, Torx Socket (M10 x 1.5 x 25mm)	32
23	Arc Washer (M10)	30
24	Washer (M10)	4
25	Caution Label	1
26	Caution Decal	1
27	Serial Decal	1
28	L-type Torx Wrench	1
29	Manual	1

WARRANTY

Stamina Products, Inc. ("Stamina") warrants to the original purchaser that this product will be free from defects in materials and workmanship that arise under normal use, service, proper assembly and proper operation in accordance with product warnings/instructions for a period of 90 days on the parts and three years on the frame from the date of the original purchase from an authorized retailer. THIS WARRANTY SHALL NOT APPLY TO ANY PRODUCT WHICH HAS BEEN SUBJECT TO COMMERCIAL USE, ABUSE, MISUSE, ALTERATION OF ANY KIND OR TO ANY DEFECT OR CHANGE CAUSED BY IMPROPER ASSEMBLY, REPAIR, REPLACEMENT, SUBSTITUTION OR USE WITH PARTS NOT PROVIDED BY STAMINA. Commercial use includes use of product in athletic clubs, health clubs, spas, gyms, and all other public or semipublic facilities whether or not the product's use is in furtherance of a profit making enterprise, and all other use which is not for personal purposes.

To implement this limited warranty, send a written notice stating your name, date, and place of purchase and a brief description of the defect along with your receipt to Stamina Products, Inc. 2040 N Alliance Ave, Springfield, Missouri, USA, MO 65803, or email us at customer.care@staminaproducts.com, or call us at 1-800-375-7520. If the defect is covered under this limited warranty, you will be requested to return the product or part to us for free repair or replacement at our option.

NO ACTION FOR BREACH OF THIS LIMITED WARRANTY MAY BE COMMENCED MORE THAN ONE (1) YEAR AFTER THE DATE THE ALLEGED BREACH WAS OR SHOULD HAVE BEEN DISCOVERED. NO ACTION FOR BREACH OF ANY IMPLIED WARRANTY (INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) MAY BE COMMENCED MORE THAN ONE (1) YEAR AFTER DELIVERY OF THE PRODUCT TO THE PURCHASER. These warranties are not transferable. IF ANY PART OF THE PRODUCT IS NOT IN COMPLIANCE WITH THIS LIMITED WARRANTY OR ANY IMPLIED WARRANTY, THE REMEDY OF REPAIR OR REPLACEMENT IS THE EXCLUSIVE REMEDY. If any claim is made under this limited warranty or any implied warranty, Stamina reserves the right to require the product to be returned for inspection, at the purchaser's expense, to Stamina's premises in Springfield, Missouri. Return of the enclosed warranty registration card is not required for warranty coverage, but is merely a way of establishing the date and place of purchase.

Stamina SHALL NOT BE LIABLE FOR THE LOSS OF USE OF ANY PRODUCT, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS OR ANY OTHER INDIRECT, CONSEQUENTIAL, SPECIAL OR INCIDENTAL DAMAGES DUE TO BREACH OF THE ABOVE WARRANTY OR ANY IMPLIED WARRANTY.

THIS LIMITED WARRANTY IS THE ONLY EXPRESS WARRANTY. NO ORAL OR WRITTEN INFORMATION GIVEN BY STAMINA, ITS AGENTS OR EMPLOYEES, SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. This warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state. ANY OTHER RIGHT WHICH YOU MAY HAVE, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

The laws in some states affect the disclaimer or limitation of implied warranties and consequential and incidental damages. If any such law is found applicable, the foregoing disclaimers and limitations of and on implied warranties and consequential and incidental damages shall be deemed to be modified to the extent necessary to comply with applicable law.

NOTES

TO CONTACT CUSTOMER CARE

For your convenience, Stamina's customer care representatives can be reached by email at customer.care@staminaproducts. com or by phone at 1-800-375-7520 (in the U.S.). Our customer care representatives are available Monday through Thursday from 7:30 a.m. until 5:00 p.m., and Friday 8:00 a.m. until 3 p.m. Central Time.



233 TELEPHONE CUSTOMER CARE Tel: 1 (800) 375-7520





STAMINA PRODUCTS, INC. ATTN: Customer Car 2040 N Alliance Ave, Springfield, MO 65803

Would you like to recieve email information or special offers from Stamina Products? Register at contact.staminaproducts.com

TO REGISTER YOUR PRODUCT

To enact your warranty, please register your product by going to register.staminaproducts.com. Please have your product model number (printed on the cover of this owner's manual) and the serial number (printed on the black and white sticker on your product) ready.

If you don't have internet access, you can call customer care at 1-800-375-7520, or fill out and mail the product registration form below to Stamina Products, Inc.; 2040 N Alliance Ave, Springfield, MO 65803.

PRODUCT REGISTRATION FORM Stamina Products, Inc. 2040 N Alliance Ave, Springfield, MO 65803			
Model Number:	Serial Num	ber:	
Product Name:			
Place Purchased:			
Date of Purchase:	Purchase F	Price:	
First Name:	Last Name		
City:	State:	Zip Code:	
Email Address:	Phone #: ()	
Would you like to receive email information or special	offers from Stamina Products?*Ye	sNo *If yes, be sure your email address is included above.	
-fo	Detach and Mail or Fax the Form A	bove 🧳	

TO ORDER PARTS

If there are missing or damaged parts, you can go to parts.staminaproducts.com and order those parts. If you have questions, please contact customer care. Do not return the product. To order parts by mail, fill out the sheet below and fax it to 417-889-8064. The part will be mailed to your address.

	Detach and Mail or Fax the Form Below	
PARTS ORDER FORM	Stamina Products, Inc. 2040 N Alliance Ave, Springfield, MO 65803	
Mr./Ms:		
Address:		
City:		
IMPORTAN	T : We require your phone number to process the order!	
Phone #: ()		
Date of Purchase:		
Model #:		
Purchased From:		
IMPOR	RTANT: Before filling out the portion below, make sure you have the correct information Refer to the parts list to make sure you're ordering the right parts!	n.
PART #	DESCRIPTION	QUANTITY
EXAMPLE: 1	Rear Unit Assembly	1