E-Paper Driver HAT

- Based on the Raspberry Pi 40pin GPIO header, E-Paper Driver HAT is suitable for Raspberry Pi series boards and Jetson Nano.
- Leading SPI control interface for Connecting Raspberry Pi, Arduino, Nucleo, etc.
- Onboard voltage converter is compatible with the 3.3V and 5V ports of the MCU.
- Provide complete resources and manuals (including Raspberry/Jetson Nano/Arduino/STM32 demos).

Parameter

- Operating voltage: 3.3V/5V (Please make sure the power supply is consistent with the logic voltage, otherwise it can not be operated normally.)
- Communication interface: 3-wire SPI, 4-wire SPI
- Outline dimension: 65mm x 30.2mm
- Fixed hole diameter: 3.0mm
- Display Config

Resistor (Display Config)	Screen
0.47R (B)	2.13inch e-Paper (D), 2.7inch e-Paper, 2.9inch e-Paper (D)
	3.7inch e-Paper, 4.01inch e-Paper (F), 4.2inch e-Paper
	4.2inch e-Paper (B), 4.2inch e-Paper (C), 5.65inch e-Paper (F)
	5.83inch e-Paper, 5.83inch e-Paper (B), 7.3inch e-Paper (G)

7.3inch e-Paper (F), 7.5inch e-Paper, 7.5inch e-Paper (B)
1.64inch e-Paper (G), 2.36inch e-Paper (G), 3inch e-Paper (G)
4.37inch e-Paper (G)

1.54inch e-Paper, 1.54inch e-Paper(B), 2.13inch e-Paper

2.13inch e-Paper (B), 2.66inch e-Paper, 2.66inch e-Paper (B)

2.9inch e-Paper, 2.9inch e-Paper (B)

• It mainly affects the display effect. If you find that the display is abnormal, you can turn the switch to the other end.

Resources

Documentation

Schematic

Related Resources

- Waveshare e-Paper display with SPI
- Pisugar case
- For Meage2560, you can refer to this guide

e-Paper User Guides

- 1.54inch e-Paper
- <u>1.54inch e-Paper (B)</u>
- 2.13inch e-Paper
- <u>2.13inch e-Paper (B)</u>
- 2.7inch e-Paper
- 2.7inch e-Paper

3R (A)

- 2.9inch e-Paper
- 2.9inch e-Paper (B)
- 4.2inch e-Paper
- 4.2inch e-Paper (B)
- 7.5inch e-Paper
- 7.5inch e-Paper (B)

FAO

Question about Software

```
Question: The Raspberry Pi runs the python program and the following occurs?

pi@liguanghao:~/e-Paper/RaspberryPi_JetsonNano/python/examples $ python3 epd_7in
5_V2_test.py
INFO:root:epd7in5_V2 Demo
INFO:root:init and Clear
INFO:root:[Errno 2] No such file or directory
```

Answer:

- Enter the command: Is /dev/spi*
- The result may appear as shown in the figure

```
pi@raspberrypi:~ $ ls /dev/spidev*
/dev/spidev0.1 /dev/spidev1.1 /dev/spidev1.2
```

This is because the SPI interface is occupied in the /boot/config.txt file.

```
dtparam=spi=on
dtoverlay=spi1-3cs
toverlay=mcp251xfd,spi0-0,interrupt=25
dtoverlay=mcp251xfd,spi1-0,interrupt=24
```

Steps:

- Delete the occupation of spi0-0 in the /boot/config.txt file.
- Modify the location shown in the picture in the /e-Paper/RaspberryPi_JetsonNano/lib/waveshare_epd/epdcon fig.py file and change it to 0,1.

Question:stm32 drives the ink screen, the MDK compilation display space is not enough?

Answer:

*Our demo uses stm32f103zet6. If the customer modifies other models in MDK, such as stm32f103rbt6, the ram space becomes smaller, and the stack size and heap size in the startup file need to be modified on the original basis.

Question:When to transmit Data Start Transmission 1 and when to use Data Start Transmission 2?

Answer:

When transmitting B/W data, use Data Start Transmission 1; when transmitting RED data, use Data Start Transmission 2.

Question: After multiple positions are brushed, the font is lighter after brushing several times?

Answer:

In this case, the customer needs to reduce the position of the round brush and clear the screen after 5 rounds of refreshing (increasing the voltage of VCOM can improve the color, but it will increase the afterimage).

Question:e-Paper shows black border?

Answer:

The border display color can be set through the Border Waveform Control register or the VCOM AND DATA INTERVAL SETTING register.

Question: After multiple positions are brushed, the font is lighter after brushing several times?

Answer:

In this case, the customer needs to reduce the position of the game and clear the screen after 5 times of the game.

Question: When the ink screen is in deep sleep mode, there will be a problem that the screen refresh will not be clean when it wakes up for the first time. How can I solve it?

Answer:

The process of re-awakening the e-ink screen is actually the process of repowering. Therefore, when the EPD wakes up, the screen must be cleared first, so as to avoid the afterimage phenomenon to the greatest extent.

Question:When testing the program, the program has been stuck in e-Paper busy?

Answer:

*It may be caused by the unsuccessful spi driver.

- 1. First check whether the wiring is correct.
- 2. Check whether the spi is turned on and whether the parameters are configured correctly (spi baud rate, spi mode and other parameters).

Question:Why can't the image be displayed after full refreshing?

Answer:

The full refresh initialization function needs to be added when the ink screen is switched from partial refresh to full refresh.

Question:Why is the printing information normal when running a python program, but the ink screen does not respond?

Answer:

It may be a demo based on the BCM2835 library that has run the C language before. At this time, you need to restart the Raspberry Pi and then run the python demo.

Question:ImportError: No module named Image?

Answer:

*Install the imaging library using the command sudo apt-get install pythonimaging

Question about Hardware

Question:Can Arduino 5V drive the ink screen?

Answer:

Yes, now there is a level conversion chip onboard, supporting a 5V drive.

Question: What should be paid attention to when designing the driver board?

Answer:

- The rated input voltage of the ink screen is 2.3~3.6V. If it is a 5V system, level conversion is required. In addition, the voltage should not be lower than 2.5V, so as not to affect the display effect of the ink screen.
- Device selection can use the model in the schematic diagram we provide or choose according to the data sheet.

Question:Can I use analog SPI?

Answer:

Yes, pay attention to the correct timing.

Question:Why is the BUSY pin always busy?

Answer:

- Check if SPI communication is normal.
- Confirm whether the BUSY pin is normally initialized to input mode.
- It may be that there is no normal reset, try to shorten the duration of the low level during reset (because the power-off switch is added to the drive circuit, the reset low level is too long, which will cause the drive board to power off and cause the reset to fail).
- If the busy function sends the 0x71 command, you can try to comment it out.

Question: What is the specification of the screen cable interface?

Answer:

- 1.64inch, 2.36inch, 3inch, 0.5mm pitch, 26Pin.
- 1.02inch, 0.5mm pitch, 30Pin.
- 4.37inch, 7.3inch, 0.5mm pitch, 50Pin.
- The rest (non-parallel ports) are 0.5mm pitch, 24Pin.

Question: What type of connector does the ink screen use?

Answer:

Cable socket 0.5-24pin rear-flip 2.0H (FPC connector).

Question about Screen

Question: What is the usage environment of the e-ink screen?

Answer:

- [Working conditions] Temperature range: 0~50°C; Humidity range: 35%~65%RH.
- 【Storage conditions】: Temperature range: below 30°C; Humidity range: below 55%RH; Maximum storage time: 6 months.
- 【Transportation conditions】: Temperature range: -25~70°C;
 Maximum transportation time: 10 days.
- 【After unpacking】: Temperature range: 20°C±5°C; Humidity range: 50±5%RH; Maximum storage time: Assemble within 72 hours.

Question: Precautions for e-ink screen refresh?

Answer:

refresh mode

- Full refresh: The electronic ink screen will flicker several times during the refresh process (the number of flickers depends on the refresh time), and the flicker is to remove the afterimage to achieve the best display effect.
- effect during the refresh process. Users who use the partial brushing function note that after refreshing several times, a full refresh operation should be performed to remove the residual image, otherwise the residual image problem will become more and more serious, or even damage the screen (currently only some black and white e-ink screens support partial refreshing, please refer to product page description).
- refresh rate
- During use, it is recommended that customers set the refresh interval of the e-ink screen to at least 180 seconds (except for products that support the local brush function).
- During the standby process (that is, after the refresh operation), it is recommended that the customer set the eink screen to sleep mode, or power off (the power supply part of the ink screen can be disconnected with an analog switch) to reduce power consumption and prolong the life of the e-ink screen. (If some e-ink screens are powered on for a long time, the screen will be damaged beyond repair.)
- During the use of the three-color e-ink screen, it is recommended that customers update the display screen at least once every 24 hours (if the screen remains the same

screen for a long time, the screen burn will be difficult to repair).

Application

The e-ink screen is recommended for indoor use. If it is used outdoors, it is necessary to avoid direct sunlight on the e-ink screen, and at the same time, take UV protection measures, because charged particles will dry out under strong light for a long time, resulting in loss of activity and failure to refresh. This situation is irreversible. When designing e-ink screen products, customers should pay attention to determining whether the use environment meets the requirements of an e-ink screen.

Question:What is the refresh rate/lifetime of the e-ink screen?

Answer:

Ideally, with normal use, it can be refreshed 1,000,000 times (1 million times).

Question: After using for a period of time, the screen refresh (full refresh) has a serious afterimage problem that cannot be repaired?

Answer:

Power on the development board for a long time, after each refresh operation, it is recommended to set the screen to sleep mode or directly power off processing, otherwise, the screen may burn out when the screen is in a high voltage state for a long time.

Question: After the ink screen enters deep sleep mode, can it be refreshed again?

Answer:

Yes, but you need to re-initialize the electronic paper with software.

Question:Why is the image displayed offset?

Answer:

Maybe the SPI rate is too high, resulting in data loss, try to reduce the SPI rate.

Insufficient or unstable power supply leads to data loss.

The data cable is too long to cause data loss, the extension cable should not exceed 20cm.

Question: What is the waveform file of the e-ink screen and what does it do?

Answer:

The display gray scale of electrophoretic electronic paper is determined by the spatial position of the particles in the Microcapsule or Microcup. The electrophoresis phenomenon occurs between black particles and white particles under the action of voltage. This voltage sequence that promotes the electrophoretic movement of the particles is the driving force of the electronic paper. waveform. The driving waveform is the core part of the electronic paper display, and the optimization of the driving waveform will directly affect the display effect of the display. The driving waveform file is used to describe the parameters formed by the voltage sequence that promotes the electrophoretic movement of the particles, and it needs to be called regularly when the electronic paper is refreshed.

Different batches of e-paper diaphragms and electrophoretic matrices require different voltage values when driving the display due to materials, manufacturing processes, etc. The waveform of the e-ink screen is reflected in the relationship between grayscale, voltage, and temperature. Generally

speaking, after each batch of electrophoresis matrix is generated, there will be a corresponding waveform file in the form of a .wbf file. The film manufacturer will provide the waveform file and electrophoresis matrix to the manufacturer of the electronic paper screen, and then the manufacturer of the electronic paper screen integrates the protection board, substrate, and driver and then provides it to customers; if the waveform file does not correspond to the screen, it is likely that the display cannot be displayed or the display effect is unsatisfactory. Generally, the waveform file has OTP built into the driver IC of the ink screen when leaving the factory, and some programs we provide also call external waveform files to drive the e-ink screen.

Question: What do LUT and OTP stand for?

Answer:

LUT is the abbreviation of LOOK UP TABLE, and OTP is the abbreviation of ONE TIME PROGRAM. The original intention of LUT is to load waveform files, and the waveform files are divided into OTP and REGISTER. Among them, OTP is the built-in waveform storage method, and REGISTER is the external waveform storage method.

Question: What is the process of partial refreshing?

Answer:

*There are mainly two types of ink screens.

- One is to refresh the background image first.
- o The other is to alternately refresh old data and new data.

Question:How do I play in different positions at the same time?

Answer:

Simultaneous brushing in different locations needs to be operated in the program design, that is, first brushing the data of different locations into the electronic paper IC, and finally doing the Update/TurnOnDisplay uniformly.

Question: Does the three-color e-Paper have a red/yellow color difference?

Answer:

Yes, when e-Paper is batched, there will be some color difference, which is a normal phenomenon. Store the e-paper faces up to reduce the reddish/yellowishness to a certain extent.

Question: Are bare screens shipped with a film?

Answer:

with film.

Question: Does e-Paper have a built-in temperature sensor?

Answer:

At present, all screens have built-in temperature sensors, and you can also use an external LM75 temperature sensor with IIC pins.