

ARIES G2.2 *Streaming Transporter*



User's Guide



Copyright © 2008-2023 AURALIC LIMITED (AURALIC) and licensors.

All rights reserved. No part of this publication including but not limited to, graphics, text, code or interactive features, may be reproduced without the express written permission from AURALiC or its licensors. The content of this manual is provided for information use only, is subject to change without notice, and should not be construed as a commitment by AURALiC. AURALiC assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual. AURALiC, inspire the music, Lightning Streaming, Purer-Power, ORFEO and their graphic logos are trademarks or registered trademarks of AURALiC in the United States and/or other countries. AURALiC's trademarks may not be used in connection with any product or service that is not AURALiC's, in any manner that is likely to cause confusion among customers or in any manner that disparages or discredits AURALiC. All other trademarks not owned by AURALiC that appear on this site are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by AURALiC.

Welcome

Congratulations on your purchase of the AURALiC ARIES G2.2 wireless streaming transporter. Please take some time to read through this manual which provides a comprehensive, thorough overview of the products features and functions.

Our award-winning ARIES products have led the world of high-resolution streaming since their introduction in 2014 and have become the premier choice for high-performance music enthusiasts worldwide. The ARIES G2.2 is the culmination of nearly 10 years of research and development. As we continually pioneer technologies to improve our hardware designs and software platform, each product release keeps us solidly at the forefront of streaming technology. The G2.2 release of the ARIES has seen a complete hardware upgrade, including a significant increase in processing power, which will provide the ability to accommodate future streaming features and keep you on the cutting edge of technology for years to come.

Providing endless avenues for musical exploration, the ARIES G2.2 has the flexibility to connect music stored locally, or from online services. Our advanced Lightning Streaming Platform lets you take advantage of features like On-Device Playlists, Memory Caching, Gapless Playback, and Bit-Perfect Multi-Room functionality. It also offers advanced features like resampling, parametric EQ, and virtual speaker placement, essential tools to sculpt and refine your listening environment.

Based on the values of choice, natural sound, and reliability, our philosophy is a fundamental part of every product we design. To fully incorporate our philosophy into our products, we created the Lightning Streaming Platform as our unique ecosystem. This platform allows you to choose from an extensive variety of streaming services. It also provides the freedom to choose from various software options to control your music. Sonically, we engineer both our software and hardware to ensure a neutral and natural sound giving you the ability to tailor your musical taste through speaker choice and room setup. With complete control over our ecosystem, we can quickly and easily adapt to developments in music streaming technology.

Keeping your ARIES G2.2 current is easy with our over-the-air software updates. We regularly add new features and services, allowing you to relax and enjoy state-of-the-art streaming music. When connected to the internet, your ARIES G2.2 will automatically download and install new updates as we release them, ensuring you always have the latest software.

Welcome to the AURALiC community. We sincerely hope the ARIES G2.2 gives you years of listening pleasure.

Table of Contents

Welcome	2
Understanding the Technology	5
Network Requirements	6
Warranty	7
Unpacking	9
Placement and Cabling Placement Check Your AC Mains Voltage	9 .9 10 10
Front Panel1	14
Power Management	L5 15 15 15
Connect ARIES G2.2 to a Home Network	L6 16 18 21
Setup Music Library and Streaming Service	24 24 25 26
Display and Operation 2 Welcome Screen 2 Main Menu 2 Playing 2 Queue 3 Library 3 System 3 Streamer 3 Processor 3 DAC and Master Clock 3	28 28 30 31 31 32 33 33
Lightning Web Control Interface 3	35
Smart-IR Remote Control 3	37

38
40
41
42
44
45
46
47
48
49

Understanding the Technology

AURALIC streaming devices have the ability to work with different technologies and control software. The most common way to operate your new streamer is in Lightning mode. This is when you take full advantage of our Lightning Streaming Platform by controlling it with our iOS App Lightning DS or another OpenHome protocol based control software. When operating in Lightning mode, there are three fundamental elements to the system: Renderer, Server, and Controller. The Renderer is the physical device that plays the music, e.g. ARIES G2.2. The Server provides the music library. When playing files stored locally on your network, the server can be our Lightning Server or any other DLNA-based server. If you use an internet streaming service like Qobuz, Tidal, or Amazon Music, that platform acts as the server as well.

The Controller is the software you use to browse and select music. With AURALiC products, you have the freedom to choose from a number of different Controller options. When operating in Lightning mode, you can use our Lightning DS App or any OpenHome protocol based software such as BubbleUPnP or Kazoo as your controller. Operating in this mode allows the Renderer to fetch the music data directly from the Server without passing through the Controller. Since Lightning mode is an integral part of our system, it allows us to apply some advanced technologies, like our memory cache, to optimize the sound quality. This feature preloads the music data from the server into the Renderer's memory, allowing it to be played bit-perfect from the most pristine environment possible.

Your AURALiC streamer can also work in many ways other than Lightning mode. If you prefer the Roon ecosystem, the ARIES G2.2 will operate seamlessly as a certified RoonReady endpoint. It also works directly with TIDAL Connect, Spotify Connect, and provides the option of an AirPlay or Bluetooth connection. Each of these systems has its own specific operating environment, which requires us to bypass our memory cache system. Some of the other processing features available via Lightning mode may be disabled as well. Your ARIES G2.2 will sound slightly different when using these software options, but not necessarily worse. Each of these systems uses its own technology to optimize for sound quality.

Network Requirements

Our Lightning streaming technology utilizes SSDP (Simple Service Discovery Protocol), a network package that facilitates communication between Lightning DS and your streaming device. However, poorly designed routers and network switches often mishandle SSDP, causing issues. We have encountered WiFi routers that fail to broadcast SSDP messages effectively between Ethernet and WiFi connected devices or within the same WiFi network. If you are using a low-cost WiFi router provided by your ISP, it is likely to be insufficient for this task, resulting in difficulties finding the streaming device within Lightning DS or experiencing significant delays in device detection.

The ability to stream Netflix or play Pandora on your smart speaker does not necessarily guarantee that your router can handle specific multicasting (SSDP) messages without dropouts or block certain (IGMP/ICMP) data packets that AURALiC Lightning devices rely on for optimal performance. In many cases, lower-performing routers provided by your Internet Service Provider may struggle with this type of traffic due to their firmware limitations. Additionally, a weak WiFi connection can also impact the transmission of these UDP discovery data packets, even if your other data connections appear to be functioning as they should.

We recommend upgrading to a high-performance aftermarket router manufactured by reputable brands like Netgear, ASUS, or Linksys to resolve these issues and ensure the best streaming experience.

It's worth noting that some enterprise-level network routers and switches implement additional security measures that require specific configuration to enable SSDP messages, those security measures may also block IGMP/ICMP messages which are essential for your AURALIC devices to join your network properly. If you are using this type of equipment, we advise consulting an IT professional for assistance in setting up the firewall policy correctly.

Warranty

AURALiC offers a 1-Year factory limited warranty from the date of purchase as a general. For devices originally sold and used in EUC or UK, AURALiC offers a 2-Year factory limited warranty from the date of purchase.

The warranty will be extended to three years if the original owner completes the product registration within 30 days from purchase. You could either activate the device inside Lightning DS software under your AURALiC account or fill out the 'AURALiC Product Registration Form' on page 49 and send it back to support@auralic.com to finish the registration. This extended warranty is nontransferable and for the original owner only.

We recommend registering your device using Lightning DS as it provides the easiest way to complete the registration process. AURALiC values your privacy and does not collect any personal sensitive data during the registration process. To register your device, you will need to provide a valid email address, your name, and the country you are living in. For detailed instructions on how to activate and deactivate your device, please refer to the **'Device Activation and Deactivation**' on page 45.

Warranty coverage includes all parts and labor. Warranty is void if damage is due to abuse, neglect or unauthorized modifications. Costs associated with the return of this product are the sole responsibility of the owner. All repair work must be carried out by AURALiC or by an authorized AURALiC repair agency. Work done by unauthorized persons will void any and all warranty coverage.

AURALIC products are uniquely identified with a serial number (S/N) printed on the label attached under the unit. This number is required to validate your warranty. Please provide your serial number if service is required.

Before the product can be returned for service, an RMA (Return Material Authorization) number must be issued by AURALiC. Contact your dealer or AURALiC for further information. Units without an RMA number will not be accepted for service.







TO REDUCE THE RISK OF ELECTRIC SHOCK,

DO NOT REMOVE COVER.

NO USER-SERVICEABLE PARTS INSIDE.

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

IMPORTANT SAFETY INSTRUCTIONS

- All safety and operating instructions must be read before actual operation, and retained for future reference.
- This product should be connected only to the type of power source indicated on the back of the unit. If you are not sure of the type of your mains power supply, please consult your dealer or local power company.
- To completely disconnect this product from the AC mains, disconnect the power supply cord plug from the AC receptacle.
- Do not use the product near water, i.e. near a bathtub, kitchen sink, laundry tub, in a wet basement, near a swimming pool etc.
- Do not install the product near heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat. See "Placement and Cabling" on page 9.
- Do not let objects or liquids fall into the product. Do not expose the product to dripping or splashing. Do not place a vessel containing liquid on top of the product.
- Clean only with a soft, dry cloth.
- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltage. Refer all servicing to authorized service personnel. See 'Support & Contact' on page 47.

Unpacking

Please check that the following items are in the box:

- ARIES G2.2
- AC Power Cord
- Wi-Fi Antennas (2 pieces)
- User's Guide

Carefully unpack the box. If anything is missing or damaged, please notify your AURALiC dealer as soon as possible. Once you have inspected everything, return all the packing materials to the box, and store it in a safe place. You will want to retain the box and packaging as they are specially designed to protect the unit during transportation and shipping.

ONLY SHIP THIS PRODUCT IN ITS ORIGINAL PACKAGING!

Placement and Cabling

Placement

ARIES G2.2 should be placed on a solid and stable surface with good ventilation. Do not install this product near any heat source, such as a radiator or wood stove, or directly above an amplifier that creates significant heat.

Ventilation Requirement

ARIES G2.2 dissipates up to 50 Watts of power during normal operation. It should be installed in a space with at least one inch of clearance above, behind and on both sides of its enclosure to provide adequate ventilation. Avoid placing it directly above other equipment that produces heat.

Due to the distinctive foot damper design of the ARIES G2.2, it is essential to avoid placing any objects on top of the device. The springs within the chassis foot damper are

precisely calibrated according to the weight of the ARIES G2.2. Adding extra weight to the unit will compress the springs, leading to a significant impact on the damper performance and potentially compromising the sound quality. It is crucial to refrain from placing additional weight on the machine to ensure optimal performance and preserve the integrity of the sound quality.



ARIES G2.2 chassis foot damper system

Check Your AC Mains Voltage

ARIES G2.2 is shipped with its mains voltage preset for operation in the destination country. The mains voltage setting is written on the back of the unit, besides the power cord socket. There is a jumper inside the machine to set the mains voltage between 110-120V and 220-240V. If it needs to be changed, contact us to obtain additional information.

The power cord has a three-wire grounding type plug (a plug having a third pin for grounding). It will only fit into a grounded power outlet. If you are unable to insert the plug fully into the outlet, contact your dealer or AURALiC. Do not defeat the safety purpose of the grounded plug.

ARIES G2.2 MUST BE USED WITH THE CORRECT MAINS VOLTAGE AND PROPERLY EARTHED!

Fuse Specification

The fuse used inside ARIES G2.2 is one single T1A/250V (1A slow blow) with size of 5*20mm. The fuse is located inside the fuse box at the IEC AC power socket:



It is crucial to replace a fuse with the same rating when necessary. Failure to do so can lead to serious hazards, including but not limited to electric shock, fire, and explosion.

ONLY REPLACE FUSE WITH THE SAME RATING!

Cabling

The I/O ports on the rear of ARIES G2.2:



• IEC Power Socket and Main Switch

Power cable connection. Double-check the AC MAIN voltage rating directly below the power socket before connecting to your wall outlet. Please do not use heavy aftermarket power cables without proper support. Excessive cable weight may damage the power cord socket.

The toggle power switch cuts off all power to the unit when the side labeled 'O' is toggled and connects power to the unit when the side labeled 'I' is toggled. Please make sure to power off all units in your system before changing any cables. Failure to do this may result in permanent damage to your streamer and void any warranty.

ALWAYS POWER OFF ARIES G2.2 BEFORE CABLING!

• ATN1 and ATN2

These are the connections for the two Wi-Fi antennas that are included in the box with the ARIES G2.2. These antennas also provide access to the Bluetooth connection. Once the antennas are installed, you will be able to join your home wireless network. We always recommend wireless network as a preferred connection if your network infrastructures meet requirements mentioned at the beginning of this user's guide.

• LAN

This Gigabit Ethernet connection is supplied in case you would like to connect the ARIES G2.2 to a wired network.

• HDD

This USB 3.0 port is for connecting removable USB storage devices. When you connect a USB drive to this port, the internal Lightning Server will read the content on the drive and index the music files automatically. This connection provides 1.5 amps of power, allowing for a wide range of external storage options. Our platform supports drives formatted as FAT32, exFAT, NTFS, Linux Ext2/3/4, HFS+, and APFS (Apple File System).

• AES, COAX and TOS

The AES/EBU, Coaxial, and Toslink output ports are used to connect to a DAC with a matching input. These are all driven by the same Femto Clock source, but they are individually buffered so they can be used together. Select 'Digital Outputs' as the output channel inside the device menu to activate them. The maximum sampling rate supported by AES, Coaxial, and Toslink is 24bit/192kHz PCM or DSD64 (DoP).

• DAC

The USB Audio Host port features our 2nd generation galvanic isolation with improved DAC compatibility and further optimized noise isolation and jitter performance. Once connected, select your DAC's name as the output channel inside the device menu to enable it. Please refer to your DAC's specifications for the maximum sampling rate it supports.

• L-LINK

Lightning Link is the preferred connection method if you use the ARIES G2.2 with other AURALIC products that support Lightning Link. The ARIES G2.2 has two Lightning Link connections labeled VEGA and LEO. The VEGA connection is used to send the output data stream to our VEGA DAC or SIRIUS processor. The connection labeled LEO is for communication with our LEO GX.1 Reference Master Clock, which is used together with the MCK-IN clock input connection.

When using ARIES, VEGA and LEO together, please always connect your LEO directly to the VEGA in order to take full advantage of its performance.

Lightning Link uses an HDMI connector, but it is neither an HDMI port nor an I2S output. Please do not attempt to connect it to any HDMI or I2S device. Select 'Lightning Link' as the output channel inside the device menu to activate it. The maximum sampling rate supported by Lightning Link is 32Bit/384kHz PCM or DSD512.

• MCK IN

Clock signal input for AURALIC LEO Reference Master Clock. Adding LEO to your ARIES G2.2 will boost digital output performance; this however will not affect the USB output. MCK IN is not compatible with other clock product, such as a 10M reference clock.

Note: ARIES G2.2 can only work with LEO version 2.1 and above. You can check your LEO's version at its front display when powered up. Please contact AURALiC to have your LEO updated if you have an earlier one.

Front Panel

The front panel of ARIES G2.2:



• 'Power' Button

The 'Power' button controls the power status of your ARIES G2.2. Please refer to Power Management' on page 15 for detailed information.

• 'Play' Button

The 'Play' button has two functions: in 'Playing' interface, this button will play/pause the current track. When navigating menus, use this button to confirm selections.

• 'M' Button

The 'M' button has two functions: in 'Playing' interface, the 'M' button returns to the home menu. When navigating menus, this button steps backwards to the previous menu level (brief press) or exits to the Home Menu (long press).

• 'Up' and 'Down' Buttons

The 'Up' and 'Down' buttons have two functions: in 'Playing' interface, they adjust volume up and down. When navigating menus, use these buttons to highlight menu items.

• Front Panel Display

The 4-inch high-resolution true color display on the front panel gives you full access to ARIES G2.2 settings as well as displaying enriched metadata.

Power Management

ARIES G2.2 is equipped with advanced power management system which allows true on/off, low power standby and sleep mode.

Power On/Off

The AC power to your ARIES G2.2 can be controlled using the toggle switch located on the back of the device. This switch directly manages the flow of AC power to the unit. We recommend completely switching off the device using the toggle switch if you do not plan to use it for an extended period, such as during a vacation trip.

Standby

Once the toggle switch is set at 'I' position, your ARIES G2.2 will enter standby mode automatically. The standby mode uses very little power as most of the circuits inside the machine are powered off. In standby mode, your machine is off from network and will not react to any programmed IR remote control command.

To wake the machine from standby mode, press the 'Power' button briefly on the front panel. Within a few seconds, the front display will illuminate, and your ARIES G2.2 will begin the boot-up process.

Sleep

Sleep mode allows most circuits inside your ARIES G2.2 to remain powered on while staying connected to your home network. In this mode, the device will appear in Lightning DS as a device under sleep mode.

To wake the machine from sleep mode, you have multiple options. You can use Lightning DS app, utilize a programmed IR remote control, or simply press the 'Power' button briefly on the front panel.

Force Off

In the rare event that your ARIES G2.2 becomes unresponsive or fails to start, you can perform a force off operation by pressing and holding the 'Power' button for 7 seconds. This action will reset the system put the ARIES G2.2 back into standby mode. To restart the device, simply press the 'Power' button briefly once again, and it will begin the boot-up process.

Connect ARIES G2.2 to a Home Network

Connecting your ARIES G2.2 to your home network is a relatively easy process. There are three different methods you can use for setup: Lightning DS setup guide, Lightning web control interface, or device front panel control.

Before proceeding with the setup of your ARIES G2.2, it's important to ensure that ICMP (Internet Control Message Protocol) and IGMP (Internet Group Management Protocol) packets are not being blocked on your router/firewall/switch. Your ARIES G2.2 will not be able to join home network if ICMP/IGMP is disabled.

Use Lightning DS Setup Guide

Lightning DS is the control software that AURALiC created to use with its streaming devices. You can install Lightning DS on any iPad or iPhone running iOS 11 or above. Lightning DS can also be installed on any Mac computer with Apple Silicon processor.

To begin, download Lightning DS from the Apple App Store. Once it is installed and you open the App, a window will pop up with this message:



Please make sure you choose '**Allow**'. Lightning DS will not be able to connect to your ARIES G2.2 if you choose 'Don't Allow' option.

Next, you will be prompted to select your language. Once you have selected your language preference, Lightning DS will display the End User License Agreement (EULA.) Please read this agreement carefully and select 'Agree'. If you do not agree with the EULA, please return your unit to the seller immediately.

. 11 🗢 95)
and Conditions
ing terms before using your using your Lightning device, you und by the the terms and
icense Agreement
/arranty and Disclaimer
and Conditions MENT
those Lightning Device AND s and Conditions ATION
D TO FULLY
Agree RALIC RDWARE, TOGETHER WITH THE ED TO AS THE "PRODUCT").
DUR ACCEPTANCE OF THESE TING THE "Agree" BUTTON AT A GREEMENT, YOU ARE (1) T YOU ARE OVER THE AGE OF IG THAT YOU HAVE THE RIGHT D LEGALLY BIND YOURSELF OR AS APPLICABLE, AND (3) E LEGALLY BOUND BY ALL OF A GREEMENT. IF YOU DO NOT SE TERMS OR CANNOT MAKE THONS, DO NOT USE THE ELECT NOT ON ACCEPT THE IREEMENT, YOU MAY RETURN

At the welcome screen, choose 'Setup Lightning Device' option then select 'Setup New Device' to start a step-by-step setup guide. It will lead you to configure your ARIES G2.2 to join your home network.

18:44

2 95

	Setup Lightning Device Close
	Welcome to Lightning Streaming
Setup Your Lightning Streaming	
Hello and welcome! We will guide you to setup the Lightning device and music library in your home network step by step.	This guide will help you get through the setup of your Lightning streaming device in your home network and HiFi System.
Setup Lightning Device	
Add Music Library	
-01-	Add Existing Device
l Will Set Up Later	
	Setup New Device

Use Lightning Web Control Interface

All AURALiC streaming devices come with an HTML5-based hardware control interface, allowing you to configure the device to connect to your home network. To begin using the web control interface, follow these steps:

Connect the power cord to your ARIES G2.2, switch on the main power by putting toggle switch to the 'I' position, press the 'Power' button on the front panel to start up the device.

The ARIES G2.2's front display should light up after a couple of seconds and you will see an AURALIC logo on the display indicating the device is starting up. If this is a brand-new device, you will need to select the device language. Once the device has fully started, you will see the 'Welcome' screen, which displays basic information about your device:



Once you see the interface and verify that the second line displays 'Wi-Fi Hotspot: 10.5.5.1', you can proceed with joining an open WiFi network called '**AURALiC-Lightning**' on any computer or mobile device.

Please note that your computer or mobile device might issue a warning stating that the network is not password protected or lacks internet connectivity. This is perfectly normal as the Wi-Fi hotspot is temporary and intended solely for the initial device setup process.

Once connected to 'AURALiC-Lightning', open a web browser, and enter '**10.5.5.1**' into the address bar. The Lightning web control interface is now available:

••• • • <	> 0 10.5.5.1		ି + 🗅
Lightning DS	E		English
Device List	Lightning Device Name		Lightning Device Name
Streamer Setup			Room Name: The name of your Lightning Streaming
🛞 Processor Setup	Room Name ①	AURALIC 📝	device, used for both the device itself and the Lightning Server configuration running on the device.
බී Hardware Setup			Volume Control
	Volume Control		Enable Volume Control: Allows volume control of your device, via software such as Lightning DS.
	Enable Volume Control 🕕		Volume Control Type: Volume changes can be processed
	Volume Control Type 🕕	Software 🕶	Hardware volume control is generally the best option for sound quality and is recommended when available. Software volume
	Maximum Volume 🛈	100 🕜	control can be useful when connecting to external devices that only accept digital or USB input, or that have no volume control
			volume control with DSD formats the volume must be set at
	Output Delay		100.)
	Delay Time ()	Disable 🕶	<u>Maximum Volume</u> : Define a maximum volume that any control software can set for the streaming device. Use this option if you want to prevent accidental operation that may result in potential damage to your loudspeakers with excessive
	Available Input Methods ①		volume. You can select a maximum number between 10 and 100. Note: You may not be able to play DSD music if you have enabled this option while using software type volume control.
	AirPlay		Output Delay
	Bluetooth	Ō	Delay Time: Some external DACs need a little extra time to lock onto an input signal delivered at a new sampling rate (i.e., different from the previous track.) This setting instructs your
	Roon Ready		streaming device to pause briefly before playing music at a different sampling rate to let the DAC adjust. Without turning
	Spotify Connect		this setting on it's possible to miss the first few moments of a track when sampling rates change.

At the top right corner of the interface, change the language option by selecting the desired language. On the left-hand side, click on 'Hardware Setup':

••• • • • >	0	10.5.5.1	۵ به ۲ (۵ به ۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (۲ (
Lightning DS	ē		English 🛩
Processor Setup Image: Constraint of the setup Image: Constraint of the setup Image: Constraint of the setup	Power Management Sleep Dev Auto Reboot Streamer Output	ice E Off >	Power Management Sleep Device: Set streaming device in sleep mode. Auto Reboat: Schedules a daily automatic reboot of your streaming device at a user-defined time. Reboat At: The user-defined time set for the Scheduled reboot function. Streamer Output
	Output Channel ①	Digital Outputs 🕶	Output Channel: Select from signal output channels currently available for your streaming device. Analog/digital outputs and USB outputs may not be used simultaneously, as they utilize separate clocks for signal timing.
	Network Configuration	•	Network Configuration Display Settings
	Connection Status	Connect as Wireless Connect as Wired Start Wi-Fi Hotspot	Idle Status: Adjust device front panel display status when idle: Always On: Fron panel display remains on whether the device is playing music or not. Auto Off: Front panel display turns of fautomatically after a period of no activity.
	Display Settings		Auto Off Timer: Select how long the front panel display will turn off when it is set at Auto Off mode.
	Idle Status 🕕	Auto Off 🗸	Display Brightness: Adjust the brightness of your device's LED/display.
	Auto Off Timer 🕕	30 Seconds 🕶	Network Information
	Display Brightness 🕕	Level 7 🕶	Hardware Information Firmware Information
	Network Information		Setting Management

Locate the '**Network Configuration**' group and click on the blue gear icon at the right corner. From the options provided, select the desired connection type.

If you are using a wired connection, ensure that you have connected the network cable before selecting 'Connect as Wired'. If you are using a wireless connection, choose 'Connect as Wireless', and a popup window will appear within the web control interface. In the popup window, select your Wi-Fi network, then click on 'Next' to join it. If your network does not broadcast its name, choose the 'Other...' option to manually input the network information.

/ireless Configuration	
AUKALIC_101	<u>≞</u> ≈
My Guest	â 👳
My Guest	≙ ⇒
AURALIC_IoT	<u>₽</u> 🧇
AURALIC_IoT	≙ 🤤
NETGEAR81	÷ 🤤
My Guest	<u>a</u> 🗢
NETGEAR81-5G	ê 🤤
NETGEAR28	<u>₽</u> 🤤
My Guest	<u>a</u> 🗢
ther	
	Cancel Nex

After entering the network information correctly, click the **'Join'** button, and your ARIES G2.2 will attempt to connect to the selected network. During this process, the device's front display will show a loading animation.

Once your ARIES G2.2 has finished attempting to join the selected network, the 'Welcome' screen will reappear. However, the second line of the display will no longer show 'Wi-Fi Hotspot: 10.5.5.1'. Instead, it will display the name of the Wi-Fi network along with its corresponding IP address. If you have chosen a wired connection, it will display 'Wired' along with the IP address. You have now successfully configured your ARIES G2.2 to join your home network and the device is ready to use.



In the event that your ARIES G2.2 fails to connect to your selected network, it will revert to the 'Welcome' screen. However, the second line will show 'Wi-Fi Hotspot: 10.5.5.1' again. This indicates that the device was unable to join the network and has automatically returned to Wi-Fi hotspot mode.

Once you have successfully configured your ARIES G2.2 to join the network, you no longer need to use the Lightning DS device setup guide for further configuration. In the Lightning DS app, you can choose **'Setup Lightning Device'** > **'Add Existing Device'** at start up screen. Your ARIES G2.2 should appear in the list of available devices. Simply select it and start using the app.

Use Front Panel Control

You can use ARIES G2.2's front panel control to join wired or wireless network. Connect the power cord to your ARIES G2.2, switch on the main power by putting toggle switch to the 'I' position, press the 'Power' button on the front panel to start up the device.

The ARIES G2.2's front display should light up after a couple of seconds and you will see an AURALIC logo on the display indicating the device is starting up. If this is a brand-new device, you will need to select the device language. Once the device has fully started, you will see the 'Welcome' screen, which displays basic information about your device:



Press 'M' button on the front panel to enter main menu, use 'Up' or 'Down' button to select '**System'** menu, then press the 'Play' button to enter system menu:



Use 'Up' or 'Down' button to select '**Network**' menu, then press' Play' button to enter network menu. Select '**Connection Type**' and enter the menu. Choose the connection type you prefer to use and go to the next step.

If you are using a wired connection, ensure that you have connected the network cable before selecting 'Join Network'. If you are using wireless connection, ARIES G2.2 will scan and list networks that are available to join. If your network does not broadcast its name, choose the 'Other...' option to manually input the network information.

Connection Type		Wirel	ess		
	Wired	>		Other	
	Wireless	>		AURALIC_5G	• ?>
	Sack to Network			K Back to Connection Type	
Wired: Set up an Ethernet connection for your device.			Searching WiFi Network		

After you have selected 'Join Network', ARIES G2.2 will attempt to connect to the selected network. During this process, the device's front display will show a loading animation.

Once your ARIES G2.2 has finished attempting to join the selected network, the 'Welcome' screen will reappear. However, the second line of the display will no longer show 'Wi-Fi Hotspot: 10.5.5.1'. Instead, it will display the name of the WiFi network along with its corresponding IP address. If you have chosen a wired connection, it will display 'Wired' along with the IP address. You have now successfully configured your ARIES G2.2 to join your home network and the device is ready to use.



In the event that your ARIES G2.2 fails to connect to your selected network, it will revert to the 'Welcome' screen. However, the second line will show 'Wi-Fi Hotspot: 10.5.5.1' again. This indicates that the device was unable to join the network and has automatically returned to Wi-Fi hotspot mode.

Once you have successfully configured your ARIES G2.2 to join the network, you no longer need to use the Lightning DS device setup guide for further configuration. In the Lightning DS app, you can choose **'Setup Lightning Device**' > **'Add Existing Device**' at start up screen. Your ARIES G2.2 should appear in the list of available devices. Simply select it and start using the app.

Setup Music Library and Streaming Service

After you have successfully configured your ARIES G2.2 to connect to your home network, it's time to bring your music to the system. However, if you exclusively use Roon software or rely solely on TIDAL Connect, Spotify Connect, or AirPlay, you may skip this chapter.

If you have music stored locally on a computer, NAS (Network Attached Storage), USB drive or internal storage, you will need to set up a music library within Lightning DS. Your music library can be any DLNA/UPnP media server present on your network. AURALiC has developed its own integrated media server called Lightning Server, which is part of the ARIES G2.2 operating system. However, if you prefer to use a third-party media server, we recommend using Minimserver for the best compatibility.

If you use online streaming exclusively, you can skip the next two sections and jump to 'Add Streaming Service in Lightning DS' on page 26.

Setup Lightning Server

At Lightning DS start up screen, choose 'Add Music Library' option then select 'Setup New Library'.

	15:01 🕇		? 82
AURALIC	Ad	d Music Library	Close
Oops! Something is Wrong	Ac	d Music Library	
We can't find your 'Music Library'. If you have changed your network setup or have switched to a new device, please run the guide again to set it up.	We will guide you t existing DLNA serv music library.	o setup the Lightning er to Lightning DS an	Server or add d import your
Device Found: AURALiC			
Add Music Library			
-0ľ-			
Let's Try Again	Ad	ld Existing Library	
Just Start-Up			
	S	etup New Library	

Lightning DS will scan and show all available UPnP/DLNA media servers in your network. You may see several server options in the network but you will want to select the one named 'LightningServer[XXXXXX]' (XXXXXX is your device S/N). Select the correct Lightning Server then click Next.

15:02 🕇	. ? 82	15:02	•1	? 82
Add Music Library	Close	Add	Music Library	Close
We Have Found These S	ervers	AURALIC		
LightningServer[AURALIC] LightningServer[MINI]		AURALIC		
		Where Is Lightning Server can USB drive or shared n where your music is s	Your Music Stored' read music files stored retwork folder. Please I stored:	? d either on et us know
		USB Drive		~
Š ^{i∉} Scanning		Network Folder		
K Back	Next >	K Back	Ne	ext 🗲

Our setup guide will prompt you with questions and provide guidance to complete the initial setup of Lightning Server. Please note that the setup guide only allows you to add a single music library path to your Lightning Server. However, Lightning Server is capable of supporting multiple music library paths. To access these additional options, you can utilize our Lightning web control interface. For more information about the Lightning web control interface, please refer to the **'Lightning Web Control Interface'** section on page **34**.

Use Other UPnP/DLNA Media Server

If you already have a well-organized UPnP/DLNA media server, you can skip the Lightning Server and use your own media server as the music library server for Lightning DS. You can simply configure Lightning DS to connect to your existing media server and access your music library directly. This allows you to continue using your preferred media server while utilizing the features and capabilities of Lightning DS for playback and control. At Lightning DS start up screen, choose 'Add Music Library' option then select 'Add Existing Library'.

	15:01 🕇	. 1 🗢 82
AURALIC Sound of Innovation	Add Mu	sic Library Close
Oops! Something is Wrong	Add Mu	sic Library
We can't find your 'Music Library'. If you have changed your network setup or have switched to a new device, please run the guide again to set it up.	We will guide you to setu existing DLNA server to L music library.) the Lightning Server or add ightning DS and import your
Device Found: AURALiC		
Add Music Library		
-01-		
Let's Try Again	Add Exis	ting Library
Just Start-Up		ang cibrary
	Setup N	ew Library

Lightning DS will scan and show all available UPnP/DLNA media servers in your network. Select the one that you are currently using then click 'Next'. The setup guide will start creating an index of this media server on your iOS device.

Add Streaming Service in Lightning DS

If you don't have any locally stored music and intend to solely stream music online using your ARIES G2.2, you can bypass the media server setup steps. Simply select either the **'I Will Set Up Later**' or **'Just Start-Up'** option on the Lightning DS startup screen. This will allow you to proceed directly to using Lightning DS for online music streaming without setting up a media server.

To log in your streaming service account, click on the blue navigation icon at the top left of the screen. This will open the blue navigation side menu. Locate and click on the blue gear icon at the bottom left corner of the menu. This will take you to the '**Settings**' menu.



Select 'Streaming Account' option then click 'Add Streaming Account'. The streaming services that are currently being integrated inside Lightning DS will be listed here:

15:03	. 11 🗢 (82)	15:25 -		.ul 🕆 79)	15:03		. 1 🗢 82)
Settings	Close	Settings	Settings	Close	< Settings	Settings	
Lightning Device	>	Add Streaming	g Account	>	Amazon music Amazo Unlimit	zon Music n Music - any way you want it. S ed, Prime Music, or your Amazo	tream Amazon Music > in Music library.
Music Library Streaming Account	> >				HRA Stures	reaming is an commercial-free, on music streaming service in e Audio).	audiophile and high- > xclusively 24-bit
Cover View Text Alignment	>				KKBOX music li 24bit/1	OX , Asia's leading music streamin brary of over 70 million tracks t 92kHz Hi-Res audio.	g service, offers a rich 📏 hat supports up to
l [↑] Sorting	>				6 NetEas	ase e Music, offering 100 millions m Is in China.	
Disable System Auto-Lock Disable Volume Buttons					Qob Qobuz Iossiess	UZ is a French streaming service pr and high resolution streaming	roviding high quality > service, especially
C Language	>				TIDAL r 90,000	n Classical & Jazz Music. L nembers access 40 million sonj high quality videos, live stream	gs in high-fidelity, >
	>				Tune	l content and offline experience In listen to local and international 7 countries.	
(i) Version 7.7	>						
							,

If you wish to stream a service that is not currently integrated within Lightning DS, you have the option to use alternative software. For more information on how to do this, please refer to the **'Use with Other Software'** section on page **43** of the user manual.

Display and Operation

The front panel buttons, along with the 4" display, provide a convenient interface for users to complete hardware-related setup tasks and view the current playback status when the ARIES G2.2 is in use. However, for an optimal setup experience, we highly recommend accessing and configuring all settings through the **Lightning web control interface**. This web-based interface offers a more comprehensive and user-friendly way to set up your ARIES G2.2, providing access to a wider range of options and features. Please refer to page 34 for more information about Lightning web control interface.

Welcome Screen



Upon startup, the ARIES G2.2 presents the welcome screen, which provides essential information such as the device model, firmware version, current network connection type, IP address, and the output channel in use. To access the Lightning web control interface, simply type the IP address of your ARIES G2.2 into a web browser.

To exit the welcome screen and navigate to the main menu, you can press any front panel button (excluding the power button).

If you have already selected a track to play using a control software, the ARIES G2.2 will automatically transition to the 'Playing' screen, where you can view the current playback information and control the playback functions.

Main Menu



The main menu serves as the root level menu for your ARIES G2.2, offering access to eight different destinations. Here is an overview of each destination available from the main menu:

- 1. **'Playing'**: This destination displays track information, playback status, playback mode (shuffle, repeat), and volume control.
- 2. 'Queue': Here, you can view the current queue of tracks in the ARIES G2.2 and select individual tracks for playback.
- 3. **'Library'**: Browse and play music from your library, and configure the built-in Lightning Server on your ARIES G2.2.
- 4. **'System'**: Access general hardware-related settings, including network information, output channel configuration, display language, and more.
- 5. '**Streamer**': Configure settings specific to the streaming software on your ARIES G2.2.
- 6. '**Processor**': Adjust settings for the ARIES G2.2 processor. Note that if an external processor, such as SIRIUS, is connected via Lightning Link, the ARIES G2.2 processor is disabled, and the options presented here apply to the external processor.
- 7. '**DAC**': View and modify settings for any Lightning Link-connected DAC, such as VEGA G2.2 (if applicable).
- 8. 'Master Clock': Access settings for any Lightning Link-connected Master Clock, such as the LEO GX.1 (if applicable).

To navigate the main menu, use the 'Up' and 'Down' buttons to highlight a destination, and press the 'Play' button to select it. To return to the welcome screen, press the 'M' button.

Playing



On the 'Playing' screen, you will find information related to the current playback, including playback status, track progress, playback mode, volume control, and metadata for the currently playing track. You can also utilize the front panel buttons for specific functions:

- 1. 'Play' button: Press this button to play or pause the current track.
- 2. 'M' button: Use this button to return to the main menu from the 'Playing' screen.
- 3. 'Up' and 'Down' buttons: Adjust the volume by pressing the 'Up' button to increase the volume and the 'Down' button to decrease the volume.

Queue

()	Oh, Good Grief	2:24
2	Pebble Beach	2:51
3	Happiness Is	3:43
4	Schroeder	1:54
5	Charlie Brown Theme	4:24
6	Linus & Lucy	3:07
7	Blue Charlie Brown	7:29
8	Baseball Theme	3:17

The 'Queue' menu displays the playback queue that is currently stored in the device's memory. You can interact with the 'Queue' menu using the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to navigate and highlight a specific track in the queue.
- 2. 'Play' button: Press the 'Play' button to start playback of the selected track in the queue.
- 3. 'M' button: This button allows you to return to the main menu.

Library

Libra	ary	
	Browse Library	>
	Library Setup	>
	K Back to Menu	
Browse Library: Browse and play music from		
Lighting of ver a notary.		

The 'Library' menu on your ARIES G2.2 provides options to set up the Lightning Server and browse the music library created by the server. When on the 'Library' menu, you can utilize the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to highlight different menu items within the 'Library' menu.
- 2. 'Play' button: Press the 'Play' button to select the highlighted menu item.
- 3. 'M' button: This button allows you to exit to the previous level of setting menu. You can press and hold the 'M' button and return to the main menu directly.

System

Syste	em		
	Network	Wi-Fi Hotspot : 10.5.5.1	>
	Output Channel	Digital Outputs	>
	Display Settings		>
	Smart-IR Settings		>
Network: Set up your device's network connection.	Hardware Informatio	n	>
	Language	English	>
	Erase All User Settin	gs	
	🕻 Back to Menu		

The 'System' menu in Lightning DS encompasses general hardware-related settings for your ARIES G2.2. When navigating the 'System' menu, you can employ the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to highlight different menu items within the 'System' menu.
- 2. 'Play' button: Press the 'Play' button to select the highlighted menu item.
- 3. 'M' button: This button allows you to exit to the previous level of setting menu. You can press and hold the 'M' button and return to the main menu directly.

Streamer

Stream	ner	
	Lightning Device Name	
	Room Name	W092A6FC >
	Available Input Methods	
Room Name: The name of your Lightning Streaming	AirPlay	0n 🗲
device used for both the device itself and the	RoonReady	On 🗲
Lightning Server configuration running on the device.		
	🕻 Back to Menu	

The 'Streamer' menu contains all streaming and rendering related setup options. When navigating the 'System' menu, you can employ the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to highlight different menu items within the 'System' menu.
- 2. 'Play' button: Press the 'Play' button to select the highlighted menu item.
- 3. 'M' button: This button allows you to exit to the previous level of setting menu. You can press and hold the 'M' button and return to the main menu directly.

Processor

Processor			
	Resampler Configuration		
<u>PCM Auto-Detect</u> : When this feature is enabled your AURAL IC streaming device automatically detects	PCM Auto Detect	On	>
the maximum sampling rate supported by USB-	Convert DSD to PCM	Off	>
connected DACs and ensures compatibility by resampling the signal only when it is more than the	DoP Marker	0x05/FA	>
DAC can handle. For example when playing 384 kHz music with a DAC that supports a 384 kHz sampling rate the signal is delivered to the DAC unchanged. However if your DAC can only support rates up 192 kHz your AURALiC device would resample that 384 kHz music to 176.4 kHz. The result is a signal that's always compatible with your DAC and the best 88.2KHz	Filter Mode		>
	44.1KHz	44.1KHz	>
	48KHz	48KHz	>
	88.2KHz	88.2KHz	>
sound quality possible from your system.	96KHz	96KHz	>
	176.4KHz	176.4KHz	>
	~		

The 'Processor' menu displays all available DSP (Digital Signal Processing) plug-in options. If you have connected an external processor, such as the SIRIUS, via Lightning Link, the software processor inside ARIES G2.2 will be disabled, and the options shown in the 'Processor' menu will apply to the external processor.

To navigate within the 'Processor' menu, you can use the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to highlight different menu items within the 'Processor' menu.
- 2. 'Play' button: Press the 'Play' button to select the highlighted menu item.
- 3. 'M' button: This button allows you to exit to the previous level of setting menu. You can press and hold the 'M' button and return to the main menu directly.

DAC and Master Clock

The 'DAC' and 'Master Clock' menu will light up and accessible when a VEGA and LEO is connecting to ARIES G2.2 via Lightning Link corresponding. You will be able to access to the DAC and clock's setting through these two menus.

To navigate within the 'DAC' and 'Master Clock' menu, you can use the following front panel buttons:

- 1. 'Up' and 'Down' buttons: Use these buttons to highlight different menu items within the 'DAC' and 'Master Clock' menu.
- 2. 'Play' button: Press the 'Play' button to select the highlighted menu item.
- 3. 'M' button: This button allows you to exit to the previous level of setting menu. You can press and hold the 'M' button and return to the main menu directly.

While the front panel buttons provide access to the settings of your ARIES G2.2, it's worth noting that you can easily access and configure all the settings through the Lightning web control interface. The web interface offers a more comprehensive and user-friendly way to manage the Lightning Server and access your music library.

Lightning Web Control Interface

The Lightning web control interface provides a user-friendly way to access and configure hardware settings for AURALiC streaming devices. You can access the web interface using any laptop, tablet, or desktop computer with a compatible web browser. Follow these steps to access the Lightning Web Interface:

- 1. On the welcome screen of your AURALiC streaming device, note the device's IP address displayed.
- 2. Open a compatible web browser such as Google Chrome or Safari on your laptop, smartphone, or desktop computer.
- 3. Enter the IP address of your AURALiC streaming device, as shown on the welcome screen, into the address bar of the web browser.

É Chrome File Edit	View History Bookmarks People Window Help	۵ 🗘	: 🚓 📙 🎭 👜 奈 🖵 100% 📾 💻 Wed 5:31 PM 🛛 Xuanqian Wang 🔍 😑
🔍 🔍 🔽 Lightning DS 19	22.168.0.113 ×		≞
\leftarrow \rightarrow C (3) 192.168.0.1			
🔁 Lightning DS	Ξ		English 🛩
Device List			
	Lightning Server Information		Lightning Server Information
Streamer Setup	Status ①	Ready	Status: Reflects the current working status of the Lightning Server system. Scanning progress and any potential scanning errors are displayed.
A DAC Setup	Library Paths ()	0	Library Paths: The total number of user-defined music storage locations recognized by Lightning Server. Includes attached USB drives, network shared folders and internal
② Hardware Setup	Library Capacity 🕕	OM	storage.
	Total Tracks ①	0	Library Capacity: Combined disk space of all user-defined music storage locations.
		2017 10 14 10 24 57	files and files not recognized or supported by Lightning Server are not included.
		2017-10-14 10:34:57	Last Re-scan: Date & time of the last library scan performed by Lightning Server.
	Re-scan All Paths	=	Re-scan All Paths: Re-scans all user-defined library file locations for changes.
			Library Path Information
	Library Path Information	0	Lightning Server Configuration
			Always On: When enabled, this feature keeps Lightning Server running as a
			on if you use the Scheduled Re-Scan feature, or if you use Lightning Server to stream
	Lightning Server Configuration		content to other devices on your home network. Note: when this feature is enabled, internal and or attached USB storage drives remain active and accessible to Lightning
	Always On (1)		Server.
			Scheduled Re-scan
	Scheduled Re-scan	Off >	Scheduled Re-scan: Turns on automatic, daily re-scanning of all music storage locations at a user-defined time.
	Ignore Prefix for Album	Off >	Re-scan At: The user-defined time set for the Scheduled Re-scan function.
	Ignore Prefix for Artist	Off >	Ignore Prefix for Album
			Ignore Prefix for Album: When enabled, this setting ignores specific words in album titles during library scans. Changing this setting promote an immediate re-scan of
	Ignore Prefix for Track	Off >	your library.
	Smart Album Title 🕕		Prefix List of Album Title: The user-defined words that will be ignored in album names. Designating words to ignore is case-sensitive, and multiple words should be
	Group Multi-Disc Album 🕕		separated by spaces. A list consisting of 'The the' for example prompts Lightning Server to ignore both the word 'The' and the word 'the'.
	CUE File Encoding ()	Chinese Simplified (GB18030) +	Ignore Prefix for Artist

4. Press Enter or Go to load the Lightning Web Interface.

The Lightning web control interface consists of three sections:

- 1. Navigation menu on the left: This menu provides navigation options to access different sections and settings within the interface. It allows you to easily switch between different setup options and features.
- 2. Main setup options in the middle: The central section of the interface displays the main setup options and configuration settings for your AURALiC streaming

device. This is where you can make adjustments and customize various aspects of your device's functionality, network settings, streaming options, and more.

3. Setup guide on the right: The right section of the interface provides a setup guide or additional information to assist you in configuring your AURALiC streaming device. It may offer step-by-step instructions, tips, and explanations for specific settings or features.

With these three sections in the Lightning web control interface, you have easy access to navigate through the different menus, configure the setup options, and refer to the setup guide for assistance or additional information as needed.

Smart-IR Remote Control

Our Smart-IR feature is an intuitive way to eliminate the clutter of an additional remote in your listening room. This easily programmable feature allows you to control the operation of your AURALIC product with a remote that you already have. Our system is basically the reverse of a learning remote. With Smart-IR, you choose a function on the ARIES G2.2 you would like to access via the remote control, and then by pressing any button on the remote, teach your ARIES G2.2 to respond to that specific IR code.

To explain this advanced technology, we have created a step-by-step video guide helping you understand and use this feature. Please scan the QR Code below to view the video:



https://us.auralic.com/pages/auralic-smart-ir-feature

If you do not have a remote for your ARIES G2.2 and would like to use one, AURALIC offers a generic remote that are compatible with ARIES G2.2. You can order this remote by contacting your local AURALIC dealer, distributor, or reaching out to AURALIC directly.

Lightning DS

Lightning DS is an iOS-based software designed to provide a comprehensive and intuitive user interface for controlling and managing AURALiC's streaming devices, including ARIES, VEGA and ALTAIR family products. With Lightning DS, users can access and organize their digital music libraries, stream music from various sources, such as local storage, online streaming services, or internet radio, and control playback on AURALiC devices.

Lightning DS offers features like playlist and user collection management, search functionality, and extensive metadata support, making it easy to navigate and find desired music. The software also integrates with popular streaming services like Tidal, Qobuz, Amazon Music Unlimited, enabling seamless access to their vast libraries. Additionally, Lightning DS supports multi-room audio, allowing synchronized playback across multiple AURALiC devices in different rooms.

Main Interface

The following introduction is based on the interface displayed on a tablet screen. The interface may appear slightly different on a mobile device, but the essential elements remain the same. When Lightning DS is launched, you will encounter the following interface:



Aside from the obvious library content showing in the middle of the screen, the Lightning DS interface includes several key elements. Here is a description of each element:

- **Device List**: The currently selected streaming device name is displayed in the middle of the top navigation bar. Clicking on the device name will open the device list window, allowing you to select a different streaming device if available.
- **Navigation Button**: At the main interface level, this button activates the side menu. You can use the side menu to switch between different content sections. When browsing your music library, the navigation button transforms into a **back button**. Briefly pressing the back button will return you to the previous interface, while holding the back button opens the side menu.
- Search Button: Clicking on the search button opens the search bar, where you can search for music among your local library and online streaming sources. This feature helps you quickly find specific tracks, albums, or artists.
- **Playback Control**: This section displays the current playing music. It includes transport controls for previous track, play/pause, next track, and volume control. Additionally, it shows the queue list, allowing you to manage the playback order. Clicking anywhere in this section will open the full 'Queue' interface, providing a detailed view of the current playback queue.

Album Information

You can tap the small 'Play' bottom at the left bottom corner of the album cover to instantly play selected album or tap the album cover to enter album information:



The Album Information interface provides comprehensive details about a specific album. Here are the key elements to mention:

- Artist Page Link: If available, the artist name will be displayed in blue color, indicating that an individual page about the artist is accessible. Clicking on the artist name will redirect you to the artist page, where you can find more information about the artist and their other works.
- Album Operations: This section contains four icons that allow you to perform operations at the album level. For example, clicking the heart icon indicates that you want to add the album to your collection or favorites.
- **Track Operations**: Each individual track within the album can be tapped to perform specific operations. Tapping a track adds the entire album to your device's queue and starts playing the selected track. Additionally, tapping the '...' icon provides access to additional track-related operations.
- **Back Button**: Tapping the back button briefly will take you back to the previous interface, allowing you to navigate through your music library seamlessly. Pressing and holding the back button opens the side menu, providing quick access to various sections and settings within Lightning DS.

Playback Control

At the bottom of the main interface, you will find the playback control section, which provides quick access to essential transport-related control functions. Here are the key elements to mention:



• **Previous, Play/Pause, Next Buttons**: These three buttons in the middle of the playback control section are the primary track control buttons. It's worth noting that if you click the previous button after the playback progress has exceeded 5 seconds, Lightning DS will jump to the beginning of the current track and play from there. If the playback progress is less than 5 seconds, it will jump to the previous track in the device's playback queue.

- **Playback Progress Bar**: The small blue line represents the approximate percentage of the track currently being played. You can press and drag the marker on the progress bar to seek to a specific position within the track.
- **Currently Play**: This area displays metadata information about the track that is currently playing. You can tap on this area to open the 'Queue' interface and get more details about the current playback.
- **'Mute' Button and Volume control**: This area allows you to adjust the volume level and quickly mute or unmute your device's audio output.
- **Queue List**: Tapping this icon will open a small pop-up window that displays the tracks currently stored in the device's queue. This allows you to view and manage the playback order, add or remove tracks, and make changes to the queue as desired.

Queue Interface

In the queue interface, you have full control over playback-related operations and access to some hardware control functions. Here are some key points to remember:



Final Rate and Filter Select

Queue Items

- Original Rate: The original rate section displays information about the source of the music, including the sampling rate, bit depth, file bitrate, and format details. This information is displayed briefly and can be accessed again by tapping the album cover. It provides valuable insight into the quality and characteristics of the music being played.
- More Options: Tapping the '...' icon on the album cover opens a small pop-up

window that offers additional options. You can access more information about the track, add it to your collection or a playlist, or jump to the album to which the track belongs. This feature is particularly useful when streaming music from online service providers.

- **Processor Control**: If available, individual processor function icons will be displayed in this section. You can click on these icons to access their settings or enable/disable the corresponding functions. This allows you to customize and optimize the audio processing according to your preferences.
- **Final Rate and Filter Select**: The final output sampling rate, bit depth, and bitrate are shown in this section. These values represent the data streaming directly to the output circuit of the device, such as DAC. If this section is displayed in blue color, it indicates the availability of a filter selection option. You can click on it to view and change the filter settings, tailoring the audio output to your desired characteristics.

Side Menu

The side menu in Lightning DS provides convenient navigation and allows you to switch between different features and sections of the app.



- **My Account**: This option allows you to register an AURALiC account and manage the streaming devices you have purchased. Refer to the 'Device Activation and Deactivation' section for detailed information.
- Input: The input menu enables you to switch between different physical and virtual input channels of your device. For virtual input channels like Lightning, Radio, AirPlay, and others, the switching is automatic without the need for manual operation.
- **Collection and Playlist**: This section contains your favorite tracks and customized playlists that are stored on your specific iOS device. If you want to transfer this data to different devices, you can use the **'iCloud Backup'** function in the Settings menu.
- **My Music**: This option displays the music library stored locally on your selected media server. You can browse and access your music collection from this menu.
- **CD Audio**: If you have selected the current machine's Lightning Server as the music library and have a USB CD drive connected to the back of your ARIES G2.2 with an audio CD inside, this option will appear. You can use this menu to play

Ay Account
 My Account
 Input
 Collection
 Playlists
 My Musice
 CD Audio
 CD Audio
 Radio
 Qobuz
 Settings

CD audio.

- Radio: This option allows you to access the internet radio function. The internet radio service is provided by vTuner, and you may also have the option to use TuneIn as a radio service provider. To use TuneIn, you will need to register or log in through the Streaming Account menu.
- **Qobuz/TIDAL/etc**: After successfully logging in to a streaming account within Lightning DS, the individual service name (e.g., Qobuz, TIDAL) will appear under the side menu. You can navigate and browse the library of the specific service provider from this menu.
- **Settings**: Access to all Lightning DS and hardware related user settings.

Useful Tip: To quickly activate the side menu in Lightning DS without having to click the back button multiple times to navigate to the main level, you can simply press and hold the back button. This action will immediately activate the side menu, allowing you to access its options and navigate to different features or sections of the app. It's a convenient shortcut that saves you time and makes it easier to switch between different parts of Lightning DS's interface.

Use with Other Software

While Lightning DS is the recommended software for operating your ARIES G2.2, you have several other options available for controlling and streaming with the device. Here are some additional software and ecosystems that are compatible with the ARIES G2.2:

- 1. **OpenHome Software**: ARIES G2.2 is fully compatible with any control software that supports the OpenHome protocol, such as BubbleUPnP, BubbleDS, and Linn Kazoo. These applications allow you to control and stream music to your ARIES G2.2 in Lightning mode as well.
- 2. **Roon**: ARIES G2.2 works as a Roon Ready endpoint, allowing you to integrate it seamlessly with the Roon software ecosystem. This enables you to control and stream music to your ARIES G2.2 directly from the Roon interface.
- 3. **TIDAL Connect, Spotify Connect**: The ARIES G2.2 supports TIDAL Connect, Spotify Connect. With these features, you can easily stream music from TIDAL, Spotify, or compatible devices directly to your ARIES G2.2 without the need for Lightning DS.
- 4. **AirPlay**. ARIES G2.2 is fully compatible with Apple AirPlay 2 protocol. You can stream music from services like Apple Music and Deezer by using the official music software on your iOS device or Mac computer and sending the audio signal to your ARIES G2.2 via an AirPlay connection.

Although no additional setup or input switching is required for these functionalities, please ensure that the corresponding option under 'Available Input Methods' is enabled in your ARIES G2.2 settings if you intend to use any of these features. This allows seamless integration and automatic connection with the respective software or ecosystem you choose to utilize.

Device Activation and Deactivation

Activating your AURALIC product is a straightforward process that extends the basic factory warranty and makes hardware logging available for troubleshooting. The activation process is optional; forgoing it will not affect device function or performance. Please scan the QR Code below to view our step-by-step video:



https://us.auralic.com/pages/activate-and-deactivate-your-auralic-streamer

If you have purchased a used product and it's still registered to the previous owner, you have a couple of options. Your first step should be to contact the person you purchased the unit from and ask them to deactivate it remotely. This can be done by the previous owner using Lightning DS installed on any IOS device they may have.

Once they have started Lightning DS they can choose the option of "I Will Set Up Later", or "Just Start-Up" if the app was previously configured. The previous owner now needs to log into their AURALiC account and deactivate the product. This process can also be done without the unit connected.

If the previous owner refuses to help or cannot deactivate the unit, you should arrange for a refund and return the unit immediately, as the device may not be authentic. If you purchased your AURALiC product second-hand from a dealer, you should contact them for help deactivating the unit. AURALiC will not directly deactivate a device upon request by a new owner for legal reasons.

Cleaning

To maintain the cleanliness of the enclosure, it is recommended to follow these cleaning instructions:

- 1. Use a soft, dry cloth: Regularly wipe the enclosure with a soft, dry cloth to remove dust and smudges. This helps to keep the surface clean and free from debris.
- 2. Dish soap and magic eraser: If the enclosure is heavily soiled or dirty, you can use a mild dish soap along with white-colored 'magic eraser' sponges. Dampen the sponge with water, apply a small amount of dish soap, and gently rub the surface of the enclosure.
- 3. Dry with a microfiber cloth: Use a clean microfiber cloth that has been slightly dampened with water to gently dry the surface. Microfiber cloths are gentle and effective in absorbing moisture without leaving lint or scratches on the surface.

Remember to avoid using harsh chemicals, abrasive materials, or excessive moisture on the enclosure, as these can potentially damage the finish or electronic components. By following these cleaning guidelines, you can keep your ARIES G2.2 enclosure looking clean and well-maintained.

Support & Contact

For support or service inquiries related to your ARIES G2.2, it is recommended to first contact the <u>dealer</u> or <u>distributor</u> from whom you purchased the device. They have a better understanding of your system and can provide personalized assistance.

If you have general questions about using your ARIES G2.2 or Lightning DS software, there are two valuable online resources available:

- Community Forum: The AURALiC community forum is a friendly and experienced online community where you can find discussions on a wide range of topics. It welcomes new members and offers a wealth of knowledge and support. You can access the forum at <u>community.auralic.com</u>.
- Knowledge Center: AURALIC's extensive knowledge center is another valuable resource for information and assistance. It provides detailed guides, tutorials, and troubleshooting tips. You can access the knowledge center at <u>support.auralic.com</u>.

If your ARIES G2.2 experiences any issues, it is important to contact your dealer or AURALiC for assistance. Attempting to repair or service the device yourself or engaging unauthorized personnel may void the warranty. To initiate a service request, an RMA (Return Material Authorization) number must be issued by AURALiC. You can contact your dealer or AURALiC for further information on the service process.

If your ARIES G2.2 is out of warranty and you possess the necessary skills to service the device, AURALiC can provide you with the required information and service parts to assist you.

For additional help or service requests related to your ARIES G2.2, you can contact AURALIC's technical support department at <u>support@auralic.com</u>.

When you contact our support department, please make sure to include the S/N of your product and write your question in English.

Specifications

Streaming File Formats	Lossless: AIFF, ALAC, APE, DIFF, DSF, FLAC, OGG, WAV and WV Lossy: AAC, MP3 and WMA	
Sampling Rates	PCM: 44.1kHz to 384kHz in 16,24 and 32Bit* DSD: DSD64 to DSD512**	
Streaming Platform	AURALiC Tesla G3 with 64bit quad-core processor 4GB system memory, 16GB data storage	
Streaming Inputs	 Network shared folder USB removable drive Optional Internal music storage*** CD Audio playback and ripping UPnP/DLNA media server TIDAL, Qobuz, Amazon Music Unlimited, HRA, KKBOX vTuner and TuneIn Radio Spotify Connect, TIDAL Connect AirPlay, Bluetooth Roon Ready 	
Audio Outputs	AURALIC Lightning Link Digital Outputs: AES/EBU, Coaxial, Toslink USB Output: USB Host to compatible DAC ****	
Network	Wired : Gigabit Ethernet Wireless : 802.11b/g/n/ac Tri-Band Wi-Fi	
Power Consumption	Standby: <0.5W Sleep: <10W Playback: 50W at max.	
Dimensions - W x D x H	13.4 x 12.6 x 3.2 in. (34cm x 32cm x 9.6cm)	
Weight	22.5 lbs. (10.2kg)	
Product Finishing	Anodized aluminum case in matte black with copper EMI shielding enclosure.	

*352.8KS/s and 384KS/s and 32bit are supported through Lightning Link and USB Output only

** By 'DoP V1.1' or native DSD protocol

*** With internal NVME storage option

**** 'Compatible DAC' means a DAC not requiring a driver for Linux systems

All specifications are subject to change without notice.

AURALIC Product Registration Form

Owner Information		
Your Name		
Address		
City		
Zip Code		
Country		
Email		
Telephone		
	Product Information	
Product Name		
Serial Number		
Dealer Name		
Purchase Date		
Purchase Price		