	PN: UL-LED-TSVLXX-XXXX	WARNINGS:
ULTRALUX® LIGHTING	Thank you for purchasing ULTRALUX® LIGHTING Fixtures!	Turn power off before installation, inspection, or removal. Use all necessary precautions while performing this procedure.
	TROUBLESHOOTING: • Check that line voltage at fixture is correct. • Ensure that there is voltage at lamp fixture wires. If there is no voltage, then check all connections. • Check that fixture is grounded properly. If fixture does not light:	Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.
		Properly ground electrical enclosure. IT IS IMPERATIVE THAT THE JUNCTION BOX BE PROPERLY GROUNDED.
	Check switch to ensure that there are no defects.     Check fuse/circuit breaker for trips, then check wiring connections.	DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS, OTHERWISE SAFETY WILL BE COMPROMISED.
	CLEANING AND MAINTENANCE: WARNING: Always be certain that electric current is turned off before cleaning.	This Integrated LED Fixture has no lamp/bulb to replace.
	<ul> <li>Only a soft damp cloth should be used. Harsh cleaning products may damage the finish.</li> <li>CAUTION: Ensure fixture temperature is cool enough to touch.</li> <li>DO NOT clean or perform maintenance while fixture is energized.</li> <li>Clean lens and Suite with non-abrasive cleaning solution.</li> <li>Do not open fixture to clean LED. Do not touch the LED.</li> <li>Do not spray liquid directly on to LED, LED driver or wiring.</li> <li>Please read carefully before installing fixture.</li> </ul>	Do not remove or touch the inside of plastic lens covering the LED board.
ULTRALUX® LIGHTING Transitional Vanity Light Wall Sconce		<b>GENERAL:</b> All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, contact and obtain the services of a qualified electrician. Use UL or IEC approved wire only for input/output connections.
INSTALLATION INSTRUCTIONS	Save these instructions, as you may need them at a later date.	Remove fixture and mounting components from the box, and make sure that no parts are missing by referencing the illustration in the installation instructions.
1-800-316-2532 www.ultraluxled.com	Please follow the following steps for installation.	DIMMING: This product is compatible with most common residential type dimmers. Dimming performance will depend upon dimmer, dimmer settings (dimmers with adjustments to brightness range), wiring method, and number of LED modules. For best results, set dimmer position at maximum before adjusting to a lower light level.
Figure 1 $\boxed{1}$ $\frac{2}{2}$ 3		1 SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
12       1.       JUNCTION BOX (NOT INCLUDED)         2.       MOUNTING BRACKET         3.       LOCKUP KNOBS         4.       MOUNTING SCREWS (x2)         5.       MOUNTING SCREWS (x2)         5.       WHITE SUPPLY WIRE         6.       BLACK SUPPLY WIRE         7.       SUPPLY GROUND WIRE         8.       WHITE FIXTURE WIRE         9.       BLACK FIXTURE WIRE         10.       FIXTURE GROUND WIRE         11.       WIRE ORDENTIFED         WHE SUPPY WIRE       11.         WIRE NUT (x3)       12.         FIXTURE BODY		2 Remove contents from box. Ensure that no parts are missing. Reference the illustration included with this instruction manual.
		<b>3</b> Pull the SUPPLY WIRES (5 & 6) and the SUPPLY GROUND WIRE (7), out from the JUNCTION BOX (1).
		<ul> <li>*NOTE: MOUNTING BRACKET (2) comes assembled in fixture, for easy install remove from inside FIXTURE BODY (12) and follow Fig.1 illustration.</li> <li>Place the MOUNTING BRACKET (2) over the JUNCTION BOX (1) and align the slots of the bracket with the screw holes in the junction box. Slide the MOUNTING SCREWS (4) through the holes of the MOUNTING BRACKT (2) and thread into the appropriate holes of the JUNCTION BOX (1). Then, fasten MOUNTING SCREWS (4) tightly.</li> </ul>
BLACK SUPPLY WRE BARE, OR GREEN GROUND WRE FRCM SUPPLY BARE, OR GREEN GROUND WRE BARE, OR GREEN GROUND WRE BARE, OR GREEN GROUND WRE GROUND WRE	13. THREADED LOCKUP KNOBS 14. GLASS GLOBE 15. ST 19 BULB	5 Make the following wire connections (Fig.2) using WIRE NUTS (11): WHITE (NEUTRAL/COMMON) SUPPLY WIRE (5) TO WHITE FIXTURE WIRE (8) BLACK (LINE) SUPPLY WIRE (6) TO BLACK FIXTURE WIRE (9) SUPPLY GROUND WIRE (7) TO FIXTURE GROUND WIRE (10) *If necessary, wrap all wire connections in electrical tape to ensure a secure connection.
6 Carefully tuck all wiring back into the JUNCTION BOX (1).		5-YEAR LIMITED WARRANTY
7 Align the screw holes of the FIXTURE BODY (12) to the attached screws on the MOUNTING BRACKET (2).		LIMITED WARRANTY: This fixture is warranted to be free from defects in workmanship and material for up to 5-years. Based upon reasonable household usage, when used in accordance with package and included instructions. If this fixture does not last for the time period guaranteed, manufacturer will send you a replacement fixture upon receipt of the returned fixture, register receipt, and proof of purchase. To contact us, please email us at returns@ultraluxled.com or call us at 1-800-316-2532 to find out how to return the fixture. We are committed to making high quality products. Returning the fixture will help us monitor and further improve product quality. This replacement is the sole remedy available, and LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IS HEREBY EXPRESSLY EXCLUDED.
8 Attach the FIXTURE BODY (12) to the MOUNTING BRACKET (2) by feeding the attached screws through the holes of the FIXTURE BODY (12). Then, fasten LOCKUP KNOBS (3) tightly.		
9 Install provided ST19 BULB (15) and secure in socket. Then, loosen the THREADED LOCKUP KNOBS (13) enough to slide the GLASS GLOBE (14) over ST19 BULB (15) and fasten THREADED LOCKUP KNOBS (13) tightly.		This device complies with Part 15 of the FCC Rules and has been tested and found to comply with the limits for Class B digital device. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by manufacturer could void user's authority to operate the equipment.
<b>10</b> Restore power at fuse box/circuit breaker. Check operation of Integrated LED Fixture.		Toll Free: 1-800-316-2532U L T R A L U X®www.ultraluxled.comLIGHTING
11 Installation complete.		© 2021 ULTRALUX <sup>®</sup> LIGHTING is a registered trademark of Superior Ventures LLC. All rights reserved.