BERNINI™

THE MATERA MODULAR 4-IN-1 FOUNTAIN TOWER

OWNER'S MANUAL



BERNINI

THANK YOU FOR YOUR PURCHASE!

Product Registration:

Bernini Fountains recommends you register your new fountain. You can register on-line at berninifountains.com/register, by printing and mailing in a registration card available on-line from our website, by calling our customer care department at 1+ (619) 449-2392, or by emailing us at customercare@ berninifountains.com. Failure to register your fountain will not diminish your warranty rights. However, registering your fountain will allow Bernini Fountains to better serve you with any of your customer care needs.

FIRST THINGS FIRST:

Bernini Fountains is dedicated to our customers. We strive to make your customer care experience as pleasurable as possible. With that being said, there are always circumstances beyond our control when a fountain doesn't work or breaks under normal operating conditions. We think it's important that you know what you can expect from us. This is why we have a limited one year warranty on our fountains.



HAS YOUR BERNINI EXPERIENCE LEFT YOU HAPPY?

Tell your friends, tag us and leave us a review! We would love to hear your feedback! Share your experience by writing comments and reviews on berninifountains.com or connect with us on social media!

#BERNINIFOUNTAINS



OR HAS SOMETHING LEFT YOU WANTING MORE?

We're sorry to hear that! Our friendly Customer Care Team is ready to assist you in any way possible to resolve any issues you may have, Monday - Friday 8:30am to 4:00pm PST, 11:30am to 7:00pm EST

CALL US, EMAIL US, CHAT WITH US







FB: Bernini Fountain Company



EMAIL: customercare@berninifountains.com



PINTEREST: Bernini





www.berninifountains.com

$BERNINI^{m}$

PLEASE READ FIRST BEFORE RETURNING



- Our Customer Care Department is available: Monday - Friday 8:30am to 4:00pm PST, 11:30am to 7:00pm EST
- If you have any questions regarding assembly, parts or operation, please visit our website at www.berninifountains.com.
 - At berninifountains.com you will find instructional videos on how to assemble and operate your fountain and you can view our newest products.
 - This product comes with a one year limited warranty against materials and workmanship, see page 32.
 - Please review the list of accessories included with your Bernini™ Fountain on the next page. Please note, images of parts are not to scale with one another.

About Matera:

Matera is a city on a rocky outcrop in the region of Basilicata, in southern Italy. It houses museums like the Casa Grotta di Vico Solitario, with period furniture and artisan tools. Nearby rock churches include St. Lucia alle Malve, with 13th-century frescoes..





Battery Compartment & Water Pump



Water Tubes ('L'-Long, 'M'-Medium & 'S'-Short)



Pirouette

Shower

Dancing Water Attachments

Umbrella



Cap



3 Prong Foot



Upper Body

Lower Body (Infinity Bowl/ Bird Feeder/ **Self-Watering Planter**

Fountain Body

Items/Tools Required: (Not Included)

- · Philips Screwdriver
- 4 D Cell Batteries



PLEASE READ THIS INSTRUCTION MANUAL IN ITS ENTIRETY PRIOR TO ASSEMBLING YOUR FOUNTAIN.

PAGE

PAGE:	
1.	STEP 1: BATTERY INSTALLATION
2.	Inserting Batteries Into The Battery Compartment
3-4.	Installing Batteries
5.	Assembling Battery Compartment Housing & Battery C
6-7.	Assembling the Water Pump, Water Tube to Battery Co
7-8.	Changing The Batteries
9.	
10.	Modular Fountain Body Styles/Configurations
11-12.	Style/Configuration 1 & 2
12-13.	Assembling The Water Pump & Water Tube To Battery
10.11	Compartment For Style/ Configuration 1 & 2
13-14.	Style/Configuration 3
15.	Assembling The Water Pump & Water Tube To Battery
10 17	Compartment For Style/ Configuration 3
16-17.	Style/Configuration 4, 5 & 6
18.	Assembling The Water Pump & Water Tube To Battery
10	Compartment For Style/ Configuration 4, 5 & 6 STEP 3: 3-IN-1 INFINITY BOWL/BIRD FEEDER/
19.	PLANTER BOWL
20.	Infinity Bowl
20.	Self-Watering Planter
20.	How The Self-Watering System Works
21.	Self-Watering Planter Assembly
22.	
	STEP 4: SETTING UP YOUR FOUNTAIN
24.	Fill Your Fountain
24-25.	Operating Your Fountain
26.	Dancing Water Attachments
27.	TROUBLESHOOTING AND MAINTENANCE
27.	Water Pump Connection
28.	Priming the Water Pump
28.	Cleaning Your Fountain
28-29.	Cleaning Your Water Pump's Parts
29-30.	Cleaning Your Water Pump Impeller
30.	Cold Storage
31.	Troubleshooting Guide
32.	Limited Warranty Information

STEP

BATTERY INSTALLATION

You will need:



Battery Compartment Water Tube & Water Pump



Upper Body

Lower Body (Infinity Bowl/ Bird Feeder/ Planter Bowl)

Fountain Base

PLEASE READ THIS INSTRUCTION MANUAL IN ITS ENTIRETY PRIOR TO ASSEMBLING YOUR FOUNTAIN.

> Items/Tools Required: (Not Included)

- · Philips Screwdriver
- 4 D Cell Batteries





INSERTING BATTERIES INTO THE BATTERY COMPARTMENT Figure 1b Figure 1a Figure 1c Battery Compartment Retaining Screws X2 Figure 1d

NOTE: There are 6 different ways (configurations) to build this fountain For simplicity and because we are showing how to install batteries, in this step we are showing 1 way to configure this fountain. Please refer to Step 2 for specific ways to configure the fountain in the way you desire.

INSTALLING BATTERIES

NOTE: The Battery Housing utilizes screws that are captive in the Battery Housing. When they are loosened they will stay within the Battery Housing and will not come loose (Arrow A & B Figure 2c).

- 1. (If Battery Compartment & Water Pump are installed into the Topper) Lift out of the Fountain (Figure 1a). Disconnect the Water Tube from the Battery Compartment (A Figure 1b&c). When pulling the water tube from the pump and or battery housing, grab the water tube above the black nipple and not on the black nipple (Figure 1e).
- 2. Unscrew (counter clockwise) the Battery Compartment Screws and open cover (Figure 1d). Note: Cover fits tightly and may take some effort to separate. If screws continue to turn compartment is completely unscrewed.




Figure 1e

3. Fountain requires 4 D batteries (Not Included). Insert x2 D Batteries with the (+) side facing up in Battery Compartment and x2 D Batteries with the (-) facing up in Battery Compartment (Figure 2a).

NOTE: Flat or negative side of battery will rest on springs.


- 4. Reinstall the Fountain Top by aligning the locating dowel in the Battery Compartment and Fountain Top (Figure 1f white arrow). Set the Battery Cover down onto the Battery Compartment ensuring the dowel sets into the alignment hole.
- 6. Apply pressure and tighten the Battery Cover Screws by turning clockwise.


NOTE: Pressure must be applied to the Battery Compartment while tightening the screws to assure the compartment is properly sealed. If needed, while holding battery compartment, place it upside down on an even surface to tighten screws (Figure 2a, 2b & 2c).



3

INSTALLING BATTERIES (CONTINUED)








4

ASSEMBLING BATTERY COMPARTMENT HOUSING & COVER



- 1. Place Battery Cover on Battery Compartment Housing. Turn over assembled Battery unit and place on a flat, level surface. Using a Phillips screwdriver (not included) alternate tightening both screws down firmly.
- 2. After both screws have been tightened, you may notice a small gap between the Battery Cover and the Battery Compartment Housing.
- 3. Press down firmly on the bottom of the Battery Compartment Housing to help tighten the gap.
- 4. Re-tighten the screws (left screw first, right screw second) to close the gap between the Battery Cover and the Battery Compartment Housing.



ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT




Figure 3a

NOTE: There are 6 different ways (styles/configurations) to build this fountain For simplicity and because we are showing how to install batteries, in this step we are showing 1 way to configure this fountain. Please refer to Step 2 for specific ways to configure the fountain in the way you desire.

- 1. Connect one side of the Water Tube to the Water Pump and the other end of the tube to the bottom side of the Battery Compartment (A & B of Figure 3a).
- 2. Lower the Battery Compartment and Water Pump into the Fountain Body. Battery Compartment and Water Pump should be flush with Topper (Figure 3e).
- 3. Set into the Bowl of your choice (not Included) (Figure 3G).



ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT (CONTINUED)





Figure 3g Bowl Not Included

Figure 3e

CHANGING THE BATTERIES

- 1. Remove any Dancing Water Attachment.
- 2. Lift Battery Compartment and Water Pump out of the Fountain (Figure 4a).

NOTE: When changing batteries, ensure Battery Compartment and Water Pump are completely dry before opening Battery Compartment to prevent water from getting inside.



CHANGING THE BATTERIES (CONTINUED)





SIEP 2

MOULAR FOUNTAIN BODY ASSEMBLY

You will need:



Cap



3 Prong Foot



Water Tubes ('L'-Long, 'M'-Medium & 'S'-Short)



Battery Compartment Water Tube & Water Pump



Upper Body




Lower Body (Infinity Bowl/ Bird Feeder/ Planter Bowl)

Fountain Body

MODULAR FOUNTAIN BODY STYLES/CONFIGURATIONS

There are 6 different styles/configurations to build your fountain (each of the styles/configurations are shown below with a corresponding number to better assist you). Choose any of the styles below to configure your fountain to suit your mood. Refer to the following sections to build your fountain (bowl not included).



STYLE/CONFIGURATION 1 & 2:

Style/Configuration 1 & 2: The upper and lower fountain body halves have locking grooves (upper body) and tabs (lower body) (Figure 1 & 2). Take the upper and lower fountain body halves, align the grooves and tabs and insert the lower into the upper body (Figure 3). Turn clockwise until locked (Figure 4).


UPPER AND LOWER BODY LOCKING RINGS




Figure 1



Lower Body Locking Tabs Figure 2



Configuration 1 & 2 (Continued): There are 2 different styles/configurations that utilize the 'L'- Long Hose (16cm /6.3"), (Figure 5 & 6).



ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT FOR STYLE/CONFIGURATION 1 & 2





Figure 7

- 1. Use the 'L'-Long Hose (16cm /6.3") for this step.
- 2. See **Step 1** to install batteries.
- 3. Connect one side of the Water Tube to the Water Pump and the other end of the tube to the bottom side of the Battery Compartment (A & B of Figure 7).
- 2. Lower the Battery Compartment and Water Pump into the Fountain Base. Battery Compartment and Water Pump should be flush with Base (Figure 8).
- 3. Set into the Fountain Configuration 1 (Figure 8).

ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT FOR STYLE/CONFIGURATION 1 & 2 (CONTINUED)



Configuration 1 & 2 Figure 8




Your fountain should look like one of the images above when complete.

STYLE/CONFIGURATION 3:

Style/Configuration 3: This style/configuration utilizes the "M"-Medium Hose (12cm/4.72"). The Lower Fountain Body sets into upper Fountain Body to create Configuration 3. Take the upper and lower body halves and set the Lower Fountain Body Down into The upper Fountain Body (Figure 8).



STYLE/CONFIGURATION 3: (CONTINUED)



ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT (STYLE/CONFIGURATION 3)




Figure 10

- 1. Use the 'M'-Medium Hose (12cm/4.72") for this step.
- 2. See **Step 1** to install batteries.
- 3. Connect one side of the Water Tube to the Water Pump and the other end of the tube to the bottom side of the Battery Compartment (A & B of Figure 10).
- 2. Lower the Battery Compartment and Water Pump into the Fountain Base. Battery Compartment and Water Pump should be flush with Base (Figure 11).
- 3. Set into the Fountain Configuration 2 (Figure 11).





Your fountain should look like the image to the right when complete.


Style/Configuration 3

Figure 11



STYLE/CONFIGURATION 4, 5 & 6:


Configuration 4 & 5 & 6: There are three styles/configurations that utilize the Short Hose (Figure 12, 13 & 14). Place the Battery/Pump Assembly into either the Top Fountain Body (style/configuration 4) or the Bottom Fountain Body (style/ configuration 5).



STYLE/CONFIGURATION 4, 5 & 6: (CONTINUED)

Configuration 3: With this style/configuration the Lower Fountain Body can be set up as a Bird Feeder, Infinity Pool or a Self-Watering Planter. Please refer to Step 3 for specific instructions on assembling this style/configuration the way you wish (Figure 14).

Figure 14



ASSEMBLING THE WATER PUMP & WATER TUBE TO BATTERY COMPARTMENT (CONFIGURATION 4, 5 & 6 CONTINUED)




Figure 16

- 1. Use the 'S'-Short Hose (3cm /1.18") for this step.
- 2. See **Step 1** to install batteries.
- 3. Connect one side of the Water Tube to the Water Pump and the other end of the tube to the bottom side of the Battery Compartment (A & B of Figure 15).
- 2. Lower the Battery Compartment and Water Pump into the Fountain Base. Battery Compartment and Water Pump should be flush with Base (Figure 12, 13 & 14).
- 3. Set into the Fountain Configuration 4, 5 or 6 (Figure 12, 13 & 14).



Your fountain should look like the image to the right when complete.



Move on to the next section which will explain and show you how to configure this style/Configurations 3-In-1 Infinity Bowl/Bird Feeder/Self Watering Planter.

Configuration 4, 5 & 6



Figure 17



3-IN-1 INFINITY BOWL, BIRD FEEDER, SELF-WATERING PLANT

You will need:



3 Prong Foot



Cap



Infinity Bowl/Planter /Bird Feeder

INFINITY BOWL

To install the Bowl as an Infinity Pool:

- Take the Bowl and the Cap, screw the Cap into the inside of the bowl turning clockwise (Figure 1, 2 & 3). DO NOT OVER TIGHTEN.
- Place infinity Bowl on the fountain spout just as you would place one of the Dancing Waters Attachments.
- Push button to enjoy your fountain.








Figure 1

Figure 2

Figure 3

SELF-WATERING PLANTER HOW THE SELF-WATERING SYSTEM WORKS

Your self-watering garden fountain waters from the bottom up. Do not worry if you do not see the top soil becoming wet after the first day or two of use. The bottom layer of the soil will be watered every time you run the fountain. After approximately 3 days, the soil will reach its maximum water level. The water will steadily climb to just below the surface of the soil, while your fountain is on, the water level rises, watering your plant from bottom to top. (Figure 5).

When your fountain is off, the roots of your plant will be aerated to produce strong healthy roots. When the fountain is on, the water level will rise above the surface of the top planter bowl, saturating the soil (Figure 6).








Figure 4

Figure 5

Figure 6





SELF-WATERING PLANTER ASSEMBLY

To install the Bowl as a Planter:

- Take the Bowl and 3 Prong Foot, line up the arrows (Figure 11 white circle) on the 3 Prong Foot to the "Planter" position located on the bottom of the bowl (Figure 8).
- Align the arrows and push firmly to lock in place.
- There are 2 small holes on the bottom of the planter that will allow water to be absorbed from the bottom of the bowl when fountain is running (Figure 4, 5 & 6).
- Place the Bowl and Foot on top of the fountain. Be sure to not cover the button or light on top of the fountain.
- Push on 3 Prong Foot to secure.
- Once Planter is in place use your favorite soil (do not over pack) and plant your new addition to your family.
- Push button to enjoy your fountain.



BIRD FEEDER



Figure 10

Figure 9

To install the bird feeder:

- Take the Infinity bowl and 3 prong foot, line up the arrows (Figure 11 white circle) on the 3 prong foot to the bird feeder position located on the bottom of the bowl (Figure 9 & 10).
- Align the arrows and push firmly to lock in 3 prong foot.
- Place the bowl and foot on top of the fountain.
- Be sure to not cover the button or light on top of the fountain.
- Push on 3 prong foot to secure.
- Fill bowl with bird food, avoid over-filling to prevent bird seed from going in your fountain.
- Push button to enjoy your fountain.



Figure 11



S I E P

SETTING UP YOUR FOUNTAIN

You will need:



FILL YOUR FOUNTAIN

- · Fill Bowl with water. Depending on bowl size or depth, ensure water does not touch bottom of battery housing.
- To dislodge any air bubbles from the pump, grab both sides of the large bowl and quickly shake your fountain for ten seconds.
- · Press the button once to turn your fountain on. Water should be flowing from the top of your fountain.
- · If water is not flowing, press the button once more to turn your fountain off and repeat the step above.

OPERATING YOUR FOUNTAIN




Figure 1

Turn Fountain on and off:

- · The A Button is the manual on and off button.
- With the Fountain off, press the A button: The fountain will run for a maximum of 6 hours or until the A button is pressed again which will shut the fountain off.



OPERATING YOUR FOUNTAIN (CONTINUED)

Programing The Fountain:

- · Press the A Button 2 times: Clears out all programing.
 - **Press the B Button 1 time:** Will program the fountain to run for 1 hour each day at the same time. The light (Figure 1), will flash once to confirm your selection.
- **Press the B Button 2 times:** Will program the fountain to run for 2 hours each day at the same time. The light (Figure 1), will flash twice to confirm your selection.
- **Press the B Button 3 times:** Will program the fountain to run for 3 hours each day at the same time. The light (Figure 1), will flash 3 times to confirm your selection.
- **Press the B Button 4 times:** Will program the fountain to run for 4 hours each day at the same time. The light (Figure 1), will flash 4 times to confirm your selection.
- **Pressing the B Button more than 4 times:** Pressing the B Button a fifth time will shut off the fountain. If this is done by mistake and you want to ensure that a timer is set, press the A button twice to reset the system (which will turn the fountain on and off), then press the B button as indicated above to set the timer for the desired interval time.

Reset/Change the timer:

· Press the A button twice to clear out any timers programmed into the B Button. If you want to reset the timer, set the B Button Programing as in the "Programing The Fountain" Section above (Figure 1).



DANCING WATER ATTACHMENTS




Figure 2b Figure 6c

DANCING WATER ATTACHMENTS: (OPTIONAL)

You can put any of the Dancing Water Attachments on the Fountain whether the Fountain is running or is not running.

· Select one of the Dancing Water Attachments and place on the outlet in the middle of the Battery Compartment (Figure 2a, 2b & 2c).

NOTE: Please be aware that there is over-spray that occurs while using the Dancing Water Attachments.



You can now try your fountain to see if everything is working correctly! Turn your fountain on and you should see water flowing from the outlet on the top of the Topper. If water is not flowing, please refer to the "Priming The Water Pump" in the "Troubleshooting & Maintenance" Section.



THE FOLLOWING SECTION COVERS THE 3-IN-1 INFINITY BOWL/BIRD FEEDER/PLANTER BOWL.



TROUBLESHOOTING AND MAINTENANCE

WATER PUMP CONNECTION

If your fountains water pump tube becomes disconnected from pump and or Battery Compartment use these instructions to reconnect your water pump.



Before beginning, remove the Battery Assembly from Topper. Step 1: Lift the Battery Assembly out of the Topper to access pump and tube.



Step 2: Rest the Battery and Pump Assembly on its side. Check the connection at the top of the water tube at the Battery Housing. Reconnect if needed.



Step 3: Check the connection at the bottom of the water tube at the Water Pump. Reconnect if needed.



Step 4: Reassemble the Battery and Pump Assembly in reverse of removal or refer to the instructions in the Battery and Pump Assembly section of this manual.



PRIMING THE WATER PUMP

If you find the Water Pump is running, but water is not flowing from your Fountain, you can try priming the Water Pump:

- **Turn off Fountain:** Grab both sides of the Fountain and quickly shake your Fountain for ten seconds. This is to dislodge any air bubbles that may be caught in your Water Pump.
- Press the button to turn your Fountain on: Water should be flowing from the top of your fountain. If water is not flowing, press and hold button for over two seconds again to turn your Fountain off and repeat the step above.

CLEANING YOUR FOUNTAIN

To keep your fountain in tip top shape and for a prolonged life It is important to keep your fountain clean.

- · To clean your fountain, drain of all water and disassemble
- · Use a mild soap and a soft cloth to clean the parts of your fountain.
- DO NOT SCRUB YOUR FOUNTAIN, THIS COULD CAUSE DAMAGE TO THE FINISH OF YOUR FOUNTAIN.

CLEANING YOUR WATER PUMP'S PARTS

After about <u>six weeks</u> of usage, clean the water pump's impeller to keep your fountain in tip-top shape. The water pump impeller inside of the water pump is what pushes water up through the fountain. Clean the water pump impeller to make sure your fountain runs optimally.


· Drain the fountain of all water prior to cleaning the water pumps' parts.



When pulling the water tube from the pump and or battery housing, grab the water tube above the black nipple and not on the black nipple.



CLEANING YOUR WATER PUMP'S PARTS (CONTINUED)



Begin by disconnecting the pump from the water tube. (See inset image)

Step 1: Remove the front of the water pump by grabbing the sides of the front panel and pull it off the unit.

Step 2: Remove the impeller chamber cover. This is tightly fitted on to the impeller chamber, but will come off.

CLEANING YOUR WATER PUMP IMPELLER



Step 3: Remove the impeller from its chamber.



Step 4: Rinse the impeller and the impeller chamber until all debris has been removed.

CLEANING YOUR WATER PUMP IMPELLER (CONTINUED)

Reassembly is the reverse of disassembly.

- · Replace the impeller in the impeller chamber.
- · Put the impeller chamber cover back on.
- · Replace the pump's front panel.

COLD STORAGE

- · Turn power off
- · Remove fountain from container.
- · Clean and dry the fountain of all water.
- · Remove the batteries for long term storage and bring the fountain indoors.

Now is a great time to clean the pump to remove any debris that may have accumulated throughout the year.

TROUBLESHOOTING AND MAINTENANCE

PROBLEM	SOLUTION
Fountain is not working	Check that batteries have a full charge: (See Changing Battery Section).
	Prime Pump as instructed. (Refer to Priming The Water Pump).
	Check batteries are installed correctly: (See Installing Battery Section).
Water Not Flowing	Check that batteries have a full charge: (See Changing Battery Section).
Flowing	Check water level.
	Check pump is free of debris, kinks or obstructions. (See Troubleshooting section).
	Check water tube is connected properly. (See Base and Fountain Bowl Installation Section).
	Prime Pump as instructed. (Refer to Priming The Water Pump Section)
Loud Pump	Check water level.
	Check pump is free of debris, kinks or obstructions. (See Troubleshooting section)
Fountain Settings not working	Check that batteries have a full charge: See Changing Battery Section.
	See Changing Battery Section.
Low Water Flow	Check pump is free of debris, kinks or obstructions. See Troubleshooting section.
	Check water level.
	Pump is cavitating. See Priming The Water Pump Section.
Suddenly Stops	Check pump is free of debris, kinks or obstructions. See Troubleshooting section.

BERNINI™

LIMITED ONE YEAR WARRANTY

This product has a one year limited warranty on all materials and workmanship. Bernini[™] warrants the original purchaser of this product that the product will be free from manufacturing defects in workmanship and material for a period of one (1) year from the date of original purchase.

If within one (1) year this product fails due to defect in material or workmanship, Bernini[™] will repair, replace or supply any defective part at their discretion.

The purchaser must contact BerniniTM and provide a description of the defective part, including digital pictures if requested, with this original purchase documentation as validation of warranty coverage.

This warranty does not cover or apply to: (a) damage to the product due to misuse, mishandling, and abuse, (b) products not used in accordance with instructions, (c) product not assembled or installed according to instructions, and (d) normal wear and tear.

Call for assistance at 1+ (619) 449-2392 or you can email us at: customercare@berninifountains.com

Our Customer Care Department is available: Monday - Friday 8:30am to 4:00pm PST / 11:30am - 7:00pm EST



IMPORTANT BATTERY SAFETY INSTRUCTIONS

DANGER: Do not store battery in an airtight container as it may cause an explosion.

WARNING: When using electric devices, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

WARNING:

- 1. Do not incinerate the battery even if it is severely damaged or is completely worn out.
 - The battery can explode in a fire.
 - Check with municipal codes in your area for possible special battery disposal instructions.
- 2. If liquid leaks from the battery cell, discontinue use immediately and dispose of batteries properly.
- 3. Use only 4-1.5V D Cell Batteries.
- 4. Do not mix old and new batteries.
- 5. Do no mix alkaline, standard (Carbon-zinc), or rechargeable (Ni-Cd, Ni-Mh, etc) batteries.
- 6. Do not attempt to disassemble, remodel or destroy the batteries, as it may cause battery leakage, fire, or bursting.
- 7. Never dispose of batteries in the garbage.
 - Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations.
 - Always take used batteries to your local battery-recycling center.



BERNINI™

THANK YOU FOR SELECTING BERNINI FOUNTAINS

Were excited to offer you the highest quality fountains with the reliability you need! We would love to hear if you have any suggestions or ideas that can be incorporated into new or enhanced features. We hope you have many years of enjoyment from your fountain and we look forward to hearing from you.

PLEASE READ THIS INSTRUCTION MANUAL IN ITS ENTIRETY PRIOR TO ASSEMBLING YOUR FOUNTAIN.



Scan this QR code for the latest version of these instructions



PHONE: 1+ (619) 449-2392



EMAIL: customercare@berninifountains.com











Santee, California 92071 World Wide Patents Pending © Yeiser Research & Development, LLC; 2023. All rights reserved.