




WARNING:

- Risk of electric shock. Disconnect power at fuse or circuit breaker before installing or servicing.
- To prevent early lamp failure, lamp should only be installed in operating environments between -20°C and + 40°C (-4°F and 104°F)
- No user serviceable parts inside. To avoid electric shock do not disassemble product.
- This product is not intended for use in emergency light fixtures or exit signs.

ATTENTION:


Unit must be installed into a UL Listed junction box
 Turn power off before inspection, installation, or removal.
 Suitable for use in wet locations.
 Use only on 120VAC, 60Hz circuits.

What's In The Box



Tools Needed

A screwdriver is needed for installation.



Minimum Compartment dimensions

J-Box min. volume = 12.5in³


Compatible with standard 4/O and 4" non-metallic j-boxes.

Make sure all power is turned off before beginning installation


4/O and 4" Non-Metallic Ceiling Box Installation

- 1 Make sure building wires are accessible from J-Box.
Strip back building wires minimum 3/8"

- 2 Remove faceplate from light by pulling to lift from magnets.




- 3 Select desired lumen output and color temperature by adjusting the switches on the side of the fixture.




CCT:
2700/3000/3500/4000/5000K
Lumens:
550/700/900lm

- 4 Prepare mounting location by inserting mounting screws into the junction box screw holes.


- 5 Splice fixture wires to the building wires with push-in connectors (included): black to line (black), white to neutral (white), and green to ground.



- 6** Tuck all wiring into junction box. Align fixture keyhole slots to screws. Carefully press fixture into box.




- 7** Turn fixture to lock into keyholes. Tighten two (2) screws.



- 8** NOTE: For wet location installations: Install the included gaskets over the keyholes and apply a bead of caulking to the edge of the faceplate before attaching.

Re-attach faceplate to fixture by aligning faceplate with fixture and pressing until faceplate is retained by fixture magnets.


Note: To change faceplate to colors or square shape (available separately), remove original faceplate (see Step 2) and press on new faceplate.




- 9** Power on the fixture to enjoy your new surface mount LED downlight.

Wall Wash Accessory Installation

- 1** With faceplate removed, take a small screw driver or other prying tool and carefully pop the diffuser from the reflector cone.





- 2** Being careful not to contact the LEDs, insert the wallwash reflector into the fixture reflector cone. Ensure the snaps fully engage.



- 3** Complete fixture installation per steps 3-7 above. Once fixture is installed, wall wash reflector can be rotated to orient into the desired direction. Once reflector is set, install faceplate by pressing until faceplate is retained by fixture magnets and align to opening.

NOTE: NOTE: For wet location installations: Install the included gaskets over the keyholes and apply a bead of caulking to the edge of the faceplate before attaching.



NICOR LED Express Limited Warranty

Subject to the exclusions below, each NICOR LED product, including the LED electronics and components of a property installed NICOR LED product, will be free from defect in materials and workmanship for a period of five (5) years from the original date of purchase. The product shall be considered defective only if 10% or more of the product's LED components fail. NICOR LED product warranty covers the following performance criteria: LED Light Output will be maintained above 70% of initial output; LED color temperature will not shift more than 200K in CCT; LED driver will operate within NICOR specifications; and the fixture finish, excluding natural aluminum or brass products, will not exhibit cracking, peeling, excessive fading, or corrosion during the warranty period. Exceptions apply as defined in NICOR's product specification sheets, which are incorporated by reference herein.

This limited warranty is provided to you, the purchaser of the product identified on Seller's invoice, as your exclusive remedy and applies only to NICOR products that have been purchased from an authorized NICOR Distributor; the product was new and in an unopened NICOR package at the time of installation; and the NICOR product was installed by a licensed electrician or under the supervision of a licensed electrician and used by consumers in the United States or Canada when accompanied with this warranty.

This warranty extends only to the first consumer purchaser and is not transferable. A consumer wishing to invoke the terms of this limited warranty must first obtain a RGA number within 30 days of discovery of the defect, and return the product to NICOR for inspection. Once verified to be covered by this limited warranty, NICOR will, at its sole discretion, repair, replace, or refund the purchase price of any product that does not conform to this limited warranty. If NICOR, at its sole discretion, determines that the product should be repaired or replaced, this warranty is limited to the reasonable, customary, and necessary costs and expenses associated with the repair/replacement. This warranty requires that all repair/replacement estimates and costs, including but not limited to equipment rental (if any), and any other cost or expense to be incurred in the repair/replacement of the product, be approved in advance and in writing by NICOR.

FAILURE TO OBTAIN NICOR'S ADVANCE WRITTEN APPROVAL OF ALL REPAIR/REPLACEMENT COSTS AND EXPENSES IN WRITING SHALL VOID THIS LIMITED WARRANTY.

THIS LIMITED WARRANTY DOES NOT COVER THE FOLLOWING:

- Defects or damages resulting from improper installation, operation, storage, misuse or abuse, accident, or neglect;
- Defects or damages resulting from improper service, testing, adjustment, installation, maintenance, alteration, connection to out-of-specification electrical service, corrosive or damp environments, or connection to incompatible equipment or devices (e.g., connecting non-dimmable lighting products to dimmers);
- Damage which occurs in transit;
- Power surges or overheating due to external conditions
- Acts of nature including but not limited to lightning strikes

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL NICOR BE LIABLE, WHETHER IN CONTRACT OR IN TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCT TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.