


Replacement Parts List

PART	DESCRIPTION	QTY
PARTS		
Α	TOP PANEL	1
В	FRONT PANEL	1
С	LEFT PANEL	1
D	RIGHT PANEL	1
Е	BASE	1
HARDWARE		
F	CAM DOWEL	20
G	CAM LOCK	20
Н	SCREW	4

Mantel Assembly

Instructions

MODEL: AMF-CC/LM



NOTE: Carefully inspect each part for shipping damage before beginning assembly. Compare the carton contents with the list above. All necessary hardware is provided to fasten the mantel parts together. When tightening screws, do not over tighten. This may cause threads to strip. For this reason, we recommend using a manual screwdriver rather than a power screwdriver. Do not force screws into holes.

 Lay FRONT PANEL (B) down on a soft surface to avoid damaging the mantel surface and finish. place screw 6 CAM DOWELS (F) into the FRONT PANEL (B) as shown in figure 1. Insert 6 CAM LOCKS (G) into the mating holes in the LEFT SIDE (C) and RIGHT SIDE (D) with the triangle arrow pointing towards the hole in the edge. Mate the LEFT SIDE (C) and RIGHT SIDE (D) with the CAM DOWELS (F) in FRONT PANEL (B) and twist CAM LOCKS (G) clockwise with a screwdriver to tighten mantel sides to front panel.




Figure 1

2. Place screw 6 CAM DOWELS (F) into the BASE (E) as shown in figure 2. Insert 6 CAM LOCKS (G) into the mating holes in the LEFT SIDE (C), RIGHT SIDE (D) and FRONT PANEL (B) with the triangle arrow pointing towards the hole in the edge. Mate the LEFT SIDE (C), RIGHT SIDE (D) and FRONT PANEL (B) with the CAM DOWELS (F) in and BASE (E) and twist CAM LOCKS (G) clockwise with a screwdriver to tighten mantel sides to front panel.




Figure 2

3. Place Screw 6 CAM DOWELS (F) into the TOP (A) as shown in figure 3. Insert 6 CAM LOCKS (G) into the mating holes in the LEFT SIDE (C), RIGHT SIDE (D) and FRONT PANEL (B) with the triangle arrow pointing towards the hole in the edge. Mate the LEFT SIDE (C), RIGHT SIDE (D) and FRONT PANEL (B) with the CAM DOWELS (F) in and Top (A) and twist CAM LOCKS (G) clockwise with a screwdriver to tighten mantel sides to front panel.




Figure 3




Figure 4




Figure 5




Figure 6

FIREPLACE INSTALLATION

- 1. Fireplace should be fully assembled. Refer to fireplace owner's manual.
- Place mantel assembly close to installation location. Refer to fireplace owner's manual for installation clearances. Provide enough room to insert fireplace from back of mantel.
- 3. Insert fireplace into mantel. (Figure 4)
- 4. Turnover four metal sheets 90 degree on fireplace shell. (Figure 5)
- 5. Fix fireplace to mantel with 4 Screws (H). (Figure 6)
- 6. Carefully push mantel and base into position against wall.



Questions about installation, operation, or troubleshooting? Before returning to your retailer, Call customer service department toll-free at (877)886-5989.

Printed in China