

LTspice Model PWM Converter ROHM BM2P054

Model Information

Model A macro model
Call Name MDC_BM2P054_LT

Pin Assign 1:SOURCE 2:NC 3:GND 4:FB 5:VCC 6:DRAIN 7:DRAIN

File List Model Library MDC_BM2P054_LT.lib

Model Report MDC_BM2P054_LT.pdf(this file)

Verified Simulator Version LTspice XVII

Note Recommend to use METHOD=Gear

References

The information which was used for modeling is as follow:

[Data Sheet]

Date/VersionOct.2013/Rev.001Product nameBM2PXX4 SeriesCompany nameROHM Co., Ltd.

[Characteristics listed]

Characteristics

Transient(Soft Start) VCC Charge Bast Mode

Simulation Condition

This table shows the range of evaluated simulation range that was not occurs any convergence problems in this area.

Item	Condition	Unit
Temperature	25	deg C



O: Implemented

×: Not Implemented
—: Not applicable

Model Functions Table

RANK=1


	IV (IVI) — I	
Functions	RANK	Implemented
Control Method(PWM,PFM)	1	0
Enable Function	1	0
Soft Start	1	0
Line Regulation	1	0
Load Regulation	1	0
Synchronous External Oscillation	1	_
UVLO	1	0
Line Transient	2	×
Load Regulation	2	×
Light Load Current Mode	2	×
Spread Spectrum	2	×
Over Current Protection	2	×
Over Voltage Protection	2	×
Brown IN/OUT Function	_	_
ZT Pin OVP Function	_	_



Transient(Soft Start) Testbench

Referred to Data Sheet


tuan 0 100m 0 100u startu



Simulation results are following.

Explanatory notes — : simulated

Transient(Soft Start)






VCC Charge TestBench


Referred to Data Sheet

tran () 10m () 100u startui



Simulation results are following.

Explanatory notes — : simulated






Burst Mode Testbench

Referred to Data Sheet

.OPTION METHOD=Gear .OPTION TNOM=25 .TEMP 25 .PARAM VIN=100 k1 L1 L2 L3 0.998 RF1001T2D C1 C6 C4 L2 12.8u IC=0 V1 120k 2200p IC=0 330u IC=0 1000u IC=0 0.1u IC=0 / PWL(0 0 0.5m {VIN} 4m {VIN}) D3 RFL30TZ65 D2 RF05VAM2S 10u C3

Simulation results are following.

Explanatory notes — : simulated





© 2022 MoDeCH inc. Jan 04,2023 Rev 1.0



DISCLAIMER

- 1. This SPICE (Simulation Program with Integrated Circuit Emphasis) model and its content (the "Contents") are copyright of MoDeCH Inc. All rights reserved. Any redistribution or reproduction of any or all part of the Contents in any form is prohibited without express written permission made by MoDeCH Inc.
- MoDeCH Inc. as licensor (the "Licensor") hereby grants to you, as licensee (the "Licensee"), a nonexclusive, non-transferable license to use the Contents as long as you abide by the terms and conditions of this DISCLAIMER.
- 3. The Licensee is not authorized to sell, loan, rent and redistribute or license the Contents in whole or in part, or in modified form, to anyone.
- 4. The Licensor shall in no way be liable to the Licensee or any third party for any loss or damage (including ,but not limited to, lost profits, or other incidental, consequential, or punitive damages), however caused (including through negligence) which may be directly or indirectly suffered from, arising out of, or in connection with, any use of the Contents.
- 5. Notwithstanding anything contained in this DISCLAIMER, in no event shall Licensor be liable for any claims, damages or loss which may arise from the modification, combination, operation or use of the Contents with the Licensee's computer programs.
- 6. The Licensor does not warrant that the Contents will function in any environment.
- 7. The Contents may be changed or updated without notice. MoDeCH Inc. may also make improvements and/or changes in the products, pricing and/or the programs related to the Contents at any time without notice.



MoDeCH Inc.

Head Office

Location: 5-15 Yokoyama-cho, Hachioji-Shi, Tokyo 192-0081, Japan

Tel:+81-42-656-3360

E-Mail:model-on-support@modech.co.jp

URL:http://www.modech.com/en/