Goldair

Operating Instructions

Straight Flat Bar Towel Warmer 7 Bar Ladder



For Models: GTRMF7C, GTRMF7B

General Care and Safety Guide

When using any electrical appliance, basic safety precautions should always be observed.

READ THESE INSTRUCTIONS CAREFULLY.

This appliance is intended to warm and dry towels and therefore is hot to the touch. When used by or near young children or infirm persons, close supervision is necessary. Young children should be supervised to ensure that they do not play with the appliance.

NOTE The surface temperature of your towel rail will be 20-25 degrees higher than the ambient air temperature. Any rise in ambient air temperature is directly reflected in the appliance and as a result of this the appliance will feel hotter to the touch during warmer periods. Also the insulation effect of towels will cause the operating temperature to increase. Example, if the ambient air temperature is 20 degrees, this will mean the towel rail surface will be approximately 40-50 degrees.


- The towel rail is to be installed so that switches and other controls cannot be touched by a person in the bath or shower.
- DO NOT use this appliance for any purpose other than its intended use.
- To avoid a hazard this heated towel rail MUST NOT be used to carry towels or any other articles that have been in contact with oil, petroleum based products or dry cleaning fluids.
- Use this appliance only with the voltage specified on the rating label, or elsewhere in these instructions.
- Regulations require that electrical work be carried out only by authorised persons. For your own safety and that of others ensure this is done.
- DO NOT immerse in any liquid.
- For service contact your nearest Authorised Service Agent.


WARNING: In order to avoid a hazard for young children, this appliance must be installed so that the bottom rail is at least 600mm above the floor.

Specifications

SPECIFICATIONS/DIMENSIONS						
Model:	GTRMF7B	GTRMF7C				
Height:	825mm	825mm				
Width:	600mm	600mm				
Depth:	100mm	100mm				
ELECTRICAL						
Wattage:	80W	80W				
Colour:	Black	Stainless Steel				
Power supply:	230-240 VAC, 50Hz, single phase					
Ingress Protection Rating: IP55						

Dimensions





Components



2 x Upper Legs



4 x Grub Screws (Already fitted to Legs)



2 x Lower Legs 1 leg has a cut out for exposed wire install



2 x Screws for Securing Upper Legs



3 x Mounting Bush



2 x Screws for Securing Lower Legs







4 x Long Screws For mounting to wall



1 x Through Wall Bush For Concealed Cable



4 x Wall Plugs



1 x Allen Key

WARNING: Installation must be completed by a registered electrician.

Always choose a safe location for the Towel Rail, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the unit before use.

WALL PREPARATION

Goldair Heated Towel Rails may be fixed to any type of timber stud, steel stud or masonry (solid or cavity) wall.

Walls made from timber or steel require studs at the correct position for all rails. If the precise position can't be determined early in the job, consider sheets of 18mm construction ply, covering a larger area.

This rail has a small footprint against the wall. The wire holes and mounting holes must be drilled neatly and accurately.

For drilling through hard materials such as porcelain tiles, marble, granite etc. an appropriate drill bit must be used.

No responsibility will be taken by Goldair for instances where installers drill incorrectly.

NOTE: Attempting to fix into plasterboard or cement sheeting alone is not recommended. Plasterboard in particular will not hold long term.

PRE WIRING

NOTE: Only drill holes when you are 100% sure of your measurements.

A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring guidelines AS/NZS 3000:2007.

Provision should be made for a Timer to control the mains supply. It is recommended that a Timer is used for energy saving purposes. Goldair recommend a Goldair Heated Towel Rail Timer (GBT100 – not supplied).

WALL MOUNTED TOWEL RAILS ARE ONLY TO BE MOUNTED ON HEAT RESISTANT WALLS THAT COMPLY WITH CURRENT AS/NZS SPECIFICATIONS & BUILDING REGULATIONS

MOUNTING INSTRUCTIONS

You must next select which side of the towel rail is needed to be wired in. The heated towel rail within this box has two wiring options (left or right hand). The location of existing wiring through or on the wall will dictate which side you will use.

For Left hand wiring, connect the power cable from Point A. For Right hand wiring, connect the power cable from Point B.

For the side that you do not use, insert the termination plug into the power cable and secure with the cap screw fitting.





Select desired position to mount towel rail with at least 300mm clearance from all permanent objects in surrounding area and the bottom rung must be 600mm above the floor. The Ladder Towel Rail should be installed in accordance to local governing AS/NZS regulations. The Goldair Heated Towel Rail can only be mounted 1 way. Your towel rail is mounted by legs. The top two legs are fixed with a screw on each of the 4 legs as indicated in Fig1. below.


CONCEALED OR EXPOSED WIRING

First, select which method of cord entry your installation situation requires – exposed or concealed. (please see images below as an indication to the differences)


The accessory pack contains a set of 4 legs for your heated towel rail – one of which is a universal leg (used for both concealed and exposed installations)













- 2. Align the screw with the threaded hole of the upper leg positions on the towel rail, ensure grub screw is facing down. Tighten so that the legs are secured onto the upright tube. Do not overtighten, leave just enough give to allow the leg to rotate and align parallel with other legs.
- 3. Repeat steps 1 & 2 to attach the second upper leg



4. Using the short lower leg mounting screw, secure the non-wired side, lower leg by sliding the leg over the lower leg mount on the towel rail. Ensure the grub screw is facing down.


NOTE: Use the lower leg with the cutout for the side (either left or right) where the power cable is located.



5. The last lower leg should be installed either in a concealed or exposed manner, as per the previous page. For exposed wiring – ensure you use the included black cable guide to prevent damage to the power cable.



6. Hold the towel rail against the wall in the location where you want the towel rail mounted. Ensure it is located parallel using a spirit level. Using a pencil, mark the four legs position on the wall.



7. Mark the centers on the wall, note that the towel rail should be installed so that the bottom rail is at least 600mm above floor level.

600mm



8. Drill holes in the marked location to suit the screws provided, If installing into Gib board, Concrete or Block, insert wall plugs into the wall.



9A. If using an exposed cable, insert a long screw through the mounting bush, then fix into wall ensuring the fit is secure – ideally you should screw into timber for sufficient strength. Do this for all 4 legs.



9B. If completing a concealed cable installation, you will need to use the Through Wall Bush for mounting the last leg. Ensure you pass the power cable through the lug before installing to the wall. Screw through the smaller hole – leaving the larger hole for the cable to exit. Ideally you should drill through a timber joist to give it strength.

- 10. ENSURE THE MAINS POWER IS OFF BEFORE ELECTRICAL CONNECTION Remove the lower leg on the side you have selected for the power connection. Pass the power cable through the leg and connect it to the towel rail, screw the leg back onto the towel rail.
- 11. Align your towel rail over the top of the 4 mounting bushes, ensure all legs cover the mounting bushes. Make sure the towel rail fits correctly do not force into place if the alignment is not correct.



12. Tighten the grub screws with the Allen key supplied, this will secure your towel rail to the wall. If using the Through Wall Bush you will need to replace the 'grub' screw in that leg for the Pointed grub screw supplied.

Operating your Towel Rail

ELECTRICIAN INFORMATION

A copy of this User Manual should be left with the consumer for future reference.

A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring guidelines AS/NZS 3000:2007.

HEAT CONTROL

These towel rails run at a single temperature. Be aware they do get very hot to the touch.

CAUTION: The Towel Rail generates heat during use. Proper precautions must be taken to prevent the risk of burns, scalds, fires or other damage to persons

Do not attempt to dismantle the Towel Rail. There are no user serviceable parts. For service or repair, contact an authorised electrical service technician.

CARE AND CLEANING

The Towel Rail requires regular cleaning to ensure longevity of the product.

Turn off the isolating switch before cleaning. For additional protection, turn the mains supply off before cleaning.

Ensure that the towel rail has been allowed to cool down completely before cleaning.

Use a damp cloth (not wet) to wipe the exterior of the towel rail to remove dust and dirt.

Never use solutions such as benzene, thinners or polishing agents.

Never use abrasive materials like steel wool / scourers to scrub the towel rail.

Ensure the Towel Rail is dry before switching back on the mains supply and isolating switch.

RUST

Surface rust can occur on stainless steel over time. To avoid this the Heated Towel Rail is best wiped down from time to time with a damp cloth and a stainless steel cleaner. Fine scratching can be removed using a metal polish such as 'Autosol' or 'Brasso' Paste which are available from most supermarkets and car care shops.

PROOF OF PURCHASE

To receive warranty retain receipt as proof of purchase.



SUPPORT AND TECHNICAL ADVICE

Goldair – New Zealand Monday – Friday 8am-5pm Phone +64 (0)9 917 4000 Phone 0800 232 633 info@cdb.co.nz Goldair – Australia Monday – Friday 8am-5pm Phone +61 (0)3 9336 4423 Phone 1300 465 324 info@cdbgoldair.com.au



Three Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **three years.** In non-domestic use Goldair limits the voluntary warranty to **three months.**

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

Goldair - New Zealand

CDB Goldair PO Box 100-707 N.S.M.C Auckland

Phone +64 (0)9 917 4000 Phone 0800 232 633 Goldair – Australia CDB Goldair Australia Pty PO Box 574 South Morang Victoria, 3752

Phone +61 (0)3 9365 5100 Phone 1300 GOLDAIR (1300 465 324)

www.goldair.co.nz	www.goidaii.com.au				
Goldair Two Year Warranty (IMPORTANT: Please complete and retain this warranty card)					
Name					
Address					
Place Of Purchase	Date Of Purchase				
Name Of Product	Model Number				
Attack a convertible annual convertible to this vice was the cond					
Attach a copy of the purchase receipt to this warranty card					

Goldair





New Zealand PO Box 100707, North Shore Mail Centre Auckland, 0745 www.goldair.co.nz

Australia PO Box 574, South Morang, Victoria, 3752 www.goldair.com.au