



leadset Helmet Intercor Single Pack

User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein

Caring For Your MOMAN Product

- Please keep the product in a dry, clean, dust-free environment.
- · Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions
- Failure to follow all the instructions may result in mechanics damage.
- · Warranty does not apply to human errors.

Package List Back Clip x1 Velcro Clip x1



USB Cable x1





1 Pair of Speakers with Microphone x1















* If the intercom has pairing record with the mobile phone, they


will be connected after power on, provided that the Bluetooth is

* Method 2 works for group intercom connection or music









ON: Press the On/Off Key for 4 seconds. When you hear voice prompt,

(1) In power-off state, long press the On/Off Key for 6 seconds until the red and blue indicator

(2) Turn on Bluetooth function in the phone and search the signal. Choose "MOMAN H3" and

OFF: Press the On/Off Key for 4 seconds. When you hear voice

(5) Function Key

2 M Key

(4) Knob

Operation

Pairing

Method 1:

1. Power On/Off

the blue indicator flashes twice.

2.1 Pairing with Mobile Phone

flashes alternatively.


prompt, the red indicator flashes twice.







(2) Hard Microphone



on, pressing BT Key can enter intercom mode.

c) During intercom, there is automatic reconnect within 10 minutes after disconnection. Also

d) During intercom, press the BT Key to disconnect.









2.2 Pairing Between Two or More Intercoms

Between two intercoms (within 1 meter):

within 1 meter.

turned on.

connect


(1) Long press the On/Off Keys of intercom A & B for 4 seconds and the blue indicators flash slowly. Long press the BT Keys of intercom A & B for 4 seconds until the blue indicators flash

(2) Short press the BT Key of intercom A. When intercom A searches B signal, the blue indicators flash slowly and you hear "Du". After one second, the blue indicator of intercom B flashes quickly to search the next device, and flashes slowly to stop searching. Short press the BT Key of intercom to send the order and build the network. When your hear "Du", it means the network is built. Press the BT Key to start intercom. (When intercom B is searching the next

* a) When two intercoms are connected successfully, no need to pair repeatedly. After power-

b) When two intercoms are connected successfully, pressing the Function Key and On/Off Key can connect phone by Bluetooth. Press the BT Key of any intercom to intercom.

you can short press the BT Key to manually connect.



Between More Intercoms (within 1 meter):

End/Restart

and On/Off Key for 6 seconds at the same time.

(1) Long press the On/Off Keys of all intercoms for 4 seconds and the blue indicators flash slowly. Long press the BT Keys of all intercoms for 4 seconds until the blue indicators flash

(2) Short press the BT Key of one intercom (define as NO. 1). NO.1 enters auto-pairing mode. When it is connected with the other intercom (define as NO. 2), the blue indicators of NO. 1. and NO, 2 flash slowly, which means the connection are successful. After one second, the blue indicator of NO. 2 flashes quickly, searching the next intercom. When it connects to NO. 3 intercom, the blue indicators of NO. 2 and NO. 3 flash slowly, which means the connection are

(3) Press the BT Keys of all intercoms (firstly press NO. 1) to create group network. Press the BT Keys again to begin to intercom.

Notes: After group network is completed, short pressing the On/Off Key will report "The equipment is No. * ".

Press the BT Keys to end the intercom. It's recommended to restore the factory settings for each machine before pairing. Clear method: In the power on state, press and hold the M Key

* Due to using environment and exterior interference, it is recommended to create intercom group network of 4 users to the most within 1000 meter.



Music Control (1) Under Bluetooth connection mode, press the Function Key to play/pause music.

(1)Long press the On/Off Key for 4 seconds and the blue indicator flashes slowly. In standby

mode, long press the Function Key and the On/Off Key for 4 seconds until the red and blue

(2) When you hear "beep", the blue indicator flashes slowly, which means the connection is

Turn on: Restore factory settings of two intercoms. After pairing intercom A and intercom B

successfully, connect intercom A with phone Bluetooth. Short press the BT Key and play music.

Long press the Function Key for 2 seconds to enter music sharing pairing, with blue indicator

flashing quickly. The intercom B prompts and means sharing is successful.

Turn off: Randomly long press the Functional Key of intercom A or B.

indicator flashes alternatively. Turn on your headphone and make it enter pairing mode. Short

press the Functional Key and On/Off key of H3, and connect them until you hear voice prompt.


(2) Next Music: turn the Knob clockwise.

2.3 Pairing with Headphone of Other Brands

Music Sharing

successful. Press the BT Key again and start to intercom.

(3) Previous Music: turn the Knob counterclockwise.







4. Phone Control

Answer the call: press the Function Key

Automatic answer: When the phone calls and there is no operation after 8 seconds, it will answer the call automatically.

Reject the call: press and hole the Function Key for 2 seconds.

End the call: press the Function Key.

Redial: In standby mode, press the On/Off Key twice to dial the last call number.



- (1) Decrease: continuously turn the Knob clockwise.
- (2) Increase: continuously turn the Knob counterclockwise.
- * There is voice alarm for two high or two low volume.

6. FM Radio

- (1) **Turn on:** under standby mode, press the Function Key twice to switch to the FM radio.
- (2) Select Channels: quickly rotate the Knob and release to adjust and select channels. Continuously rotate the Knob to select different channels. Rotate the Knob continuously to enter volume adjustment.
- (3)Turn off: press the Function Key twice to get back to the previous mode.
- * If the signal is weak indoor, you could try to turn on the FM radio near
- * When FM radio is turned on and there is a phone calling, the machine will cut off FM radio automatically and connect to the mobile phone. It gets back to the FM radio when the call ends.



window or in the open area.

Function Priority Level 1: Mobile Phone

Level 2: Intercom

Level 3: Music/FM Radio

Language

There are 8 languages for choice.

When it is on, press the M Key and rotate the Knob at the same time to change the language of voice prompt.



9. Voice Wake up

In standby state, long press the M Key for 4 seconds to enter Voice Wake up Function.

10. Restore Factory Settings


In power-on state, long press the On/Off key + M Key for 6 seconds until the red indicator is on. Power off and the memory is clear.

11. Battery Announcement

In standby state, long press the M Key for 6 seconds and the voice announces battery, divided into 3 levels.

Installation

1. Method 1: Install with Back Clip






- ① Use the screwdriver to loosen the screws of the back clip so that it can open to a proper extent
- ② Open the helmet liner, insert the clip into the right position on the left side of the helmet and

tighten the screw.

- 3 Slide the intercom into the back clip slot to make sure it locks firmly.
- ④ Open the helmet liner (ear position), clean the EPS surface of the helmet, and stick a piece of horn Velcro on the left and right sides of the helmet.
- Stick the speaker on the fixed Velcro surface and the speaker with short line should be installed close to the machine. Fix the microphone and arrange the helmet lining and cable.
- (6) Insert the headset into the jack of the intercom and tie up the headset cable.

Method 2: Install with Velcro Clip




Separate the hook and loop fasteners. First stick the hook onto the Velcro clip; choose the right installation position on the helmet and stick the loop to the position. Install the intercom onto the Velcro clip.

The installation of speakers can refer to the description above.

How to Remove the Intercom from Helmet

First unplug the headset, then press the fixed buckle in the middle of the back clip with one finger (push towards the side of the helmet), so that the back clip hook is detached from the intercom, and push the intercom upwards to let it slide out of the back clip smoothly to complete the disassembly.







Before using the Bluetooth intercom, please use the attached charging cable to charge
the intercom. The small type-C interface on the charging line is connected to the USB
charging interface of the Bluetooth intercom, and the large USB connector on the charging
cable is connected to the following charging interface for power supply:

A. USB interface of computer:

- B. A mobile power supply with DC 5V output;
- C. A USB power adapter with DC 5V output.
- When charging, the red LED is always on, and when fully charged, the red light goes out slowly. It takes up to 2.5 hours to fully charge the unit.

Transmission Range	2000m
Connection Distance with Mobile	20m
Bluetooth Version	5.0
Bluetooth Protocol	A2DP, AVRCP
Charging Port	Type-C
Standby Time	up to 500H
Working Time	30H
Battery	1000mA
Charging Time	2H
Charging Voltage	5V
Speaker Diameter	40mm
Frequency Range	2.4GHz
Temperature Range	–20~50°C

Specifications

Notes

- If you do not use intercom for up to one month or more, please charge the intercom once every two months in order to protect the lithium battery;
- The storage temperature of this product is -20 °C to 50 °C, and do not store in the
 environment with too high or low temperature, otherwise, the service life of the product will
 be affected;
- 3. Do not expose this product to fire to avoid explosion;
- 4. Do not open other screws to the intercom to avoid short circuit of main board or battery damage.
- USB emergency shutdown: during working state, the Bluetooth intercom will power off if insert USB charging, which will not save any data.

Moman (UK) Limited

- 9. Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX 8 www.momanx.com
- https://moman.co/youtube