# **Outdoor Play Tent**

## **MATERIALS:**


2 yards of Loop (183 cm) Dowels or old broom handles Carpet tape

(if not using a sewing machine)


## TOOLS:

Scissors Straight edge / ruler Sewing machine (if not using carpet tape) **DIFFICULTY:** Medium


TIME: 1 hour




**STEP 1** Mark Loop 4 in (10 cm) from both long edges. Fold the edges into these marks.




**STEP 2** Sew/tape along the edge of each fold to create a pocket along the length.




**STEP 3** Fold Loop in half. Insert 4 dowels (roughly 36 in (91 cm) long), 1 at each end of the pockets.



**STEP 4** Plant all 4 dowels on the ground to stand the tent upright.



**STEP 5** Stick the dowels into the ground outside, tie a string to the corners to pull the tent out to stabalize the tent.



**STEP 6** When finished playing for the day, the tent can be taken down and rolled up.

#### Send us the scraps left over at the end of your project.



#### RECYCLING

Loop can be recycled and used to make plastic lumber for decks and other weather resistant, outdoor products. When your project is no longer needed please use the prepaid recycling envelope to send Loop back to us.

Misplaced your recycling envelope?

Please write to: info@mioculture.com or call us at: 215-925-9359

To order more Loop go to www.mioculture.com

