

# **USE AND CARE GUIDE**

## HARRISON 7PCS DINING SET

Product code: D71 M34582 UPC code: 769455 767141 Vendor Item: SS-I-139NS/6(2016)

Date of purchase: \_\_\_\_/ \_\_\_\_/

## Thank you for your purchase

### Thank you for your purchase

We are pleased that you have chosen Sears for your outdoor furniture purchase. We hope that you enjoy the unmatched quality, comfort, and style of your new patio set. Every piece is meticulously considered all the way down to the smallest details, exclusively for you, by our world class design team. We know you have a choice when it comes to your patio furniture needs, so from our team to yours, thank you for letting us be a part of your outdoors.

## **Table of Contents**

Table of Contents		
Safety Information	3	
Set Up your Furniture Properly	3	
Examine your furniture		
Warranty	3	
Care and Maintenance	4	
Pre-Assembly	4	
Planning Assembly	4	
Observe weight Limits	4	
Hardware Included	4	
Assembly Instructions		
Package Content	5	
Swivel	6	
Chair	8	
Customer Service	ç	

## **Safety Information**

### SET UP YOUR FURNITURE PROPERLY

Ensure that all parts are assembled properly and fully tightened as per the instructions
When placing in the desired location, ensure that all legs are resting on the same
surface. You may adjust the legs levelers as required to ensure that the item stands
in a rigid position.

### **EXAMINE YOUR FURNITURE**

Examine occasionally to ensure that there are no loose parts. If loose parts are	found,
they must be retightened fully before additional use.	

## Warranty

### WARRANTY

We warrant our products to be free of manufacturing defects to the original purchaser for the period listed below. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

### **EXCLUSIONS**

This warranty does not cover: Furniture used for commercial or non-residential purposes; failures caused by improper care; unreasonable or abusive use; freeze damage; acts of nature. Steel products are not covered against rust. Tempered glass table tops are not covered against breakage.

#### **FINISH**

Frame finish is warranted to be free of manufacturing defects for a period of one (1) year. Discoloration or fading of the finish as a result of exposure to the elements, chemicals, or spills is not covered.

### **FABRIC**

Fabric is warranted to be free of manufacturing defects for a period of one (1) year. Discoloration or fading of the finish as a result of exposure to the elements, chemicals, or spills is not covered.

### **FRAMES**

Frame is warranted to be free from defects in material or workmanship for a period of two (2) years for steel frame. This product is made with a steel frame.

### **FREIGHT & PACKAGING**

Freight and packaging are the responsibility of the original purchaser.

### **CUSTOMER SERVICE**

In case of a problem, call 1-800-457-4652 between 9:00 am to 5:00 pm Eastern standard time Monday through Friday or contact us at www.numarkcustomerservice.com for any question or problems you may have.

## **Care and Maintenance**

☐ Though its powder-coated finish is rust-resistant, steel is prone to rust over time with exposure to the elements. In case of rust or scratches, lightly sand the affected area and apply touch-up paint. To maintain the finish periodically apply wax with a soft cloth.

## **Pre-Assembly**

### PLANNING ASSEMBLY

Read through all the instructions before beginning assembly. Unpack and identify all the parts. Place them on a flat, non-abrasive surface. Assembly by two people is recommended.

### **OBSERVE WEIGHT LIMITS**

The recommended weight limits for the following products are listed below:

☐ Chair: 225 lbs

☐ Swivel: 225 lbs




**CAUTION:** If you overload your furniture, injuries can occur.

### HARDWARE INCLUDED



NOTED: Hardware not shown

to actual size.






## **Safety Information**


Do not completely tighten bolts and nuts until indicated in assembly step.

# **Package Contents**

ITEM	DESCRIPTION	QUANTITY
		_
Α	Swivel Frame	2
В	Swivel Base	2
С	Center Post	2
Ε	Sling Seat And Back	2




## 1 Inserting the sling seat and back into the swivel frame




## 2 Attaching the sling seat and back to the swivel frame






- Don't tighten completely.
- Repeat procedure for the other side.
- Securely tighten all bolts.

## 3 Inserting the center post into the swivel base




## 4 Pushing the swivel base into the center post




• Repeat procedure for the other swivels.


# **Package Contents**



## 1 Inserting the sling seat and back into the swivel frame



# **2** Attaching the sling seat and back to the chair frame



- Don't tighten completely.
- Repeat procedure for the other side.
- Securely tighten all bolts.
- Repeat procedure for remaining three chairs.
- Your chairs and swivels are now ready for use.



Please refer to part numbers when reordering


For questions or comments about product: Call toll-free: 1-800-457-4652

between 9:00 am to 5:00 pm Eastern standard time Monday through Friday or contact us at www.numarkcustomerservice.com

Made in / Hecho en CHINA Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products on-line at www.sears.com and www.kmart.com





# **USE AND CARE GUIDE**

## HARRISON 7PCS DINING SET

Product code: D71 M34582 UPC code: 769455 767141 Vendor Item: SS-I-139NT(2016)

Date of purchase: \_\_\_\_/ \_\_\_\_/

## Thank you for your purchase

## Thank you for your purchase

We are pleased that you have chosen Sears for your outdoor furniture purchase. We hope that you enjoy the unmatched quality, comfort, and style of your new patio set. Every piece is meticulously considered all the way down to the smallest details, exclusively for you, by our world class design team. We know you have a choice when it comes to your patio furniture needs, so from our team to yours, thank you for letting us be a part of your outdoors.

## **Table of Contents**

Table of Contents		
Safety Information	3	
Set Up your Furniture Properly	3	
Examine your furniture	3	
Warranty	3	
Care and Maintenance	4	
Pre-Assembly	4	
Planning Assembly	4	
Observe weight Limits	4	
Hardware Included	4	
Assembly Instructions		
Package Content	5	
Table	6	
Customer Service	7	

## **Safety Information**

### SET UP YOUR FURNITURE PROPERLY

Ensure that all parts are assembled properly and fully tightened as per the instructions.
When placing in the desired location, ensure that all legs are resting on the same surface. You may adjust the legs levelers as required to ensure that the item stands in a rigid position.

### **EXAMINE YOUR FURNITURE**

☐ Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be retightened fully before additional use.

## Warranty

### WARRANTY

We warrant our products to be free of manufacturing defects to the original purchaser for the period listed below. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

### **EXCLUSIONS**

This warranty does not cover: Furniture used for commercial or non-residential purposes; failures caused by improper care; unreasonable or abusive use; freeze damage; acts of nature. Steel products are not covered against rust. Tempered glass table tops are not covered against breakage.

### **FINISH**

Frame finish is warranted to be free of manufacturing defects for a period of one (1) year. Discoloration or fading of the finish as a result of exposure to the elements, chemicals, or spills is not covered.

### **FABRIC**

Fabric is warranted to be free of manufacturing defects for a period of one (1) year. Discoloration or fading of the finish as a result of exposure to the elements, chemicals, or spills is not covered.

### **FRAMES**

Frame is warranted to be free from defects in material or workmanship for a period of two (2) years for steel frame. This product is made with a steel frame.

### FREIGHT & PACKAGING

Freight and packaging are the responsibility of the original purchaser.

### **CUSTOMER SERVICE**

In case of a problem, call 1-800-457-4652 between 9:00 am to 5:00 pm Eastern standard time Monday through Friday or contact us at www.numarkcustomerservice.com for any question or problems you may have.

### **Care and Maintenance**

- ☐ Though its powder-coated finish is rust-resistant, steel is prone to rust over time with exposure to the elements. In case of rust or scratches, lightly sand the affected area and apply touch-up paint. To maintain the finish periodically apply wax with a soft cloth.
- Always use an umbrella base to secure umbrella. Do not store anything on glass tabletop. Ensure the "o" ring is in place in the umbrella hole in the glass top before inserting umbrella. Make sure umbrella is in the closed position when not in use and during high winds. Use furniture covers or store indoors during cold or inclement weather.

## **Pre-Assembly**

### PLANNING ASSEMBLY

Read through all the instructions before beginning assembly. Unpack and identify all the parts. Place them on a flat, non-abrasive surface. Assembly by two people is recommended.

### **OBSERVE WEIGHT LIMITS**

The recommended weight limits for the following products are listed below:

□ Table: 100 lbs




**CAUTION:** If you overload your furniture, injuries can occur.

### HARDWARE INCLUDED




**NOTED:** Hardware not shown to actual size.




Do not completely tighten bolts and nuts until indicated in assembly step.

# **Package Contents**

ITE	M DESCRIPTION	QUANTITY
		_
Α	Tempered Glass Tabletop With Rim	1
В	Leg (2 Metal Washers and 2 Bolts attached for each)	4
С	Metal Center Ring	1




## 1 Attaching the legs to the tabletop.




• Repeat procedure for the other three legs.

## **2** Attaching the legs to the tabletop.




- Securely tighten the screw.
- Repeat procedure for the other three legs.

## Attaching the metal center ring to the legs.



- Don't tighten completely.
- Repeat procedure for the other three legs.

## Inserting the umbrella insert piece into the umbrella hole.



• Your table is now ready for use.

Please refer to part numbers when reordering

For questions or comments about product: Call toll-free: 1-800-457-4652

between 9:00 am to 5:00 pm Eastern standard time Monday through Friday or contact us at www.numarkcustomerservice.com

Made in / Hecho en CHINA Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products on-line at www.sears.com and www.kmart.com