



Operating Instructions

40cm Electronic Pedestal Fan with Wifi



Model: GCPF170

Wifi – Downloading and Setting up APP

This APP is supported only on 2.4GHz Wifi channels.

The Goldair app and device pairing process require your 2.4ghz connection to be separated from your 5ghz connection. For instructions on how to do this please contact your internet provider.

Please note, we endeavour to keep our app up to date as devices and software continue to adapt and evolve. However, with ever changing technology and software we cannot guarantee as models age that their Wifi operation will continue to be supported. If you feel like the day-to-day functionality of your app is impacted, please contact our customer services team.

Download Goldair mobile APP

- Open the APP Store or Google Play on your mobile phone.
- Open 'Search' and enter 'Goldair'
- Click 'GET' and begin to download and install.

Once downloaded to your phone open the APP


- Tap REGISTER near the bottom of the screen.
- Read and agree to the Privacy Policy.
- Add your email address.
- Tap 'Obtain verification code'

You will then receive an email with a verification code.

- Enter the verification code from your email.
- Create a password.
- Then tap confirm.

If you haven't received a verification code via email, tap the resend button and when the verification code is received follow above steps.

Your APP is now registered and ready for pairing to your device.







New Zeal	and	
Email		
	Obtain verification code	



Connect with 2.4ghz Wifi Network




On the Home screen, tap 'Add Device' or the '+' icon.



Select 2.4 GH	
Network and ente	r password.
If your Wi-Fi is 5GHz, ple 2.4GHz. Common router	
× W-Fi - 5Ghz	
✓ Wi-Fi - 2.4Ghz	. ⊽ ()
ᅙ dlink2	4
۹	
Next	

Connect with 2.4ghz Wifi Network: EZ Mode

See instructions below to finalise your device pairing via EZ mode.






Your device will now pair with the app.

Please ensure your device, modem and phone are as close together as possible and that your 2.4ghz Wifi signal is strong.


Once the device has paired, choose to rename it by tapping the Pen icon

Choose the most suitable room type and click 'Done' in the top right hand corner.



Connect with 2.4ghz Wifi Network: AP Mode

See instructions below to finalise your device pairing via AP Mode.



Change 'EZ Mode' to 'AP Mode' by clicking in the top right hand corner Ensure your device's Wifi LED is flashing slowly. If it is not, hold down the "POWER" button for 5 seconds or until the Wifi icon begins to flash. Click 'Confirm indicator slowly blink' and 'Next'


	your mobile ce's hotspot	phone to
1. Please co shown below	nnect your phone to v	o the hotspot
<	WLAN	
 Smar 	tLife-XXXX	*()
÷ W	ñ - Gizest	
	ñ - Home	
2. Return to adding devi	this app and cont ces	linue
	Go to Connec	t

Click 'Go Connect' to connect to the device's Hotspot by selecting the network highlighted on the screen in your app, e.g. 'SmartLife- XXXX'



Select the device's Hotspot network and you will be returned to the app. If not, navigate back to the Goldair app. Note- if you get a notification saying 'Internet may not be available' press Dismiss.

Done



Connect with Bluetooth

As an alternative way of connecting your device, you can pair via Bluetooth. Please ensure you have Bluetooth switched on on your mobile phone.

Home *		0
All Devices	Living Room	Master B •••
	Mo device	
•	¢.	Ø

On the Home screen, tap 'Add Device' or the '+' icon.

Ensure your device's Wifi LED is flashing rapidly. If it is not, hold down the "POWER" button for 5 seconds or until the Wifi icon begins to flash.




On the top right, click 'Auto Scan'

The app will now scan for Bluetooth devices.


When your device appears, click on the image.

Choose Wi-Fi and en	ter password
🤶 dlink2	
۵	~
Next	

Choose your 2.4ghz Wifi network and add in the password. Click 'Next'



Operating your Fan from the APP



Operating your Fan from the APP

POWER

Click the Power Icon to turn the Fan ON/OFF

MODE

When the fan is turned on, it will default to Normal mode. Click the relevant icon to move to Natural and Sleep mode.

Normal: The fan will operate a consistent wind at the speed of your choice

Natural: the speed changes every 5 seconds in a cycle from low to medium to high to medium to low to medium to high to medium to low etc.

Sleep: the sleep function first runs at high speed for half an hour, then at the medium speed for half an hour, then at low speed until the fan is switched off.

Oscillation

Turn the Horizontal Switch ON to activate oscillation.

WIND SPEED

When the fan is turned on, move the slider to choose between Speed Level 1, 2 or 3.

Countdown

When the fan is turned on, move the slider to activate the Countdown timer. Choose between 1-24 hours in 1 hour increments.





0

Device OFF

0




Wind Speed Level · 2


Set up Tap-To-Run & Create Smart Scenes


Store your favourite settings or set up automated functions based on conditions in the 'Smart' part of your Goldair app.


Warning- you must remember to turn off any Smart functions prior to leaving the house or going away. We recommend you only operate your Goldair devices when someone is on the premises.

- Tap 'Smart' on the bottom of your mobile phone.
- Tap 'Create Scene' or the '+' icon on the top right.










Review your conditions and tasks on this screen, or choose to add another device or task by clicking the '+' icon.

Click Save to store your settings and your new task will appear on the Smart homepage. Click it to operate your desired task.





As well as setting up automated Tap-to-Run tasks, you can set conditions to operate your devices.

Weather:

Click 'When weather changes' to create a task based on your local outside weather. Choose between temperature, humidity, weather type, sunset/sunrise or wind speed. Select your desired condition and click 'Next'. Click 'Run the device' and choose a device. Preset your desired functions such as Power ON/OFF, temperature, mode and timer as per on the device's functions. Click 'Next'. Review your conditions and click save. Your automation will appear on the main Smart homepage.

Schedule:

Click 'Schedule' to create a task for your device at selected times of the day. Click 'Repeat' to choose days of the week or leave as 'Once' to operate as a one off. Choose your desired time from the scroll bar and click 'Next'. Click 'Run the device' and choose a device. Preset your desired functions such as Power ON/OFF, temperature, mode and timer as per on the device's functions. Click 'Next'. Review your conditions and click save. Your automation will appear on the main Smart homepage.

Status Change


Click 'When device status changes' to create a condition based on any function on your device, for example turning the Power Off when any device function is changed (to act as a child lock)

Voice Control

Once your smart scenes are set up, you can use Amazon Alexa or Google Home Routines to operate the scenes via voice control. Refer to your Amazon or Google Home user guides for instructions on how to pair your routine to smart scenes.

Operating your Device from the APP

Device settings:



Operating your Device from the APP

Share device with family member:

- The person you add will need to have the Goldair APP installed on their phone.
- Enter your family member's details to share device operation with them.
- Tap 'Confirm' to complete the addition.

Remove family member from device:

• Tap 'Share Devices' to delete the number of the person you want to cancel. Tap 'Confirm' to confirm.

NOTE: There can only be one user operating the device at a time. The APP needs to be closed on all other devices to enable the sharing to work.

NOTE: If someone else sets up their phone on the same device without using the 'Device Sharing' the original phone will be disconnected and the device will disappear from the device list.

Group your devices:

Devices within the same group can be controlled simultaneously

- Under 'Create Group' setting, select all devices you wish to group together. Click 'Save'
- Enter a group name of choice. Click Save.

You can now operate all devices within this group simultaneously.

Ungroup your devices:

- Click on to pen icon within device group
- Select 'Dismiss Group'

You have now deleted your group.

Name Enter the name of family me. Profile Photo Image: Comparison of the device Family members can control the device Image: Comparison of the device Country/Region New Zealand Account Mobile number or email Set as administrator Image: Comparison of the device of the dev	Profile Photo Family members can control the device Country/Region New Zealand Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family, Regular members can only operate senes and devices, they are not allowed to add and	Profile Photi Family membe Country/Reg Account Set as admi Once added, yr registered with administrator i the entire family	p rs can control the devic gion New Zeala Mobile number	e and
Family members can control the device Country/Region New Zealand Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family, Regular members can only operate senes and devices, they are not allowed to add and	Family members can control the device Country/Region New Zealand Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family, Reginter all oncess, and ulowed to add and	Family membe Country/Reg Account Set as admi Once added, yr registered with administrator i the entire fami	rs can control the devic gion New Zeala Mobile number	and
Country/Region New Zealand Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate senes and devices, they are not allowed to add and	Country/Region New Zealand Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family, Regurate amembers can only operate senes and devices, they are not allowed to add and	Country/Reg Account Set as admi Once added, yo registered with administrator i the entire fami	gion New Zeala	and
Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	Account Mobile number or email Set as administrator Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	Account Set as admi Once added, yr registered with administrator i the entire fami	Mobile number	
Set as administrator	Set as administrator	Set as admi Once added, yo registered with administrator i the entire fami		or email
Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	Once added, yo registered with administrator i the entire fami	nistrator	O
registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and	registered with administrator i the entire fami		-
			that phone number. Th s granted all access, inc y. Regular members ca	e family cluding removing n only operate

<	Select	Device	Save		
Devices under same group can be controlled simultaneously					
L	My Heater Home Master B	edroom	0		
l	My Heater Home Living R	oom	0		
P	Please enter th	ne group name			
My Heater Group					
Cancel Save					

<	Group Det	ails
Basic information	of the group	
Modify group	name	My Heater Group >
Group position	ı	>
Manage Group	Devices	>
Sharing Group		>
Others		
Feedback		>
	Dismiss gr	oup

How to connect to your Alexa devices


• Download the Goldair App and pair your device.

Note: change the name of the device to an easily identifiable name such as 'Bedroom Fan' or 'Living Room Heater'

Note: Ensure you have downloaded and have configured the Amazon Alexa app. Please see your Alexa device's user manual for instructions.

- On the main page of the Alexa app, click the 'More' icon in the bottom right hand side of the page. Click on 'Skills and Games'
- Click on the search icon in the top right hand corner

Click on the search icon in the top right hand corner







How to connect to your Alexa devices

9:06 1


• Type 'Goldair' in the search bar and click to proceed.

 Click 'Enable to use' and type your phone number/ email address and password and click 'Link Now'

Click 'Authorise' and go back to the Home screen.
 Your devices will now appear and you can operate using voice control.



.....



How to connect to your Alexa devices

SUGGESTED VOICE COMMANDS

Note: Amazon and Google are in control of voice control functionality and terminology. Not all functions available via the controller or APP can be controlled via voice command.

Voice control on your device will allow you to turn ON and OFF and adjust the settings. Suggested voice commands to work with your Alexa device are:

Turning ON/OFF Alexa, turn "Device Name" ON Alexa, turn "Device Name" OFF

Adjust the settings

Alexa, turn "Device Name" to High (omit High with the desired setting or speed)


How to connect to your Google Home devices

Follow the below instructions to connect your device to Google Home.

• Download the Goldair App and pair your device.

Note: change the name of the device to an easily identifiable name such as 'Bedroom Fan' or 'Living Room Heater'


Note: Ensure you have downloaded and have configured the Google Home/Assistant apps. Please see your Google device's user manual for instructions.





• On the main page of the Google Home app, click the '+' icon in the top left hand side of the page.


Click 'Set up device'



How to connect to your Google Home devices

Click 'Works with Google'

.



 Type 'Goldair' in the search bar and click to proceed.



 Type your phone number/ email address and password and click 'Link Now'




How to connect to your Google Home devices

• Click Authorise and all devices from your Goldair App will appear on screen.



- You have the option to add these to a particular room in your home
- When you go back to the Home screen, your devices will now appear and you can operate using voice control.



SUGGESTED VOICE COMMANDS

Note: Amazon and Google are in control of voice control functionality and terminology. Not all functions available via the controller or APP can be controlled via voice command.

Voice control on your device will allow you to turn ON and OFF and adjust the settings. Suggested voice commands to work with your Google device are:

Turning ON/OFF

Ok Google, turn "Device Name" ON Ok Google, turn "Device Name" OFF

Adjust the settings

Ok Google, turn "Device Name" to High (omit High with the desired setting or speed)