

GM2711S Cooler Master 27" Gaming Monitor

User Manual



Table of Contents

Requirements and Safety Notice	1
Important Safety Instructions	3
Cleaning your Monitor	3
Correct Posture to Use the Product	4
Low Blue Light Mode	5
Configuring the Low Blue Light Mode	5
Flicker Free	5
Package Contents	6
Installing the Monitor Arm/Base	7
Adjusting the Monitor	9
Wall Mount Installation Instructions	10
External Control Buttons	11
Main Menu	12
[Picture]	12
[Color]	13
[Audio]	15
[Gaming]	16
[OSD]	17
[System]	18
[Information]	20
Specifications	21
Supported Timing	22
[PC Timing]	22
[Video Timing]	23
Product Outline Dimensions	24

Requirements and Safety Notice

FCC Safety Notice

This product has been tested and determined to be meeting the limits for a Class B digital device and in compliance with Part 15 of the FCC Regulations. These requirements are set to reasonably protect the home installation environment from hazardous interference. This product will generate, use and emit radio frequency energy. Failure to install and use it as instructed may cause hazardous interference to radio communication. However, we cannot guarantee zero interference for certain installation methods. If this product has caused hazardous interference to radio or TV reception (turn on or turn off this product to for confirmation), the user may try to make adjustment with the following methods:

- Re-adjust the angle and position of the reception antenna.
- Increase the distance between the device and receiver.
- Do not use the power sockets of the device and receiver together.
- If assistance is needed, contact the distributor or a professional radio/TV technician.

CE Compliance Statement

Cooler Master Technology Inc. hereby declares that the monitor conforms to the following key standards and other related provisions:

EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, RoHS Directive 2011/65/EU and Directive 2009/125/EC establishing a framework for the setting of eco-design requirements for energy-related products.

Note:

To prevent damage of the monitor, do not lift the monitor from the support base.

Note: Shielded cable

To comply with the EMC requirements, a shielded cable must be used for connection between this product and any other computer device.

Note:

The monitor is exclusively used in the video and image display of information acquired from electronic devices.

Note: Peripherals

Only a peripheral device (I/O device, terminal, printer, etc.) that has been certified and met the Class B limits can be sold together with this product. If this product is used together with any other uncertified peripheral device, it may cause interference to radio and TV reception.

Warning

Any change or modification not approved by the original manufacturer may lead to the user losing the right to operate this product. Such authorization is given by the Federal Communications Commission.

Requirements for Use

This product meets the limits under Part 15 of the FCC Regulations. When operating this product, please meet the following two requirements: (1) This product may not generate hazardous interference; and (2) This product must accept any interference signal received, including interference that is likely to lead to unexpected operation.

The following local Manufacturer/Importer is responsible for this declaration.

Product Name: LCD Monitor Model No: GM2711S Company Name: North America - CMI USA, Inc. Address: 1 N Indian Hill Blvd Suite 200, Claremont, CA 91711, USA Contact Person: Cooler Master Representative Phone No: +1-888-624-5099

Note: Canadian users

This Class B digital device complies with Canadian ICES-003 specifications.

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Disposal of Waste Equipment by Home Users in EU



If this symbol appears on a product and its package, it indicates that the product cannot be disposed of together with other household waste. You have to deliver the waste equipment to a designated recycling center for recycling of waste electrical and electronic equipment. Proper sorting and recycling of resources during the disposal of waste equipment is helpful for protecting natural resources and ensuring that resource recycling can protect human health and environment. For detailed information about recycling centers where waste equipment is disposed of, contact the local municipal office, cleaning service or the store where the purchased product is found.

电子电气产品有害物质限制使用标识要求

本产品有害物质的名称及含量标识如下表:

	有害物质						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴联苯醚 (PBDE)	
外壳	0	0	0	0	0	0	
电路板组件*	×	0	0	0	0	0	
电源线/适配器	×	0	0	0	0	0	
外部信号连接线	×	0	0	0	0	0	
液晶面板	×	0	0	0	0	0	

本表格依据 SJ/T 11364 的规定编制。

- *: 电路板组件包括印刷电路板及其构成的零部件,如电阻、电容、 集成电路、连接器等
- ○: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定 的限量要求以下。
- ×: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572 规定的限量要求。

限用物質含有情況標示聲明書

設備名稱:浴 Equipment name	返晶顯示器	顯示器型號(型式):GM2711S Type designation (Type)				
		限用物質及其化學符號 Restricted substances and its chemical symbols				
單元 Unit	鉛Lead (Pb)	汞Mercury (Hg)	鎬Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁺⁶)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
支架/外殻	0	0	0	0	0	0
印刷電路板	-	0	0	0	0	0
玻璃面板		0	0	0	0	0
電纜/電線/連 接線	_	0	0	0	0	0
電源設備/外接 電源供應器	_	0	0	0	0	0
備考 1. "超出 0.1 wt %" 及 "超出 0.01 wt %" 係指限用物質之百分比含量超出百分比含量基準值。 Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.						
備考 2. *〇" 係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2 : *0" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.						
備考 3. ["] -" Note 3 : The "-" ind	係指該項M licates that the re	艮用物質為排 stricted substance	除項目。 corresponds to the ex	cemption.		

注意!使用過度恐傷害視力

使用30分鐘請休息10分鐘;2歲以下幼兒不看螢幕,2歲以上每天看螢幕不要超過1小時。

Important Safety Instructions

Please read the following instructions carefully.

1. Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage it.

2. Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.

3. Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature

4. Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to 140°F). Storing the LCD monitor outside this range may result in permanent damage.

5. Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:

- Monitor to PC signal cable is frayed or damaged.
- Liquid spills onto the LCD monitor or the monitor is exposed to rain.
- The LCD monitor or case is damaged.

Cleaning your Monitor

Please carefully follow these guidelines when cleaning the monitor:

- Always unplug the monitor before cleaning.
- Use a soft cloth to wipe the cabinet front and sides.
- Do not spray water or a cleaning agent that contains alcohol or solvent on the screen. If you spill liquid on the screen, gently wipe the screen with a soft, dry microfiber cloth and then clean the screen with a lint roller.
- Cleaning the screen with a microfiber cloth and lint roller is recommended.
- Do not adhere anything onto the screen as this may damage the screen and/or affect its functioning.

NOTE: When using a lint roller:

1. Peel off the protective film from the surface of the roller.

2. Roll the roller over the dirty areas in one direction until the dirt is removed.

*Once the sheet is dirty or no longer sticky, peel it off and use a new one.

3. When finished, place the roller back into the original packaging to ensure it does not get dust on it.

NOTE: When using a microfiber cloth:

- 1. Make sure the microfiber cloth is clean.
- 2. Wipe the dirty areas in one direction until the dirt is removed.

*If there is still residual dirt, use other clean section of the microfiber cloth to wipe the dirt.

3. When finished, rinse the microfiber cloth with detergent and dry the microfiber cloth completely.

4. Place the microfiber cloth back into the original packaging to ensure it does not get dust on it.

Correct Posture to Use the Product

Use the product in the correct posture as follows:

- Straighten your back.
- Allow a distance of 45 to 50 cm between your eyes and the screen, and look slightly downward at the screen.
- Keep your eyes directly in front of the screen.
- Adjust the angle so light does not reflect on the screen.
- Keep your forearms perpendicular to your upper arms and level with the back of your hands.
- Keep your elbows at about a right angle.
- Adjust the height of the product so you can keep your knees bent at 90 degrees or more, your heels attached to the floor, and your arms lower than your heart.
- Do eye exercises or blink frequently to relieve eye fatigue.
- Use the product at the recommended resolution and frequency. Failure to do so may cause your eyesight to deteriorate.
- Looking at the screen too close for an extended period of time can deteriorate your eyesight.
- Rest your eyes for more than 5 minutes or look at distant objects for every 1 hour of product use.

Low Blue Light Mode

This display features **Low Blue Light** capabilities which help reduces the blue light emissions. When the **Blue Light Reduction** is set at level 5, it will also be compliant with TÜV Rheinland's low blue light certification requirements.

When **Blue Light Reduction** is set to level 1/2/3/4/5, the wavelength of the blue light that is between 400 nm and 500 nm will be reduced, which can provide optimal image quality while helping relax eye strain. You can adjust the low blue light settings in the **Picture** sub-menu of the OSD menu.

Configuring the Low Blue Light Mode

- 1. Press the joystick to open the OSD menu.
- 2. Toggle the joystick to navigate the OSD menu.
- 3. Select the Picture sub-menu.
- 4. Select Blue Light Reduction in the Picture sub-menu.
- 5. Toggle the joystick left / up / down to configure the display's low blue light settings.

Flicker Free

Flicker Free technology reduces screen flickering for a more comfortable viewing experience.

Package Contents



Installing the Monitor Arm/Base























Adjusting the Monitor

- For the best results, it is recommended to look directly at the front of the monitor and make any adjustments as necessary.
- Ensure that the monitor is mounted upright on the stand base.
- When adjusting the monitor viewing angles, avoid touching the screen and hold the stand in order to prevent it from falling over.



Screen Tilt	-5° – 25°
Screen Swivel	-45° – 45°
Height Adjustable	0 – 130 mm
Pivot	-90° – 90°

Wall Mount Installation Instructions



3

4







VESA: 100 x 100 mm Screws: M4 x 10 mm





External Control Buttons



(1) Joystick/Power button

Short press the joystick to turn the monitor on.

Long press the joystick for three seconds to turn the monitor off.

Short press joystick or push it right to activate the OSD menu.

When the OSD menu is activated:

- Push the joystick up/down/left/right to navigate and adjust settings.
- Short press the joystick or push it right to enter a sub-menu.
- Push the joystick left to go back to the previous menu level.
- Push the joystick left to exit the OSD menu.

2 Power LED

- Blue: On
- Orange: Power Saving

Main Menu [Picture]



		1920 x 1080 60H	z		
Picture Picture Color Audio Audio Color Audio Color Audio Color Sustem Color Audio Color Audio Color Audio Color Audio Color Audio Color Audio Color Audio Color Audio Color Color Audio Color Color Audio Color Color Audio Color C	HDMI Range		(Auto	,
	Back	Enter	Move		

- Enter the **Picture** menu to configure image settings.
 - Picture Mode: Enter the Picture Mode menu to adjust different picture modes.
 - **a. Game:** Enables the game screen mode.
 - **b. FPS:** Provides the optimal setting for FPS (First Person Shooter) games to increase the visibility in dark scenes.
 - c. RPG: Provides the optimal setting for RPG (Role-Playing Games).
 - d. Web: Provides the optimal setting for web browsing.
 - e. Custom: Provides customized options for user experience.
 - f. Standard: Enables the standard screen mode.
 - Brightness: Adjusts the backlight brightness level of the monitor (0 to 100).
 - Contrast: Adjusts the contrast level of the monitor (0 to 100).
 - Sharpness: Adjusts the sharpness of the monitor display (Off / 1 to 10).
 - Black Level: Adjusts the backlight brightness level to illuminate dark areas without overexposing brighter areas (0 to 10).
 - Blue Light Reduction: Reduces the amount of blue light emitted by the monitor (Off / 1 to 5).
 - Aspect Ratio: Adjusts the aspect ratio of the monitor (Full / Aspect).
 NOTE: When the input source is interlaced, the aspect ratio setting is disabled.
 NOTE: If the aspect ratio setting is disabled, its default is set to Full.
 - HDMI Range: Adjusts the quantization range of the monitor (Auto / Full / Limited).

[Color]

1920 x 1080 60Hz				
Picture	ColorTemp.	•	6500K	►
Color	Red			100
Audio	Green			100
Gaming	Blue			100
OSD OSD	Enhanced Color	•	Custom	►
System	Enhanced Contrast	•	Level 1	►
Information	Saturation	•	Off	►
	Back OEnt	er 💽	Move	

		1920 x 1080 60H	łz		
Picture	Gamma		•	2.2	•
Color	HDR		•	Auto	•
Audio					
Gaming					
OSD OSD					
System					
Information					
	Back	Enter		Move	

- Enter the Color menu to adjust color settings.
 - ColorTemp.: Adjusts the color temperature of the monitor (6500K / 7200K / 9300K / User). User allows you to adjust the Red, Green, and Blue values individually (0 to 100).
 - Enhanced Color: Adjusts the tint of the image on the monitor (Off / Custom / 1 to 9).
 - Enhanced Contrast: Adjusts the tonal gradation of the image on the monitor, which makes light areas become lighter and dark areas become darker (Off / Level 1 to Level 5).
 - Saturation: Adjusts the color intensity of the image on the monitor (Off / 1 to 10).
 - **Gamma:** Adjusts the gamma curve of the monitor (2.0 / 2.2).
 - HDR: Configures the HDR function of the monitor (Off / Auto).

[Audio]

	1920 x	1080 60Hz		
Disture	Voluera			10
Color	Custom button	•	Mic Mute	•
Audio	Mic	•	On	►
Gaming				
System				
	Back	Enter 💽	Move	

- Enter the **Audio** menu to configure the display's audio settings.
 - Volume: Adjusts the volume of the monitor (0 to 30).
 - Custom button: Assigns a hotkey function to your headphone's button (Mic Mute / Mute / Custom).
 - Mic: Enables/Disables the microphone (On / Mute).
 NOTE: To use a microphone, ensure that the monitor has been connected to the output device via USB-B cable.

[Gaming]



- Enter the Gaming menu to adjust gaming settings.
 - Dark Contrast Enhancement: Configures the dark contrast function which brightens the dark areas of the image on the monitor (Off / Level 1 / Level 2 / Auto (Level 1) / Auto (Level 2)).
 - Over Drive: Configures the over drive function which makes the display's pixels transition colors faster (Off / Level 1 / Level 2 / Level 3 / Burst).
 - MPRT: Enables/Disables the MPRT (Moving Picture Response Time) function which reduces picture motion blur (Off / Level 1 / Level 2 / Level 3). **NOTE:** The MPRT function is only available when the input source features refresh rates of 120Hz or above.

NOTE: The MPRT and Adaptive-Sync functions are mutually exclusive.

■ Adaptive-Sync: Enables/Disables the adaptive sync function which synchronizes the output frames of the GPU to the refresh rate of the monitor (On / Off). NOTE: The Adaptive-Sync function is only available via the Display Port input.

[OSD]

		1920 x 1080 60	Ηz		
Picture	Time Out		•	30	•
Color	Language		•	English	►
Audio	Rotate		•	0	►
Gaming					
System					
Information					
	Back	Enter	0	Move	

- Enter the **OSD** menu to configure the display's OSD settings.
 - Time Out: Sets the idle time before the OSD menu closes (15 seconds / 30 seconds / 45 seconds / 60 seconds).
 - Language: Sets the language to English, Japanese, French, German, Spanish, Italian, Finnish, Russian, Vietnamese, Korean, Traditional Chinese, or Simplified Chinese.
 - Rotate: Adjusts the image rotation of the monitor (0° / 90° / 270°).

[System]



	1920 x	1080 60Hz		
Picture Color Audio Caming Gaming OSD System	System Update	١	Cancel	Þ
Information	Back O	Enter ON	Nove	

- Enter the **System** menu to configure system settings:
 - Power Save: Enables the monitor to switch to power saving mode when there is no signal (Off / Level 1 / Level 2).
 NOTE: When Level 1 is selected, the power LED turns off when the monitor is on standby. When Level 2 is selected, the power LED lights up orange when the monitor is on standby, and the monitor turns off when left on standby for one minute.
 - Signal Input: Sets the input behavior when the video signal is lost (Auto (Fast) / Auto / Manual).
 - Quick Boot: Enables/Disables the quick boot function which speeds up the monitor's boot-up process (On / Off).
 - Power LED: Adjusts the brightness of the monitor's power LED (Off / Level 1 to Level 5).
 - DDC/CI: Enables/Disables the DDC/CI function of the monitor (On / Off).
 NOTE: Enable the Quick Boot function to ensure stability of the DDC/CI command.
 - HDMI-CEC: Enables/Disables the HDMI-CEC function of the monitor (On / Off). NOTE: When the CEC function is enabled, the Quick Boot function will automatically be enabled.
 - **Reset:** Resets the OSD menu to its default settings (Apply / Cancel).
 - System Update: Updates the firmware of the monitor (Apply / Cancel).
 NOTE: When the firmware is updating, the following image will be displayed on the monitor to show the firmware update's progress status:



[Information]

		1920 x 1080 60H	Iz	
	î			
Picture	Model		GM2711S	
Color	SW version		01.00	
Audio	Input		HDMI 2	
Gaming	Resolution		1920 x 1080	
OSD OSD	Frame Rate		60Hz	
System				
Information				
	Back	Enter	Move	

- Enter the Information menu to view the display's information.
 - Model: Shows the model number of the monitor.
 - **SW version:** Shows the software version of the monitor.
 - Input: Shows the video input source currently being used by the monitor.
 - **Resolution:** Shows the current resolution of the monitor.
 - **Frame Rate:** Shows the current frame rate of the monitor.

Specifications

	Size	27"		
	Pixel pitch	0.2331 (H) x 0.2331 (V) mm		
	Brightness	350nits (Typ.)		
	Contrast ratio (Typ.)	900:1 (Typ.)		
	Viewing angle (R/L/U/D)	89/89/89 degrees		
	Response time (ms)	5ms (G to G)		
Display colors		8bit, 16.7 million colors		
Max. display frequency (Resolution H*V/Fv)		2560 x 1440@180Hz (DP) 2560 x 1440@144Hz (HDMI)		
	Power On	55.2W (Typical)		
Power consumption	Standby	≤0.5W		
	Power off	≤0.3W		
Input/output connector		DP x 1 HDMI x 2 USB-A x 1 USB-B x 1 Line out x 1 Phone jack x 1		
Input video signal		HDMI 2.0 & Display Port 1.4 Signal Supported		
Speakers		2W x 2		
Audio effect		Audio output is LPCM supported into sample rate 32kHz,44.1kHz, 48kHz and bit rate@24bit		
Power supply		AC 100~240V @50/60Hz		
Environmental conditions		Operating temperature: 0°C – 40°C; Storage temperature: -20°C – 60°C; Operating humidity: 10% – 80% RH		
Machine size (L x W x H)		614.5 x 204.3 x 534.4 mm (with arm/base) 614.5 x 58.5 x 368.2 mm (without arm/base)		
Box dimension (L x W x H	1)	699 x145 x 484 mm		
Weight (Net)		6.58 kg/Unit (with arm/base) 4.18 kg/Unit (without arm/base)		
Machine specifications		Tilt: -5° to 25°		

Compliance

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

*Specifications are subject to change without notice.

If you have any question regarding use of the monitor, please visit: https://www.coolermaster.com/warranty

Supported Timing

[PC Timing]

	Posolution	Horizontal	Vortical	Pixel	Port	
Mode	(active dot)	(KHz)	(Hz)	Clock (MHz)	HDMI	DP
VESA	640 x 480@60Hz	31.47	59.94	25.18	0	0
	800 x 600@60Hz	37.88	60.32	40.00	0	0
	1024 x 768@60Hz	48.36	60.00	65.00	0	0
	1280 x 1024@60Hz	63.98	60.02	108.00	0	0
	1600 x 1200@60Hz	75.00	60.00	162.00	0	0
	1920 x 1200@60RB	74.04	59.95	154.00	0	0
	1680 x 1050@60RB	64.67	59.88	119.00	0	0
	1680 x 1050@60Hz	65.29	59.95	146.25	0	0
	1920 x 1080@60Hz	67.50	60.00	148.50	0	0
Xbox	848 x 480@60Hz	31.02	60.00	33.75	0	0
	1280 x 720@60Hz	44.96	59.94	74.18	0	0
	1280 x 768@60Hz	47.78	59.87	79.50	0	0
	1360 x 768@60Hz	47.71	60.02	85.50	0	0
	1920 x 1080@60Hz	66.59	59.93	138.50	0	0
VESA	1600 x 900@60RB	60.00	60.00	108.00	0	0
HD	1920 x 1080@120RB	137.26	119.98	285.50	0	0
VESA CVT	2560 x 1440@60RB	88.79	59.95	241.50	0	0
	2048 x 1152@60RB	70.99	59.91	156.75	0	0
	2048 x 1152@60Hz	71.58	59.90	197.00	0	0
Original	2560 x 1440@120Hz	183.00	120.00	497.75	0	0
	2560 x 1440@144Hz	222.20	144.01	595.50	X	0
	2560 x 1440@144Hz (2)	222.15	143.97	592.25	0	0
VESA	2560 x 1440@144RB2	222.19	144.00	586.59	0	0
CVT	RBv1 1920 x 1080@180Hz	212.02	179.98	441.00	0	0
Original	2560 x 1440@180Hz	262.98	180.00	694.27	X	0

[Video Timing]

Video ID code	Formats	Aspect Ratio	Field Rate (Hz)	Horizontal (KHz)	Vertical (Hz)	Pixel Clock (MHz)	Port
1	640 x 480p	4:3	60.00	31.50	60.00	25.20	Supports HDMI only.
			59.94	31.47	59.94	25.18	Supports HDMI only.
2	720 x 480p	4:3	60.00	31.50	60.00	27.03	Supports HDMI only.
			59.94	31.47	59.94	27.00	Supports HDMI only.
4	1280 x 720p	16:9	60.00	45.00	60.00	74.25	Supports HDMI only.
			59.94	44.96	59.94	74.18	Supports HDMI only.
5	1920 x 1080i	16:9	60.00	33.75	60.00	74.25	Supports HDMI only.
			59.94	33.72	59.94	74.18	Supports HDMI only.
6	1440 x 480i	4:3	60.00	15.75	60.00	27.03	Supports HDMI only.
			59.94	15.73	59.94	27.00	Supports HDMI only.
16	1920 x 1080p	16:9	60.00	67.50	60.00	148.50	Supports HDMI only.
			59.94	67.43	59.94	148.35	Supports HDMI only.
47	1280 x 720p	16:9	120.00	90.00	120.00	148.50	Supports HDMI only.
48	720 x 480p	4:3	120.00	62.94	120.00	54.00	Supports HDMI only.
63	1920 x 1080p	16:9	120.00	135.00	120.00	297.00	Supports HDMI only.
90	2560 x 1080p	64:27	60.00	66.00	60.00	198.00	Supports HDMI only.

Product Outline Dimensions

