



MINIMIKADO

MMIK S UL | SET UP

CONTENTS





1	Shade.	1 un.
2	Canopy.	1 un.
3	Electrical cable &	1 un.
	Lampholder.	
4	Steel cable.	3 un.
5	Stoppers.	3 un.
6	Level	1 un.
7	Allen key N°2	1 un.

TECHNICAL SPECIFICATIONS

Recommended bulb

120V E26 Base



CFL Spiral 1 x 18 W max. or



LED A15 1 x 5 W max. or

120V GU24 Base



CFL Spiral 1 x 18 W max. or

120-277V



WEIGHT

Net Weight 4,6 Lb Gross Weight 13,9 Lb

•••••

WARNINGS

Before assembly and installing this product, carefully read the


Turn off the mains before installing the lamp. Dry location only. This lamp is for indoor use only.

WOOD VENEER: Since wood is a natural material, a gradual change in tone may occur over time. Furthermore, if the lamps have been purchased at different times, there will be differences in colour and tone, particularly in light coloured veneers. Luziferlamps S.L. will not be held responsible for this.



ASSEMBLY INSTRUCTIONS


1.



1. The canopy is made up of a back plate with the electrical connections on it and a front cover.

Feed the electrical wires (C) from the mains through the electrical back plate (B), fix back plate to the junction box (A) with the most adequate screws (D) (not supplied) and prepare to wire up.

2.




2. CONNECTION

Turn off the mains before installing the lamp. Connect the lamp to the mains as follows.


You should have a three wire cable coming from the mains, N, L and GND (\pm) Connect these to the cables of the same colour coming from the lamp.

3.



3. Install the bulb.






4. Shade mounting.




ASSEMBLY INSTRUCTIONS



5. Adjust the height of your lamp by raising or lowering the stainless steel adjustment cable (E) and cut off the excess. For added security put on the stopper (F) and tighten it.

Note: if you want to roll up the excess stainless steel wire instead of cutting it off, do so but make sure that this wire cannot touch any of the electrical connections in the canopy.

Level the lamp with the level supplied, adjusting the height of the steel cables if necessary the suspenders.



6. Tighten the screw on the electrical cable trap (G).

Once all your wiring is complete raise the canopy and screw on the canopy support nut (H) that holds the cover in place.

7. Turn on the mains again.

© Luziferlamps, S.L. Valencia, Spain. 2018. All rights reserved. www.import-ent.com support@import-ent.com

GENERAL CARE INSTRUCTIONS

REV.06-2018

D88_078

You have just purchased an original handmade product by LZF. Your lamp is made out FSC® certified natural wood veneer treated with our patented finish, Timberlite®. This treatment both protects and safeguards the wood veneer against breakages.

Depending on the type of lamp use a feather duster, soft cleaning cloth or damp cloth for cleaning. On our more delicate shades, like those made from wood strips, a feather duster or an air blower is preferable. In our more solid shades a damp cloth may be used.

Clean only the flat surface of the veneer with the cloth, and please avoid any moisture contact along the edge of the veneer.

The acrylic diffusers on your lamp can be cleaned with a regular window cleaning spray and a soft cloth. Do not use solvents of any kind.

Bulbs not included, unless indicated. We recommend using energy-saving light bulbs, like the CFL or LED bulbs. Please refer to the instruction manual or visit our website www.lzf-lamps.com to make sure you are using the best bulb for your type of lamp.

Precautions

Luminaire for indoor use only.

Avoid direct sunlight, strong indirect sunlight and moisture on your lamp. Unplug the lamp before cleaning or changing the light bulb. Instalation of the fixture should only be performed by qualified electrical personnel or by the LZF service department