

# User Manual

Léger Mirror Light Sconce





WWW.OZARKE.COM

Thank you for shopping with Ozarké, we really appreciate your business. Our goal is to provide an excellent customer service before, during and after delivery. We've included a guide on how to install this light, should you require additional assistance please feel free to email us and one of our customer service reps will reach out to assist you.

You can reach us via email at [info@ozarke.com](mailto:info@ozarke.com) or via phone at +1-(800) 604-7271

## BEFORE YOU GET STARTED

**When working with electrical wiring, follow these safety instructions to prevent injury or damage:**

1. Turn off the power: Before starting any work, turn off the power to the area you will be working in.
2. Use appropriate tools: Only use tools designed for electrical work and in good condition.
3. Wear protective gear: Wear safety glasses, gloves, and other protective gear as necessary.
4. Test for power: Use a non-contact voltage tester to check for electrical current before touching any wires.
5. Avoid wet conditions: Do not work with electrical wiring in wet or damp conditions.
6. Keep a safe distance: Stay away from exposed wires or electrical components.
7. Seek professional help: Consult a qualified electrician if you are unsure about any aspect of electrical wiring or encounter any problems.



## WARNING!

1. Do not use the power supply beyond the specified range (100-240V).
2. Avoid scratching the surface and wires of the light during installation.
3. Do not install the light outdoors.
4. The light should not be close to corrosive chemical objects or gases.
5. It should not be washed with water. It can only be wiped with a clean soft cloth.



### Assembly Inventory:

*Please check the assembly inventory. If you find anything missing reach out to our customer service team*

A- 1 x LED Light assembled (see image 1.1)

*Includes light bar, wires*

B- 1 x Wall Bracket (see image 2.1)

D- 4 x Regular Screws(silver or black color)

E- 4 x Plastic Drywall Anchor

### Tools needed (not included):

1 x Screw Driver

1 x Electric Drill




Image 1.1



Image 2.1



**Step 1:**

Use a pencil or a pen to mark the drilling position. You can use the silver bracket to mark the position of the light. It is very important to ensure you account for the wiring position on your wall or ceiling.

**Step 2:**

Using a drill, drill holes into the wall where you marked in step 1.

**Step 3:**

Insert drywall anchors into each hole. Don't damage or force the anchor in the hole. If the hole is small, try to make the hole(s) bigger.

**Step 4:**

Screw the silver bracket to the wall using a screw driver. Don't attach the lamp. This step to be completed after wiring.

Now that you have setup the position of the lamp, it is time to wire the lamp.

**Step 5:** (skip this step if you ordered the plug-in version)

**Black Wire:** Live, **White wire:** Neutral, **Yellow wire:** Ground

Connect the lamp wires to the wall wires, and tuck inside the lamp or inside the wall.

**Step 7:**

Attach the wall lamp to the silver bracket using the provided screws.

Now you may turn your electrical power back on and test the lamp.



Please note the remote control comes with the dimmable version only

1- Please Install two AAA batteries. Once you have installed the batteries, point the remote at the light fixture and press the "On" button the light will come on. The remote should connect automatically once the batteries are installed (If the remote does not connect see step 2)

2- To connect the remote to the lamp, it must be done within the first 5 seconds after you power the fixture on, press the "Connect" button until the fixture flashes.

3- Once the light is on, use the "+" and "-" buttons on the remote to adjust the brightness. Pressing "+" will increase the brightness, while "-" will decrease it.

4- Once the light is on, use the "k+" and "k-" buttons on the remote to adjust the color temperature. Pressing "k+" will increase the temperature while "k-" will decrease it. Increasing the temperature will make the emitting color warm and decreasing the temperature will make the emitting color cold.

Helpful information:

The bottom 5 buttons represent the following:

- 1- Adjust brightness
- 2- Dims the light
- 3- Warm white (4000K) option
- 4- Warm (3000K) option
- 5- Cold White (6000K) option

