



Owner's Manual EN

**DEM UPGRADE HEAD UNIT FOR  
2014+ HARLEY DAVIDSON® MOTORCYCLES**



**SOUNDSTREAM**  
TECHNOLOGIES

Bluetooth

**X300**  
WATT  
4CH. AMPLIFIER



**HDHU.14+**

# Contents

Safety First	
Safety Definitions	2
Pre-Riding	
Checklist	3
Care and cleaning	3
Screen	3
Appearance	3
Accessories & Installation	4
Installation	5
Panel Description	6
Wiring	7
Harness	8
Operation	
Main menu	9
Setting	9
Apple CarPlay®/Android Auto®	12
Radio operation	13
USB operation	13
Bluetooth Music	14
Bluetooth Phone	15
Specification	17
Troubleshooting	18
FCC Notes	19

# Safety First

## Safety Definitions

Statements in this manual preceded by the following words are of particular significance:

### ▲WARNING

**WARNING indicates a potentially hazardous situation that could result in death or severe injury if not avoided.**

### ▲WARNING

**Set volume levels and other controls on audio and electronic devices before riding. Distractions can lead to loss of control, resulting in death or serious injury.**

### ▲WARNING

**Do not select a volume level that blocks out traffic noise or interrupts the concentration necessary for the safe operation of the Motorcycle. Distractions or a volume level that blocks our traffic noise could cause loss of control resulting in death or severe injury.**

### Note

Pay attention while riding, keeping your eyes and clear mind on the road. Some features are locked out to prevent distraction, limited in capability while the Motorcycle is in motion. Even a part is available, donot allow it to distract you from operating your Motorcycle safely.

For safety, program the system when stopped. Perform system setup and get familiar with the controls and features of the infotainment system before operating the Motorcycle on the road.

This system cannot warn about the safety of an area, bad road conditions, and availability of emergency services.

Use this radio only in locations where it is safe to do.

# Before You Ride....

## Checklist

Configure the system with your personal preferences before riding to use features and minimize distractions while on the road entirely.

1. Set brightness, background.
2. Configure presets.
3. Adjust audio settings like EQ, volume, fade, balance etc. before riding.
4. Pair, connect and set up phone features through Bluetooth.
5. Connect USB devices for Apple CarPlay® or Android Auto®.
6. Select station or media.

## CARE AND CLEANING

Use only **HDHU.14+** recommended products and methods to keep the radio, speakers, and other audio system components clean and in good condition.


Do not use any abrasives, polishes, or rubbing compounds to clean the screen or other components. Do not use any ammonia-based cleaners on the net. The use of other products or methods may cause damage to components.

### Screen:


Do not use any chemical cleaners or chemical-containing wipes or cloths. These can cause damage to the screen surface.

Gently clean the display glass surface with a clean, dry microfiber cloth. Before cleaning, it is suggested to remove any visible dust, dirt, sand particles with a gentle compressed air stream.


# Appearance



Front




Top




Back

# ***Accessories and Installation***



Harness Included


## ***Installation***




***Use OEM head unit mounting locations & original screws***

# Installation

Note: Reinstall the OEM bracket after head unit installation




# Installation



- 1 USB Fakra Connector**  
Connect the OEM USB cable to the USB connector for playback Android smartphone, iPhone
- 2 AM/FM Radio Connector**  
Connect the Radio Antenna from HD Motorcycle.
- 3 External Microphone Connector**  
Connect the External Microphone.  
(Used for Voice Command Function)

# Panel Description



## 1 Apple CarPlay® / Android Auto®

Press to enter CarPlay® / Android Auto® directly (When the iPhone/Android phone is connected).

## 2 SIRI Button Voice Recognition

Press to enter CarPlay® / Android Auto® directly

(When the iPhone/Android phone is connected).

## 3 Power / Mute

- When the power is off, press to power on.
- When the unit is working, short pressing for Mute, press again for unmute.
- Pressing and hold to turn the source unit power off.

## 4 Home button

- Press to toggle between the home screen and active media.
- Available selections: Radio, Apple CarPlay® / Android Auto®, BT Music, BT Phone, USB, Settings.


## 5 Volume + (Volume +)

- Press to increase the volume value.

## 6 Volume - (Volume -)

- Press to decrease the volume value.


# Wiring



# ***Included Harness***

Harness : Connect to Motorcycle:

Connect to HDHU.14+ (Headunit):



**Note: The Handlebar Control Module is Not Included**



# Main Menu



HDHU.14+ is a headunit for Motorcycle with the following functions:

Apple CarPlay®, Android Auto®, Radio, USB, BT Music, Phone.

Touch the corresponding Mode icon to enter playing mode. The Mode icon in gray means the corresponding function is not ready, or the proper device has not been connected.



## Hidden soft button bar:

A hidden pop-up soft button bar is located at the bottom. Touch the icon  to show the soft button bar. Touch the  to hidden.



Dimming, to change Daylight or Night (If illumination detect is OFF in Display Setting)



Setup to enter the Settings Menu.




Bluetooth pairing.



EQ, to enter the Equalizer setting menu.

# Settings

Touch the  icon to enter the Setup menu. The Setup menu is included System Settings, Display Settings, Audio & EQ Settings, Bluetooth Settings.



## System Settings :

The System Settings allow the user to set up the Language, Date & Time, Key Beep, Factory Reset, and About




## Language :



## Date & Time:

To setting Time display format (12H or 24H), setting the date and time



# Settings

## Beep Tone: On / Off

To set the touch button beep tone is On or Off.


## Factory Setting:

To default the default factory settings:



## About:

To display the HDHU.14+ hardware and firmware version.



## Display setting:

Below is the Display setting menu; users can select Lighting Detect, Daylight Dimming Level, Night Dimming Level, Illumination, and Wallpaper.




Lighting Detect: On/Off

Daylight Dimming Level: 8 – 15



Night Dimming Level: 0 – 8

## Illumination



**Led Auto:** On/Off.

**ON:** The Led color will change automatically.

**OFF:** You press the button  or  select desired color.

**Color:** White / Red / Yellow /Blue / Green / Purple / Light Green


## Wallpaper:

Users can select the preset wallpaper or select preferred pictures in the USB driver as the wallpaper.



Touch the corresponding picture to select the preferred background.

Touch "+", "the head unit will search the USB photo file for wallpaper. Select a picture and touch OK to add the wallpaper.

 Select another picture for replacing the current wallpaper.

# Settings

## Audio & EQ Setting

Below shown is the Audio settings menu.



### Balance/Fader:

Touch the + or – of Balance/Fade to tune for the driver and passenger preference.

The value of Balance (Left 12 – Right 12) and Fade (Front 12 – Rear 12)

Touch Reset to set both Balance and Fade to zero



**Subwoofer Output:** On/Off


**Subwoofer Filter:** 50Hz, 80Hz,120Hz,160Hz

**Subwoofer Level:** -10 ~ +10

**10- Band Equalizer:**

10 - band of EQ tuning, slide the EQ bar to tune each band frequency level according to user preference.

Touch Reset button to sell all Band to zero.



Or user can touch "<" or ">" at the bottom to select the following preset EQ:  
Off, Soft Rock, Pop, Electric, Jazz, EQ Custom.

## Bluetooth Settings :

Touch the Bluetooth Settings from the setting menu will be shown below:



**Connection:** On/Off (Select Bluetooth connections On or Off).

**Pairing:** To start the pairing.




**Device Name:** Shown the connected Phone or device name.

**Clear Records:** To clear the device list records.


# Apple CarPlay® & Android Auto®

## Apple CarPlay®:

Plug the iPhone (iPhone 5 or later models, and IOS 7.1 or above) through the lightning cable to the USB port of the source unit. The iPhone will be shown the "CarPlay." The source unit will enter the CarPlay interface, the APP that supports the CarPlay feature will be displayed on the source unit. Touch the corresponding APP can operate.



## Siri:


In CarPlay® mode, the user can talk to SIRI to Control the CarPlay® functions. Press  to start the SIRI function, touch the button for 2 seconds or the iPhone's HOME button. Now you can talk to Siri about

playing music; I am going...

Note: For the SIRI function in the source unit, the

The microphone must be connected.

In CarPlay® mode, touch the "Home" button or

 icon to go back to the main Menu of the source unit.

## Android Auto®:

Android Auto® enables you to use functions of your Android device convenient for driving. You can easily access route guidance, make calls, listen to music, etc. For details about

Android Auto®, visit

<https://www.android.com/auto>

or <https://support.google.com/androidauto>

## Compatible Android devices

You can use Android Auto with Android devices of Android version 5.0 or later.

Note: Android Auto may not be available on all devices and is unavailable in all countries or regions.


## Operation:

1. Connect an Android device via a USB terminal. To use the hands-free function, connect the Android device via Bluetooth. When an Android device compatible with Android Auto is connected to a USB terminal, the device is connected via Bluetooth automatically, and the Bluetooth smartphone currently connected is disconnected.

2. Unlock your Android device

3. To enter Android Auto mode, touch the Android Auto icon on the head unit screen. You can perform the operations of the Apps of the connected Android device.

4. In the Android Auto model, touch "Home" to the head unit main menu.



# Radio

Touch "Radio" in the main Menu to enter the radio interface.



Touch "FM" can change between FM1>FM2>FM3.



Touch "AM" can change between AM1>AM2.



Touch for pre-scan search; each scan station will be played for 3sec, and touch again to stop.



Touch to auto-scan searching.



Touch to enter EQ settings.



Touch to switch Local or DX.



Touch to enter Radio settings.



Short touch to seek down, long touch to tune down.



Short touch to seek up, long touch to tune-up.

Preset channel, six preset buttons store, and recall stations for each band. Touch and slide the preset channel can switch to the next band, FM1/FM2/FM3 or AM1/AM2.

## Store a Station

1. Tune the radio to the desired station.
2. Touch and hold one of the preset stations for more than 3 seconds, then the preset button will be highlighted on the screen, and the preset station will be stored.

# USB

## Radio setting:



**Radio Area:** Select the region, American/Europe /Eastern Europe /Japan /Southeast Asia /Latin American/ Asia / Australia.

**RDS:** Switch ON or OFF.

**TA:** Switch ON or OFF. **AF:**

Switch ON or OFF. **PTY:**

Switch ON or OFF.

**Note:** AF is only for the European region.

## USB

Plug the USB; the USB icon will be colorful. Touch the USB icon to enter the USB playback mode. The source unit will playback the audio in the USB device.



Press to go to the following folder.





Press to search Audio files. Press





to go to the previous folder.


## USB


 Short press to skip previous track. Long press to fast reverse.

 Play or Pause button.


 Short press to skip the next track. Long press to fast forward.


 Press to select Repeat All> Repeat 1> Repeat Folder.

 Press to switch Random is On or Off.

 Press to select Audio setting or set the preferred EQ of each band in custom mode.


### File List Browsing

Touch  to browse the folder and file list of the USB device.





### Bluetooth Music:


Touch the BT Music icon to enter Bluetooth Music playing mode. If the Bluetooth is connected, the music will be playing as below shown:





## Bluetooth


 Press to search Audio files.

 Short press to skip previous track. Long press to fast reverse.

 Play or Pause button.


 Short press to skip the next track. Long press to fast forward. Press to select Repeat All> Repeat 1> Repeat Folder.

 Press to switch Random is On or Off.

 Press to select Audio setting or set the preferred EQ of each band in custom mode.

### Bluetooth Connect:

If the Bluetooth is not connected, press Reconnect the paired Phone or pairing to pair the new device.



### Bluetooth Pairing:

The pairing screen will be shown as below:



Turn on the Bluetooth of the Mobile phone/ Bluetooth device; you can see the "SOUNDSTREAM HD." Select the "SOUNDSTREAM HD" for pairing and connection.

# Bluetooth Phone

## Bluetooth Phone:

After the mobile Phone is connected with the source unit via Bluetooth(HFP), the user can go through the source unit

Make a phone call. Touch the Phone icon in Main Menu to go to BT Phone mode. Please note it needs to connect the microphone for phone calls.



Keypad. Tap it to enter call mode.



History. Tap it to show the call record, missed, received, and dialed calls.



Contact. Tap it to show the phonebook of connected device.



BT Setup. Tap it to set Auto answer and Microphone gain.







Make a call or accept the incoming call.



Backspace, tap it to clear the incorrect dial digit.


## Make a Call:

1. Touch the  icon to enter the dial screen.
2. Touch 0-9, \*, #, #, use the keypad, and enter the desired number to dial. If you input an incorrect number, touch the  icon on the keypad to delete the wrong number.
3. Once the correct number appears on the screen, touch the  icon to go to the dialing interface.
4. To end the call, touch the icon  on the screen.



## Receive an incoming call:

If the Phone is connected with the source unit via Bluetooth, when an incoming call, the below screen will be shown:

Press  to answer the incoming call.

Press  to reject the incoming call.



The interchange between phone and source unit.




Toggle On / Off the Microphone function.




Display the Keypad.

# Bluetooth Phone

## Call List:

Touch the  icon to display the call combined list.



Slide the bar at the right up and down to display call logs.

## Contacts:

Touch the  icon to access the phone book of the connected mobile Phone. To make a call from the phonebook, simply touch the contact's name.



## BT Setup:



**Auto Answer:** On/Off, incoming call auto answer.

**MIC Gain:** Low /Middle /High



# **HDHU.14+ Specifications**

## **GENERAL**

Power Requirement:	DC 10 - 16Volts,
Power Requirement:	Negative ground
Current Drain:	15A (Max.)
Maximum Power Output:	50Watts x 4
RMS Power Output:	25Watts x 4
Speaker Impedance:	2- or 4-Ohm Load
Frequency Response:	20Hz ~20KHz
Operating temperature:	-20~60 °C
Dimensions:	230mm(W) x 210mm(D)x 140mm(H)

## **TFT Display**

TFT Screen size:	7 – Inch TFT/LCD
Resolution	1024 x 600 pixels

## **FM RADIO SECTION**

Frequency Range	87.5 – 107.9 MHz (America) 87.5 – 108 MHz (Europe)
Usable Sensitivity (S/N=30dB)	≤ 15dB
S/N Ratio:	≥ 55dB
Stereo Separation	≥ 30dB

## **AM RADIO SECTION**

Frequency Range	(America) 522 – 1620 kHz (Europe) 530 – 1710 kHz
Usable Sensitivity (S/N=20dB)	≤ 40dB
S/N Ratio:	≥ 45dB

## **Line-out / Subwoofer Output**

Maximum Output Level (10K ohms load):	≥ 4V RMS
Subwoofer Time Align	0~18ms

## ***Trouble Shooting***

<b>Problem</b>	<b>Cause</b>	<b>Correct action</b>
No Power, Dead.	Check Fuse	Replace Fuse
	Incorrect Wiring	Consult your Local Specialist. <a href="http://www.MotorcycleAudio.com/Specialist-Locator">www.MotorcycleAudio.com/Specialist-Locator</a>
No sound output when operating the unit with amplifiers or power antenna attached.	Power antenna lead is shorted to ground excessive current is required or remote on the amplifiers or power antenna	<ol style="list-style-type: none"> <li>1. Turn off the unit.</li> <li>2. Remove all wires attached to the power antenna lead. Check each wire for a possible short to the ground using an ohm meter.</li> <li>3. Turn on the unit.</li> <li>4. Reconnect each amplifier remote wire to the power antenna lead one by one. If the amplifiers turn off before all wires are attached, use an external relay to provide remote-on voltage (excessive current required).</li> </ol>
Poor performance of radio station	Weak signal	Move the Motorcycle to another place, then try again
No Sound or Audio	Volume is in minimum  The wiring is not properly connected.	Adjust volume to the desired level. Check wiring connection

## FCC Notes

**WARNING! NOTE:** This equipment has been tested and found to comply with the limits for a **ClassB** digital device, pursuant to **Part 15 of the FCC Rules**. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. However, there is no guarantee that interference will not occur in a particular installation. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that the receiver is connected.

***[www.MotorcycleAudio.com](http://www.MotorcycleAudio.com)***

Follow Us on Social Media



# RESERVE

by SOUNDSTREAM®

## UPGRADE HEADUNIT FOR 2014+ HARLEY DAVIDSON® MOTORCYCLES INSTALLATION GUIDE



androidauto

Works with  
Apple CarPlay

Bluetooth®

*To print a complete owners manual, visit us  
online at [motorcycleaudio.com/hdhu.14](http://motorcycleaudio.com/hdhu.14)*

- or -

*Scan this QR code with your phone's  
camera to download the complete  
owners manual to your phone.*



# REMOVAL OF ORIGINAL HEAD UNIT

## STREET GLIDE

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse/battery cables before proceeding.

1. Remove three outer fairing bolts using a T27 Torx screw driver. The three outer fairing bolts are located below the windshield. Remove the windshield, store it and the screws removed in a safe place for re-installation later.



**TIP:** Reinstalling the center screw after removing the windshield will prevent the outer fairing from falling during the next step. A few turns by hand will be sufficient.

2. Remove four inner fairing bolts using a T27 Torx screw driver. The four inner fairing bolts are located adjacent to each turn indicator mounting bracket and below/adjacent to each speaker. Store these screws in a safe place for re-installation later.



3. While straddling the front wheel fender, grasp the outer fairing, remove the center outer fairing bolt from the previous step, then gently pull the fairing apart from the bike. With the fairing slightly pulled away from the bike, disconnect wire harness for the headlamp and any other accessories. Lay the fairing on a protected flat surface to prevent damage.


4. Remove upper support bracket. Removal of the upper support bracket requires removing 11 screws:

4.1) remove two screws attaching the bracket to each speaker enclosure (1)

4.2) remove two screws attaching the bracket to the inner fairing adjacent to the gauge cluster (2)

4.3) remove four screws attaching the bracket to the head unit chassis (3)

4.4) Remove one screw attaching the bracket to the media compartment (6)



5. Disconnect electrical connections to the head unit.


5.1) Remove the main wire harness connector (1). To remove the main wire harness, depress the latch lock with a small flathead screwdriver and swivel the latch aside. Pull the wire harness connector to remove from the socket.

5.2) Remove the USB cable connector (2). To remove the USB cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the USB cable to release it from the socket.


5.3) Remove the radio antenna cable connector (3). To remove the radio antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the antenna cable to release it from the socket.

5.4) Remove the GPS antenna cable connector (4). To remove the GPS antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the GPS antenna cable to release it from the socket.

5.5) Remove SiriusXM antenna cable connector, if equipped (5). To remove the Sirius XM antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the Sirius XM antenna cable to release it from the socket.



6. Remove four head unit mounting screws using a 3/16" hex driver. Two screws are located at each side of the head unit chassis. Store these screws in a safe place for re-installation later. Pull the head unit assembly up and forward to remove.



# REMOVAL OF ORIGINAL HEAD UNIT


## ROAD GLIDE

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse/battery cables before proceeding.

1. Detach each turn signal / indicator light by removing the adjacent allen socket screw, using a 3/16" allen head driver. Store these screws in a safe place for re-installation later.



2. Remove four inner fairing bolts using a T25 Torx driver. Two inner fairing bolts are located below each glove box, adjacent to each wind deflector. Store these screws in a safe place for installation later.



3. Remove four windshield bolts using a 1/8" allen driver or Phillips screw driver and remove the windshield. Also remove factory vent by pulling straight up on the vent. The vent comes snapped in place. Store the screws in a safe place for installation later.



4. After removing the vent, locate and unplug the 3-pin wire harness for the left and right side turn signal indicator. These harness' are adjacent to each side of the head unit.




5. Remove an additional inner fairing bolt with a T27 Torx or 5/32" allen driver, one behind each speaker grill. Remove the speaker grill by wedging a plastic/nylon pry tool between the inner fairing and grill edge, popping it outward. Once these bolts are removed, the outer fairing will be detached from the inner fairing. Store these screws in a safe place for installation later.



6. While straddling the front wheel fender, grasp the outer fairing. Gently pull the fairing apart from the bike. With the fairing slightly pulled away from the bike, disconnect wire harness for the headlamp or any other accessories. Lay the fairing on a protected flat surface to prevent damage.

7. Remove two upper support bracket screws using a 3/16" allen driver. Store the bracket and screws in a safe place for re-installation later.



8. Disconnect electrical connections to the head unit.


8.1) Remove the main wire harness connector (1). To remove the main wire harness, depress the latch lock with a small flathead screwdriver and swivel the latch aside. Pull the wire harness connector to remove from the socket.

8.2) Remove the USB cable connector (2). To remove the USB cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the USB cable to release it from the socket.


8.3) Remove the radio antenna cable connector (3). To remove the radio antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the antenna cable to release it from the socket.

8.4) Remove the GPS antenna cable connector (4). To remove the GPS antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the GPS antenna cable to release it from the socket.

8.5) Remove SiriusXM antenna cable connector, if equipped (5). To remove the Sirius XM antenna cable connector, depress the locking tab with a small flathead screwdriver. While depressing the locking tab, pull the Sirius XM antenna cable to release it from the socket.



9. Remove four head unit mounting screws using a 3/16" hex driver. Two screws are located at each side of the head unit chassis. Store these screws in a safe place for re-installation later. Pull the head unit assembly up and forward to remove.







# INSTALLATION OF HDHU.14 HEADUNIT

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse/battery cables before proceeding.


1. Install HDHU.14 into the location of the OEM head unit. Secure the chassis to the OEM mounting location with the four bolts removed during the last step of REMOVAL OF ORIGINAL HEAD UNIT section using a 3/16" allen driver.




2. Connect the OEM USB and radio antenna cables disconnected during removal of the OEM head unit to the matching sockets on the back of HDHU.14. If either are difficult to connect, verify the orientation of the connector(s) is correct. If any aftermarket audio amplifiers will be used in the audio system, take a moment to connect the RCA cables to the corresponding audio outputs. Although not required, if the Bluetooth calling microphone will be used, secure it to the desired installation location, then route its cable to the corresponding input on the back of HDHU.14.



3. Insert and lock the male OEM head unit wire harness connector to the female socket of the included wire harness for HDHU.14. Then, insert and lock the male connector of the HDHU.14 wire harness into the corresponding female socket on the back of HDHU.14.



4. If an alternative handlebar integration module other than Scosche is available, skip this step and proceed to step 5. If included, connect the Scosche handlebar integration module to the corresponding 12-pin and 14-pin connectors on the wire harness of HDHU.14.




5. If an alternative handlebar integration module is available, cut the wires leading to the 12-pin and 14-pin connectors and discard them. Follow the color coded call-out below to connect the wires of HDHU.14 wire harness to the corresponding inputs and outputs of the alternate handlebar control module.

14-Pin Connector



- Red.....ACC turn-on
- Orange.....Illumination
- Violet/White.....CAN -
- Green/White.....CAN +
- Black.....Ground
- Yellow.....12V

12-Pin Connector

- Black/White.....Key/SWC Ground
- Green/White.....Key/SWC 1
- Grey/White.....Key/SWC 2



6. Double check all connections are complete and secure. Reassemble the fairing support bracket using the original screws to the corresponding screw holes on top of HDHU.14. Then, reassemble the fairing by reversing the model specific instructions covered in REMOVAL OF ORIGINAL HEAD UNIT.



## LIMITED 90-DAY CONSUMER WARRANTY

## LIMITED ONE-YEAR CONSUMER WARRANTY WITH PURCHASE AND INSTALLATION BY A SOUNDSTREAM TECHNOLOGIES AUTHORIZED DEALER

Soundstream Technologies promises to the original purchaser to repair or replace this product with a new or refurbished unit (at Soundstream Technologies sole and absolute discretion) should it prove to be defective in workmanship or material under regular use, for a period of \*ONE years from the date of purchase from the Soundstream Technologies authorized dealer, PROVIDED the product was purchased and installed by a Soundstream Technologies authorized dealer. During this \*two-year period, there will be no charge for product repair or replacement, PROVIDED the unit is returned to Soundstream Technologies, return shipping pre-paid, along with the required proof of installation, the bill of sale or other dated proof of purchase, and the consumer's contact information.

If the unit is installed by anyone other than a Soundstream Technologies authorized dealer, the warranty period will be 90-days from the date of purchase. This warranty is non-transferable and does not apply to any unit modified or used in a manner contrary to its intended purpose. It does not cover damage to the unit caused by installation or removal of the unit. During these 90 days, there will be no charge for the repair or replacement PROVIDED the unit is returned to Soundstream Technologies, return shipping prepaid, along with the bill of sale or other dated proof of purchase and the consumer's contact information.

This warranty is void if the product has been damaged by an accident or unreasonable use, neglect, improper service, or other causes not arising from defects in materials or construction. This warranty does not cover the elimination of externally generated static or noise, or the correction of antenna problems or weak reception, damage to speakers, accessories, electrical systems, cosmetic damage or damage due to negligence, misuse, failure to follow operating instructions, accidental spills or customer applied cleaners, wear due to environmental causes such as floods, airborne fallout, chemicals, salt, hail, lightning or extreme temperatures, damage due to accidents, road hazards, fire, theft, loss or vandalism, damage due to improper connection to equipment of another manufacturer, modification of existing equipment, or Product which has been opened or tampered for any reason. Units that are damaged by abuse resulting in thermally damaged voice coils are not covered by this warranty but may be replaced at the absolute and sole discretion of Soundstream Technologies. The unit must be returned to Soundstream Technologies, postage pre-paid, with bill of sale or other dated proof of purchase bearing the following information: consumer's name, telephone number, address, authorized dealer's name, address, and product description. Please contact the Soundstream Technologies warranty office at 800.832.4647 or [warranty@soundstream.com](mailto:warranty@soundstream.com) to obtain a Return Authorization number before shipping the product.

Note: This warranty does not cover labor costs for the removal and re-installation of the unit. FOR THE TWO-YEAR WARRANTY TO BE VALID, YOUR UNIT MUST BE SHIPPED WITH PROOF OF INSTALLATION BY A SOUNDSTREAM TECHNOLOGIES AUTHORIZED DEALER. ALL UNITS RECEIVED BY SOUNDSTREAM TECHNOLOGIES FOR WARRANTY REPAIR WITHOUT PROOF OF SOUNDSTREAM TECHNOLOGIES AUTHORIZED DEALER INSTALLATION AND PURCHASE WILL BE COVERED BY THE LIMITED 1 YEAR WARRANTY.

BY PURCHASING THIS PRODUCT, ALL WARRANTIES INCLUDING BUT NOT LIMITED TO EXPRESS WARRANTY, IMPLIED WARRANTY, WARRANTY OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, AND WARRANTY OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY ARE EXPRESSLY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY LAW, AND SOUNDSTREAM TECHNOLOGIES NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT ANY LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT. SOUNDSTREAM TECHNOLOGIES HAS ABSOLUTELY NO LIABILITY FOR ANY AND ALL ACTS OF THIRD PARTIES, INCLUDING ITS AUTHORIZED DEALERS OR INSTALLERS. BY PURCHASING THIS PRODUCT, THE CONSUMER AGREES AND CONSENTS THAT ALL DISPUTES BETWEEN THE CONSUMER AND SOUNDSTREAM TECHNOLOGIES SHALL BE RESOLVED IN ACCORDANCE WITH CALIFORNIA LAWS IN LOS ANGELES COUNTY, CALIFORNIA. Some states do not allow limitations on how long an implied warranty lasts. In such states, the limitation or exclusions of this Limited Warranty may not apply. Some states do not allow the exclusion or limitation of incidental or consequential damages. In such states, the exclusion or limitation of this Limited Warranty may not apply to you. This Limited Warranty gives you specific legal rights, and you may have other rights which vary from state to state.

## HDHU.14 Firmware Update

January 31<sup>st</sup>, 2022



1. Download the HDHU.14 Firmware Update and Save to Computer.

After downloading, make sure the compressed files are unzipped and are copied onto a blank USB Flash Drive (64GB Max) on the Root Directory File of USB Flash Drive

2. Insert USB stick and select the "Settings Icon" from the Home Screen



3. Select "System Settings" Tab at top, then next screen select "About" button



4. Select "Update" and on next screen select "Update" Again



5. (( Wait for both Updates to complete )) Headunit will restart itself once both updates are complete. New Firmware Info:

MCU - HDHU-14-220126

SOC - HDHU.14-220124-12:00

### Firmware Improvements:

- Adds 10-Second Amplifier Turn-on Option
- Defaults Key-Beep Alert to "Off"
- Balances the Source Levels (USB, BT)
- Increases Overall Level Before Clipping
- Reduces Intermittent Data Feedback

Need Help? Contact Tech-Support  
[Tech-Support@PrecisionPower.com](mailto:Tech-Support@PrecisionPower.com)  
or 800.832.4647 Monday-Friday  
8:30AM - 4:30PM Pacific Standard

If Tech Support is busy, please leave a message and you will get a return call within 48 hours of being received.  
For Faster Service Email Us