

Universal

Desk

−&---

通用学习桌



IMPORTANT: PLEASE READ THE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

重要:请仔细阅读此说明书,并妥善保管以便日后参考。

Boori Australia Pty Ltd

18-20 Charles Street St. Marys Sydney NSW 2760 Australia Tel: 61 2 9833 3769 Fax: 61 2 9673 4240 www.boori.com.au

Boori (Europe) Ltd

Unit 1 Riverside House Mill Lane Newbury, Berkshire RG14 5QS UK Tel: (44) 016 3529 5670 Fax: (44) 016 3587 7552 www.boori.co.uk

Halim & Boori Company

10F. Halim INT'L B/D, #1674-4, Seocho-Dong, Seocho-Gu, Seoul, Korea Tel: +82-2-598-1470

Fax: +82-2-583-8885 E-mail: ted@boori.co.kr Postal code: 137-725.

ブーリジャパン(株)

〒541-0057 日本国大阪府大阪市

中央区北久宝寺町4-2-10 Tel:06-4963-3939 Fax:06-4963-3900

E-mail:info@boori.co.jp

博瑞儿童用品(上海)有限公司

上海市青浦区徐泾镇华徐公路577号

VEG微格创意园A8-10室

邮编: 201702 电话: 021-52966600 传真: 021-52966636 网址: www.boori.com.cn


Universal Desk (BK-DE)


Dimensions / 产品规格: 1220mm*580mm*750mm Materials / 材质: European Beech / 欧洲山毛榉


Hardware / 五金单

Tidiαwaic/ Δω+			
A x 1	B x 2	C x 4	D x 1
	M6*47mm	M6*28mm	M5*16mm
E x 8	Fx2	G x 1	
	(000)	0 0	
M6*13mm			
# · · · · · · · · · · · · · · · · · · ·			


Parts / 部件清单









Ver 1.0





Assembly / 安装说明

5










Place the assembled furniture adjacent to the wall and fix to the wall using the appropriate screw for that wall type. If you are in any doubt about the correct type of fitting to use, please seek professional advice.

组装好的家具靠墙。用相应的螺丝固定在墙上。如果你对要使用的五金的类型有疑问,请寻求专业的建议。



Boori Australia Pty Ltd Boori (Europe) Ltd

18-20 Charles Street St. Marys Sydney NSW 2760 Australia Tel: 61 2 9833 3769 Fax: 61 2 9673 4240 www.boori.com.au

www.boori.co.uk

Unit 1 Riverside House Mill Lane Newbury, Berkshire RG14 5QS UK Tel: (44) 016 3529 5670 Fax: +82-2-583-8885

Halim & Boori Company ブーリジャパン(株)

10F. Halim INT'L B/D, #1674-4, Seocho-Dong, Seocho-Gu. Seoul. Korea Tel: +82-2-598-1470

Fax: (44) 016 3587 7552 E-mail: ted@boori.co.kr Postal code: 137-725.

T541-0057 日本国大阪府大阪市

中央区北久宝寺町4-2-10 邮编: 201702 Tel: 06-4963-3939

Fax: 06-4963-3900 E-mail: info@boori.co.jp

博瑞儿童用品(上海)有限公司

上海市青浦区徐泾镇华徐公路577号


VEG微格创意园A8-10室


电话: 021-52966600

传真: 021-52966636 网址: www.boori.com.cn

Instruction for Wall Strap / 安全带说明

Hardware / 五金单








Important: The assembled furniture must be placed adjacent to the wall and fixed to the wall using the appropriate screw for that wall type. If you are in any doubt about the correct type of fitting to use, please seek professional advice.

<mark>警 告:</mark> 为避免柜子倾倒,对宝宝造成伤害,请务必将组装好的家具靠墙放置,并用安全带与螺丝等配 件将其固定在墙上或其他固定物上。如果您对所使用的五金有疑问,请寻求相关专业的建议。

Instruction for Drawer Removal / 抽屉拆装说明







- Note: 1. Insert a small screwdriver inside the Right Hand Side drawer runner. Push down the tip of the drawer locking mechanism.
 - 2. Insert a small screwdriver inside the Left Hand Side drawer runner. Lift up the tip of the drawer locking mechanism.
 - 3. Once both drawer runners have been unlocked, pull out the drawer carefully.

- 1. 用小螺丝刀抵住右边抽屉导轨安全销;向下用力,将右侧安全销压下。
- 2. 用小螺丝刀抵住左边抽屉导轨安全销;向上用力,将左侧安全销挑高。
- 3. 安全销达到右下左上状态时,可将抽屉与柜体分离。

/er 1.0



Kids Furniture Care Instructions

We hope you love your new Boori Kids furniture and it becomes an important part of your family home. In order to keep your furniture looking its best, please follow these care instructions.

Assembly

- When assembling your furniture, please follow the assembly instructions and use the tools supplied
- Boori products should only be assembled by an adult away from children
- Heavy components should be lifted by two people to prevent injury
- Every section that is assembled should be checked after assembly before moving onto the next stage

Product Positioning

- This product is made of timber and is therefore flammable
- Do not place your Boori furniture near open flames, fire places or extreme heat sources such as electric or gas heaters
- Do not direct sprayers or humidifiers at the furniture as they can cause damage
- Where possible avoid exposing furniture to extreme changes in temperature. Timber is a natural product and will want to expand and contract as the temperature varies. Extreme temperature variations can damage timber products.
- Avoid direct exposure to sunlight as this can cause our natural timber and plant oil colours to fade.
- Black rubber feet on items such as radios, computers and picture frames can cause marks. Always use a felt mat (not plastic) to protect your Boori furniture
- Do not place in damp environments or areas with high levels of moisture as this encourages mould growth.

Cleaning

- Clean your furniture by wiping with a soft, damp cloth
- If necessary, use a mild soapy solution and wipe clean with a soft cloth
- Do not use strong household cleaners
- Always wipe in the direction of the wood grain, not in circles.
- Wipe up spills immediately with a soft cloth
- Protect the furniture against bedwetting as this can lead to discolouration

Maintenance

- We advise that you regularly check the safety of your furniture
- Ensure all bolts and screws are tightened and check for loose connections, missing parts or sharp or pointed edges
- · Avoid contact with sharp objects and hot liquids
- When moving furniture always lift and place it into position; do not drag. We recommend that two people lift or alter the positioning of the furniture

Product testing Standards

• Standard: GB 28007-2011 EN 747-1: 2012+ A1: 2015 AS/NZS 4220: 2010