


90cm 7 zone induction cooktop with SenseFry, FlexiBridge, MaxiZone, PowerSlide, PowerBoost and Hob2Hood capability





Product Details

FEATURES

SenseFry	FlexiBridge	Instant control with PowerSlide	MaxiZone
PowerBoost	Hob2Hood technology	Touch and slide controls Touch the control bar at the necessary heat setting	STOP + GO function
Timer and minute minder	Auto warm up function	Auto pot detection	

BENEFITS

EVEN FRYING. AUTOMATICALLY.

SenseFry measures heat levels and makes automatic adjustments under the pan to maintain the ideal temperature for even cooking results. Now its easy for you to whip-up evenly browned pancakes and juicy steaks at home.

MORE SPACE TO CREATE

Preparing many dishes at the same time or cooking a large dish for a dinner party? FlexiBridge provides the ultimate in flexibility. Combine cooking areas for a long pan or cook lots of dishes separately at different temperatures with this fully adaptable zone.

SLIDE FROM SEAR TO SIMMER

The PowerSlide function allows you to slide your pots between the three pre-set temperature zones so that you can easily control the cooking levels. This is ideal for bringing sauces to the boil, simmering and then keeping warm for tastier results.

SEAR. STIR-FRY. BOIL.

The PowerBoost function gives you an intense heat boost when needed, before automatically dropping to the highest power level. Perfect for pan searing fish, stir-frying crunchy vegetables, or bringing water to the boil quickly.

HANDS-FREE HOOD

Hob2Hood automatically switches on your extractor hood when you start cooking and adjusts the fan speed based on how you are using your hob. This means you can boil, sear or stir-fry without having to touch your hood with greasy fingers.

INTUITIVE TOUCH CONTROLS

Sensitive touch controls take you from simmering to boiling and back again, almost instantly. This controllability allows you to apply precise changes that can take your dishes from tasty to truly delicious. Pan-sear steak with intense heat, and then instantly drop the temperature down to protect that beautifully juicy, medium-rare texture.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	induction
Materials/Colour	black ceramic glass

DIMENSIONS

Total product height (mm)	55
Total product width (mm)	910
Total product depth (mm)	520
Cut out width (mm)	880
Cut out depth (mm)	490

CONTROLS

Controls of Cooktops	Touch and Slide controls
Functions of Cooktops	automatic warm up,timer,Keep warm function,cooking timer with acoustic signal,automatic switch off,Hob2Hood,FlexiBridge,Bridging,PowerBoost,MaxiZone
Indicators/display	fault indicator,3 level residual heat indicator
Features of Cooktop	safety cut off,overheating protection,electronic timer,minute minder,function lock,hot surface indicator,auto pot sensors,child safety device lock,PowerSlide mode,FlexiBridge zone,MaxiZone,Hob2Hood,SenseFry
Timer of Cooktop	programmable 99min,auto off,countdown,Minute minder

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	FlexiBridge
Left front Watts	2300
Left front boost watts	3400



LEFT REAR ZONE

Left rear zone	FlexiBridge
Left rear watts	2300

CENTRE FRONT ZONE

Centre front zone	MaxiZone
Centre front Watts	3500

RIGHT FRONT ZONE

Right front zone	induction
Right front Watts	1400

RIGHT REAR ZONE

Right rear zone	induction
Right rear watts	1800

ELECTRICAL SPECIFICATIONS

Connected load KW	7.4
Type of connection	hardwired


SHIPPING


Shipping Volume (m3)	0.071
Shipping Weight (Kg)	20
Pack Dimensions Height (mm)	118
Pack Dimension Width (mm)	1000
Pack Dimension Depth (mm)	600



Dimensions

Model: EHI977BE





© 2021 Electrolux S.E.A PTE. LTD. E_DIM_EHI977BE_Sep21



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz