



**Biometric Portable Vault(RP19005)
Instruction Manual**

RPNBSafe delivers security exactly where you want it.

Box Contents




FIGURE A





FIGURE B



- RPNB® Safe
- High Strength Steel Security Cable
- Screwdriver

- Owner's Manual/Quick Start Guide
- Hardware Mounting Kit
- Backup Keys (2)

Warnings

To prevent damage to your RPNB® unit or injury to yourself or to others, read the following safety precautions before using this unit.

**DO NOT PLACE OR STORE THE BACKUP KEYS INSIDE THE SAFE AT ANY TIME.
IF THE BATTERY FAILS, YOU WILL BE UNABLE TO OPEN THE SAFE.**

DO NOT expose to extreme heat or cold. Battery power may be affected.

DO NOT store loaded guns in this unit. Firearms are serious in nature and must be handled with respect. Store responsibly.

ALWAYS check to make sure door has latched when closing; Lid requires a firm press and locks automatically.

Disclaimers:

Neither seller nor manufacturer shall be liable for unauthorized access, any injury, loss or damage to personal property direct or consequential, arising out of the use of, or the inability to use the RPNB® Safe.

The user shall determine the suitability of the RPNB® Safe before the intended use and user assumes all risk and liability whatsoever in connection therewith, RPNB® Safe are not intended to protect against environmental hazards including fire and water.

Be sure and follow all local and state firearm laws.



DO NOT operate a firearm without proper training and experience.

Battery Installation

- 1 To get started, insert one of your backup keys into the keyhole at the front of the safe (see Figure C). Push key in and rotate the key 60 degrees counterclockwise to open the safe.
 - 2 Locate the battery compartment door on the inside of the safe. Open the battery cover by removing the screw with the screwdriver (see Figure D).
 - 3 Insert the 4 AAA alkaline batteries (not included) into the battery compartment. Note that pay attention to the "+" and "-" signs. The "-" end of the batteries go against the spring inside of the compartment.
 - 4 When the batteries are inserted correctly you will hear a short beep once and the panel will light up.
 - 5 Once you hear the beep, place the battery cover.
- You are now ready to program your safe.

IMPORTANT:


Use the NEW AAA alkaline battery. Using other batteries may cause unusable conditions. New batteries can not be used with old batteries together. Your RPNB® safe will automatically lock when you fully close the lid. Any fingerprint can open the door before programming the fingerprints.



Programming the Fingerprints

To Register Your Fingerprint, Locate the “reset” Button.

- 1 With the safe open, press the “reset” button once and release it (see Figure E), biometric fingerprint will light up blue once with the one beep.
- 2 Using the helpful programming tips provided on page 5 (see Figure F) place your finger on the fingerprint scanner for the 1st of 3 scans. Remove your finger after light up green once with one short beep. Place finger again over the scanner until light up green once with one short beep and lift. You will repeat this process until biometric fingerprint light up green twice with the double beeps.
- 3 Now your fingerprint has been successfully registered. Close door and test to see if the safe will open using your fingerprint. If you make a mistake and the new fingerprint will not work, you must repeat the above steps.




Programming the Fingerprints

Helpful Programming TIPS:

- 1 Place your finger on the center of the scanner (this allows the scanner to read where most of the fingerprint detail is located).
- 2 Adjust your finger slightly between scans for increased accuracy.
- 3 Excessive moisture, lotions, or dirt will affect your fingerprint and may cause inaccurate sensor reading.
- 4 If you are experiencing difficulty try different fingers. Each finger is unique and some fingers, such as your thumb, contain more readable information than others.
- 5 To increase your success rate register the same fingerprint multiple times.

FIGURE F



Programming the Fingerprints

Note:

- Any fingerprint can open the door before programming the fingerprints.
- If biometric fingerprint flash red 2 times, it means registration has failed and you must repeat the above steps.
- You cannot register more than 20 fingerprints. If the red light flashes 10 times with 10 beeps when you register your fingerprint, it means the fingerprint storage capacity is full.
- If wrong fingerprint is entered 5 consecutive times, safe will go into a lock-down mode for 5 minutes. During this period the panel will flash red. And any operation will be temporarily banned (But safe can still be opened by backup key). After 5 minutes, green light flashes with a beep the safe will automatically resume normal operation.
- After waking up the system, the blue light flashes. After no operation for more than 10 seconds, you can hear a beep then the system will automatically exit the current state.

Delete the Registered Fingerprint

- 1 Press and hold the "reset" button (3 seconds), blue and green lights flash each with double beeps.
- 2 Now all registered fingerprints are erased.
- 3 When all registered fingerprints are erased will enter the default initial state, any fingerprint can open the safe.


IMPORTANT:

You must hold the "reset" button until blue and green lights flash each with double beeps, then release it.

Silence Mode Setting

To silence the audible sound of the electronics, press and hold the "SILENCE" button by using button tool until you hear double beeps. To unmute the keys, press and hold the "SILENCE" button by using button tool until you hear one beep (see Figure G).

FIGURE G



Low Battery Warning

If light up red 10 times with 10 times beeps when opening the safe by fingerprint, your battery level is critically low and your safe needs to be replaced the new batteries. If battery level lower than 4.2V the red light will light on 3s and you can not open it.

IMPORTANT:


Use the NEW AAA alkaline battery. Using other batteries may cause unusable conditions. New batteries can not be used with old batteries together.

Securing Your Safe

Your RPNB® safe can be secured a few different ways. Included is a security cable to attach your safe to larger stationary objects. There are also mounting screws included to mount the safe to a flat surface using the pre-drilled holes on the bottom.

Using the Security Cable

- 1 Loop the security cable around a secured object.
- 2 Run the end of the cable through the eye of the other end and pull tight around the object.
- 3 Place the end of the security cable inside the fully enclosed cable mount inside your RPNB safe as shown in (see Figure H).
- 4 Make sure the safe closes with the cable secured inside the cable mount.



Using the Mounting Screws

TIP: Make sure you have enough clearance for the lid to open properly before mounting the safe.

- 1 Position the safe on a flat surface where you want to mount it.
- 2 Use a pencil to mark the holes for drilling.
- 3 Drill pilot holes.
- 4 Position safe in place and install screws through safe into pilot holes. Tighten screws.

IMPORTANT

Mounting the safe vertically so that the door flips upward will result in incomplete opening of the safe due to weight. The door will open if the safe is mounted vertically so that door opens down or to side.

Customer Support/Warranty

Customer Support

If you have a problem with your RPNB® safe that is not answered in the this manual, we encourage you to email us: CUSTOMERSUPPORT@RPNBSAFE.COM

How shall I view tutorial videos?



RPNB®

<http://www.rpnbsafe.com>

- 1 Go to our website via: www.rpnbsafe.com
- 2 Select the "**Customer Service**" on the navigation bar
- 3 Click "**How To Video**"
- 4 Select the product model you purchased

How shall I replace keys?

- 1 Go to our website via: www.rpnbsafe.com
- 2 Select the "**Customer Service**" on the navigation bar
- 3 Click "**Replace Keys**"
- 4 Fill in the required information

How shall I order accessories?

- 1 Go to our website via: www.rpnbsafe.com
- 2 Select the "**Customer Service**" on the navigation bar
- 3 Click "**Order Accessories**"
- 4 Fill in the required information

 More online at www.rpnbsafe.com under support

Linked Warranty (Terms and Conditions)

RPNB® is committed to building high quality products and will make every effort to ensure our products are free from any defects. We guarantee your safe will be free of defects in materials or workmanship for a period of one year from the date of original. This warranty does not cover abuse, misuse, use in any manner for which is not designed, neglect, modification, damage in advertently caused by the owner; accidents, and/or tampering.

If your safe is determined to be defective and we are responsible for the cause we will have it repaired at our expense, or we will send a new replacement at no cost to you. You will be required to return your existing unit as well as all included accessories to RPNB® prior to replacement of the defective unit along with your order of purchase.

If it is determined your safe needs to be returned our customer support team will provide you with a return detail.

Please have the following information available when contacting us:

- Purchaser's name and mailing address, email address, and phone number
- Online order number
- Detailed description of problem

NEITHER SELLER NOR MANUFACTURER SHALL BE LIABLE FOR ANY INJURY, LOSS OR DAMAGE, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR THE INABILITY TO USE THE RPNB® SAFE.

How shall i talk to them?

Go to Your Orders, find your order in list, and click get product support.

You can e-mail the seller by doing the following:

<p>Account&Lists Orders Try</p> <h3>Your Account</h3> <p>Your Account Your Orders ← Your Dash Buttons Your Lists</p>	<h3>Your Orders</h3> <p>Orders Open Orders Digital Orders</p> <p>1 order placed in past 6 months</p>	<p>Get product support →</p> <p>Write a product review</p> <p>Archive order</p>	<h3>Talk to an expert</h3> <p>Figure out and fix what' s wrong,get</p> <p>phone chat →</p> <p>if a new window doesn' t appear,chan</p>
<p>1.Go to your account find the order</p>	<p>2.Find your order item</p>	<p>3.Click get product support</p>	<p>4.Give the seller 24hours to respond</p>

 Please email us to get a special **VIP** discount code before your next order.

 Problem with the order? Please email us, give us a chance to help you firstly.

 **Satisfied with us.**

Hum, this people is nice, i can give them a positive reviews to tell people they are selling good products, doing the right thing.



Customer Support Hours:

Monday - Friday 9:00AM - 6:00PM (PST) Saturday - Sunday 9:00AM - 12:00PM (PST) Excluding Holidays

Hours subject to change

Customer Service Department Contact: customersupport@rpnbsafe.com