





STEP BY STEP INSTALLATION INSTRUCTIONS

Available For Select Polaris UTVs



* Application specific. Go to hypertech.com and do a product search with specific year, make, and model for CARB E.O. verification.

Table Of Contents

SECTION 1: PROGRAMMING INSTRUCTIONS	
1-1: MAIN MENU	5-6
1-2: TUNING MENU	7-21
Engine Tuning	8-9
Rev Limit	
Top Speed	11-13
Tire Size	14
Portal Gearing	15
Throtle Response	16-17
Idle RPM	
Fan Temp	
Two Foot Limiter	20
Wide Open Throttle Fueling (Gas Applications ONLY)	
1-3: SELECTION REVIEW & PROGRAMMING	22-27
Review Changes	22
Preset Tune	22-23
Programming	
1-4: DIAGNOSTIC TROUBLE CODES	
1-5: SETUP/INFO	
Device Info	
Vehicle Info	
Brightness	
SECTION 2: BACK TO STOCK/TUNING OPTIONS/SELECTING PRESET TUNES	
Programming Back To Stock	
Changing Tuning Options	
Selecting Preset Tunes	35
SECTION 3: TECHNICAL INFORMATION & TROUBLESHOOTING	
3-1: What To Do Before Taking The Vehicle In For Service	
3-2: Troubleshooting Guide	
SECTION 4: UPDATING YOUR PROGRAMMER	
SECTION 5: PRODUCT WARRANTY & CONTACT INFO	
5-1: Factory Direct Limited One (1) Year Warranty	40
5-2: 30-Day Risk-Free Money Back Guarantee	
5-3: Contact Information	41

Please Read BEFORE Using Programmer

The installation process is very easy and should not take long for programming and installation to be accomplished. To avoid problems with installation, observe the following recommendations:

It is very important in the programming process that the vehicle's battery is fully charged and there is no drain on the battery. DO NOT program with a battery charger connected to the vehicle.

TURN OFF all electrical accessories (radio, heater/AC blower, wipers, etc.) that will power up when the key is in the 'Run' position. Do not operate any electrical accessories during the programming process.

Vehicles equipped with OnStar, satellite radio, remote starter, and/or aftermarket speakers/amplifiers MUST have the fuse/fuses removed in order to disable those devices prior to and during the programming process. (Refer to the vehicle owner's manual for location of radio, remote start, and amp fuses.)

Unplug all accessories from cigarette lighter or any other auxiliary power port on the vehicle BEFORE programming (cell phone chargers, GPS, etc.)

Disconnect any mobile devices from the entertainment system BEFORE programming (Bluetooth, USB chargers, smart phones, etc.)

Daytime running lights should be disabled before programming. See vehicle owner's manual for information on how to turn off.

Please Read BEFORE Using Programmer (Cont'd)

After inspection of the vehicle and removal of the fuse(s) that operate any accessory packages, continue with the installation of the programmer.

Once the programmer cable has been connected to the vehicle's diagnostic port and to the programmer, DO NOT remove or disturb the cable during the ENTIRE programming process. Only remove the cable from the diagnostic port when the installation is complete.

DO NOT leave the vehicle unattended during programming. The programmer screen will display instructions for you to follow i.e., turning the key to the 'On' position (but NOT starting the engine), and you will be asked to select certain engine tuning and vehicle adjustment features.

During the installation and programming if an error should occur, an error code and/or message will be displayed on the programmer screen, along with a phone number. Write down the error code or message and contact the Hypertech tech support department on the provided telephone number from 8am-5pm, Central Time, Monday-Friday. Have the part number and serial number off of the programmer, and your vehicle's VIN *#* ready when you call.


Most programming errors are caused by electrical interruptions. Please see Section 3 with more information for troubleshooting programming problems.

Section 1: Programming Instructions



Set the parking brake. Connect one (1) end of the provided cable to the programmer.

Remove the protective cover to the vehicle diagnostic port, usually located in the front storage compartment near the distribution block, and plug the other end of the provided cable into the diagnostic port. Make sure the cable is plugged in completely to ensure a good connection. **DO NOT disturb the cable once it is connected to the diagnostic port.**



Section 1: Programming Instructions (Cont'd)

The programmer will power up and display the startup screen.

 TURN KEY TO RUN

IURN KEY IU RUN	
PLEASE TURN THE	
KEY TO RUN	
BUT DO NOT START	
THE ENGINE	
THEN PRESS OK	
TO CONTINUE	
ОК	

Turn the key to the 'Run' position and select 'OK' using the middle bottom button. The 'Run' position is the last key click before the engine will start. **DO NOT start the engine at any time during the programming process.** You should hear your seat belt chime and warning light on the instrument panel when the key is in this position. For keyless ignition/push button start vehicles, press the ignition button until it cycles to the 'Start/Run' mode. The programmer will then read out the VIN #, and after a few seconds, display the Main Menu.

1-1: Main Menu

Use the left and right buttons at the bottom of the screen to scroll through the menu options. Press the middle button to 'Select' an option. Press the left button to go 'Back' to the last menu screen.


TUNING

This is the main option in the programmer. It has selections for the Hypertech Power Tuning, and other adjustable performance features.



DIAGNOSTIC TROUBLE CODES


This option reads/displays/clears Diagnostic Trouble Codes (DTCs).



1-1: Main Menu (Cont'd)

SETUP/INFO

This option displays various information about the programmer and your vehicle. It also allows adjustments to the display screen.



1-2: Tuning Menu

From the Main Menu, press the left or right arrow buttons and scroll to the Tuning icon. Press 'Select' to enter the Tuning menu.



The programmer will display four (4) tuning options:

PRESET TUNING: Select a previously saved tune for installation.

CUSTOM TUNING: Select all Power Tuning and adjustable features available for the vehicle.

PREVIOUS TUNING: Select a tune you have just used.

UNINSTALL TUNING: Select to reprogram all options back to factory stock settings.

	TUNING	
PRESET TU CUSTOM TUN PREVIOUS T UNINSTALL	ING UNING	•
		۷
BACK	SELECT	

CUSTOM TUNING

When using the programmer for the first time, select the Custom Tuning option. Press the 'Select' button to display the Tuning Main Menu.

	TUNING	
PRESET T CUSTOM T PREVIOUS UNINSTAL	JNING TUNING	
		×
BACK	SELECT	

NOTE: Some adjustable features on the upcoming pages are NOT available for all applications. The year, make, model, and engine of the vehicle will determine the available features. During the installation, only the available adjustable features for that particular application will appear on the programmer screen. Screens for each of the features may vary slightly from those shown.

To find the exact programming options available for your vehicle, go to hypertech.com and select your year/make/model & engine at the top of the page.

ENGINE TUNING

Features & Benefits

Hypertech's engine tuning is the most thorough tuning on the market. The custom tunes we offer were developed over hundreds of dyno pulls. Testing was done over months not only on the dyno, but on the trails as well. Compatibility with aftermarket parts was also tested, so these tunes have room to grow if you choose to upgrade your vehicle.

Turbo Applications

Stage 1: Factory boost with optimized spark and fueling.

Stage 2: Adds slightly more boost than factory and optimizes spark and fuel.

Stage 3: Maximized boost curve with optimized spark and fueling. Clutch kit recommended.

Stage 3-RG: All out maximized tuning for boost, spark, and fueling. Requires race fuel and a clutch kit.

ENGINE TUNING (CONT'D)

Gas Applications

87 octane: Optimized spark and fueling for using 87 octane fuel.


89 octane: Optimized spark and fueling for using 89 octane fuel.

91 octane: Optimized spark and fueling for using 91 octane fuel for maximum performance.

93+ octane: Optimized spark and fueling for using 93+ octane fuel for maximum performance.

	TUNING MENU	
ENGINE TU REV LIMITE TOP SPEED TIRE SIZE PORTAL GEA THROTTLE F	ER	×
CANCEL	SELECT	FLASH

From the Main Menu, use the buttons to the right of the screen to highlight Engine Tuning. Press the 'Select' button to choose an optimized engine tuning program.



Turbo Applications

Gas Applications

Use the buttons to the right of the screen to highlight the engine tuning program for the octane fuel being used. Press 'Select' to save the chosen tuning program. By selecting 'Stock', the programmer will install any additional features selected, but keep the stock engine tuning.

REV LIMITER

Turbo Applications - Raise/Lower +200/-500RPM Gas Applications - Raise/Lower +/-500RPM

Features & Benefits

The Rev Limiter option allows you to extend the engine's rpm range and keep the engine in the "sweet spot" of its power curve for quicker acceleration.

	TUNING MENU	
ENGINE TU	NING	
REV LIMIT	ER	
TOP SPEED		
TIRE SIZE		
PORTAL GE	ARING	
THROTTLE I	RESPONSE	
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Rev Limiter. Press the 'Select' button to adjust the engine rev limiter, in 100 RPM increments.

REV LIMITER		
STOCK		
-500 RPM		
-400 RPM		
-300 RPM		
-200 RPM		1
-100 RPM		
ВЛСК	SEI ECT	
BACK	SELECT	

Use the buttons to the right of the screen to scroll up or down and highlight the value to increase or decrease the engine rev limiter. Press 'Select' to save the chosen value.

TOP SPEED LIMITER

Features & Benefits

Top Speed Limiter (High/Low): This option allows you to adjust the top speed limiter in LOW range and HIGH range independently to match the speed rating of your tires.

Top Speed Limiter (Seat belt): If you have installed aftermarket safety harnesses you can adjust the top speed limiter associated with the seat belt to match the speed rating of your tires.

	TUNING MENU	
ENGINE TU BEV LIMIT		
TOP SPEED		
TIRE SIZE		
PORTAL GE		Y
CANCEL	SELECT	FLASH
CANCEL	SELEUI	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Top Speed. Press the 'Select' button to adjust the top speed limiter.

ALL SPEED LIMITS


Use the buttons to the right of the screen to highlight the desired top speed. Press 'Select' to save the chosen value.



TOP SPEED LIMITER (CONT'D)


PER MODE LIMITS

Use the buttons to the right of the screen to highlight the desired mode: High Gear, Low Gear, or Seat Belt. Press 'Select' to Press 'Select' to save the chosen mode.



HIGH GEAR LIMIT


Use the buttons to the right of the screen to select the top speed for High Gear. Press 'Select' to save the chosen top speed.



TOP SPEED LIMITER (CONT'D)


LOW GEAR LIMIT

Use the buttons to the right of the screen to select the top speed for Low Gear. Press 'Select' to save the chosen top speed.



SEAT BELT LIMIT

Use the buttons to the right of the screen to select the top speed for Seat Belt. Press 'Select' to save the chosen top speed.



TIRE SIZE

Features & Benefits

Correct the computer reading for 24"-54" tires Note: Only select this feature if the vehicle has a different size tire than what was installed from the factory.

TUNING MENU			TIRE SIZE		
ENGINE TU	JNING		STOCK		
REV LIMI	rer and a second se		24.00 IN		
TOP SPEEL			24.25 IN		
TIRE SIZ			24.50 IN		
PORTAL GE	EARING		24.75 IN		
THROTTLE	RESPONSE		25.00 IN		
CANCEL	SELECT	FLASH	BACK	SELECT	

From the Tuning Menu, use the buttons to the right of the screen to highlight Tire Size. Press the 'Select' button to recalibrate the computer reading for installed non-stock tire sizes. Use the buttons to the right of the screen to highlight the desired tire size. Press 'Select' to save the chosen value.

IMPORTANT NOTE

It is critical to measure the ACTUAL tire height. Here are two (2) methods of measuring the tire height (in inches):

OPTION 1 (Accurate)

1. Park on flat, level ground. Then measure the distance (in inches) from the ground to the top of the tire. This is far more accurate than using the sidewall specifications.

OPTION 2 (Most Accurate)

1. Place a chalk mark on the tire where it contacts the pavement and also mark the pavement. These marks should be at the center of the tire footprint pointing straight down to the pavement.

2. Roll the vehicle in a straight line until the chalk mark makes one revolution and is pointing straight down at the pavement again. Mark the pavement again at this new spot.

3. Measure (in inches) the distance between the two (2) marks on the pavement. Divide the measurement by 3.1416. This will give you the tire height in inches.

14

PORTAL GEAR

Features & Benefits

Correct the computer reading for portal gearing (Stock/15%/35%/45%).

	TUNING MENU	
ENGINE TU REV LIMIT	ER	A
TOP SPEED TIRE SIZE PORTAL GE		
THROTTLE		
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Portal Gearing. Press the 'Select' button to recalibrate the computer reading for installed portal gears.

	PORTAL GEARING
STOCK 15% 30% 45%	
BACK	SELECT

Use the buttons to the right of the screen to highlight the desired portal gearing percentage. Press 'Select' to save the chosen value.

THROTTLE RESPONSE

Features & Benefits

High/Low Mode: Stock/Belt/Mileage/Trail/Sport/Sport+/Race

STOCK: Factory throttle response mapping.

BELT: Limits your power delivery to help you break in the belt, or even to help inexperienced drivers feel more comfortable behind the wheel for the first time.

MILEAGE: Helps with clutch engagement while still maintaining stock power delivery.

TRAIL: Increases power across the power band slightly and improves clutch engagement and take-off. **SPORT:** Bumps things up from the TRAIL setting.

SPORT+: Much more aggressive throttle mapping that brings power in quickly and strongly.

RACE: All out aggressive power delivery and makes for an exciting ride with highly increased sensitivity.

	TUNING MENU	
ENGINE TU	NING	
REV LIMIT	ER	
TOP SPEED		
TIRE SIZE		
PORTAL GE	ARING	
THROTTLE	RESPONSE	
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Throttle Response. Press 'Select' to choose.

THROTTLE RESPONSE (CONT'D)


HIGH GEAR THROTTLE RESPONSE

Use the buttons to the right of the screen to select the throttle response for High Gear. Press 'Select' to save the chosen throttle response.

THROTTLE RESP	ONSE		THROTTLE HIGH	
HIGH GEAR Low Gear		STOCK Belt Mileage Trail		A
BACK SELECT	Y	SPORT SPORT+ BACK	SELECT	Y

LOW GEAR THROTTLE RESPONSE

Use the buttons to the right of the screen to select the throttle response for Low Gear. Press 'Select' to save the chosen throttle response.



IDLE RPM

Features & Benefits Raise/Lower Up To +/-200RPM

Adjust the idle RPM to reduce noise and vibration, to improve clutch engagement on take-off, or improve battery charging at idle for lights, stereo, etc.

	TUNING MENU	
IDLE RPM Fan temp Two foot	LIMIT	
		Y
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Idle RPM. Press 'Select' to choose.

		IDLE RPM	
STOC			
-200	RPM		
-100	RPM		
+000	RPM		
+100	RPM		
+200	RPM		
BACK		SELECT	

Use the buttons to the right of the screen to select the desired idle RPM. Press 'Select' to save the chosen idle RPM.

FAN TEMP

Features & Benefits

Adjust On/Off Temperatures Of The Cooling Fans


Adjust the "on/off" temps of your vehicle's electric cooling fans to match a lower temp thermostat.

Turbo Applications: Stock (205°F)/175°F/185°F

Gas Applications: Stock (205°F)/175°F/185°F/195°F

	TUNING MENU	
IDLE RPM Fan Temp Two Foot L Wot Fuel	IMIT	×
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Fan Temp. Press 'Select' to choose.



Use the buttons to the right of the screen to select the desired temp thermostat. Press 'Select' to save the chosen themostat temp.


TWO FOOT LIMITER

Features & Benefits Stock/5000RPM/Disabled

For those of you who use both feet to drive your vehicles to the limit we can trip the two foot power limiter which is an immediate buzzkill when you're driving hard. Adjust this limiter to a higher RPM of 5000RPM, or even disable it altogether to ensure your ride is dialed in to perform.

	TUNING MENU	
IDLE RPM Fan temp Two foot	LIMIT	
CANCEL	SELECT	FLASH

From the Tuning Menu, use the buttons to the right of the screen to highlight Two Foot Limiter. Press 'Select' to choose.



Use the buttons to the right of the screen to select your choice. Press 'Select' to save.

WIDE OPEN THROTTLE FUELING (NON-TURBO ONLY)

Features & Benefits Stock/Richer +1/Richer +2

This option allows you to increase the wide open throttle (WOT) fueling to account for airflow changes you have made to the exhaust system. Specifically, we saw the need for this option due to exhaust system changes which affect the airflow through the engine during valve overlap events. These changes are not measured by the ECU's manifold pressure sensor which is used to calculate airflow and thus fueling. We optimized the WOT fueling for two (2) different exhaust systems (high-flow, and straight-through mufflers). Without changes to the WOT fueling these systems caused a loss in power due to a lean condition. In fact, even with the corrected fueling (and timing) we saw no performance advantage over the factory muffler from either type of exhaust system. It is also against Federal and California emissions regulations to alter the exhaust systems on your RZR. We do NOT recommend modifying the exhaust system, but we want to ensure that your engine is not running in a dangerously lean condition if you do.



From the Tuning Menu, use the buttons to the right of the screen to highlight WOT Fuel. Press 'Select' to choose.



Use the buttons to the right of the screen to select your choice. Press 'Select' to save.

1-3: Selection Review & Programming

REVIEW CHANGES

The Tuning Menu will display each option that you selected to change on your vehicle. Once you have completed your selections from the Tuning Menu, the programmer is now ready to flash the vehicle's computer. Press 'Accept', then 'Flash' button to continue. If you want to change any of your selections, press 'Change'.

REVIEW CHANGES	
ENGINE TUNING: 91 OCTANE REV LIMITER: +200 RPM	
HIGH GEAR SPE: = 70 MPH	
LOW GEAR SPEE: = 70 MPH	
SEATBELT SPEE: = 70 MPH	
TIRE SIZE: 26.50 IN	
CHANGE	ACCEPT

PRESET TUNE

The programmer allows you to save up to five (5) preset tunes. This feature will save a specific selection of programming options in the programmer memory. The preset tune can be selected from the Tuning Menu. If you wish to save the currently selected tuning options as a preset tune, select 'Yes'. If you don't want to save the selected options as a preset tune, select 'No'.



PRESET TUNE (CONT'D)

To save the currently selected tuning options, use the buttons to the right of the screen to scroll up or down and select any combination of letters or numbers. The 'Prev' and 'Next' buttons move the cursor left and right. Once you have selected a name, press 'Done' to continue.



PROGRAMMING


Follow all of the messages on the programmer screen during the entire programming process for the vehicle. The programmer will prompt you to turn the key to the 'Run' and 'Off' position during this process. When turning the key to the 'Run' position, it is important to make sure that you turn the key to the most forward position possible **WITHOUT** starting the vehicle.

IMPORTANT NOTES

While the unit is programming, the following is **EXTREMELY IMPORTANT: DO NOT leave the vehicle while programming is in process. DO NOT unplug or disturb the cable or turn the key off (unless instructed to by the programmer). DO NOT Start the vehicle at any time while the programmer is connected** If the unit stops programming or is interrupted, please make a note of any message(s) that appear on the programmer screen and call the provided tech service line.

On certain applications, the instrument panel message center may light up, and random code information and other warning lights may display. This is a **NORMAL** step during the programming process for certain applications.

PROGRAMMING (CONT'D)



Prior to starting the programming process, the programmer will check for any Diagnostic Trouble Codes (DTCs). If any DTCs are present, the programmer will display them. You can review the DTCs before clearing.

If the vehicle has any DTCs, the programmer will display the number of DTCs reported from the vehicle's computer. You can review the DTCs by pressing the 'Show' button. Before the programming process can begin, all DTCs must be cleared. To clear any DTCs, press the 'Clear' button. For more information on this feature, see the DTC section. Once the DTCs are cleared, the programmer will proceed to Reading Vehicle. **NOTE: Necessary repairs must be made to the corresponding DTC code(s) to properly clear the DTC(s). Make these repairs and clear all DTCs with the programmer BEFORE programming the vehicle.**



If the vehicle has no DTCs, the programmer will proceed immediately to Reading Vehicle mode.

PROGRAMMING (CONT'D)



Once the programmer has completed the reading process, it will proceed to the Writing Vehicle mode. Continue to follow the messages on the screen. You may be prompted to turn the key to the 'Run' and 'Off' position during this process.

WRITING VEHICLE	WRITING VEHICLE	
PLEASE TURN THE KEY TO RUN BUT DO NOT START THE ENGINE THEN PRESS OK TO CONTINUE	PLEASE WAIT X SECONDS	
ОК		

After the programmer has successfully programmed the vehicle, follow the instructions on the screen until you see the Complete screen.



PROGRAMMING (CONT'D)


It is now safe to unplug the programmer from the vehicle and start the engine. Make sure the "Check Engine" light on the instrument cluster goes out (If it stays on or flashes, read out the DTCs, and contact Hypertech tech support). Warm up the engine and make sure it is running smoothly.

For OnStar, Satellite Radio, or aftermarket elctronic equipped vehicles:

Plug any connector(s) back into the original location and reinstall any fuses, panels, and/or other interior components that were removed prior to programming.

1-4: Diagnostic Trouble Codes

From the Main Menu, press the left or right arrow buttons to scroll to the Trouble Codes icon. Press 'Select' to enter the Trouble Codes menu.



The programmer will immediately begin reading out the DTCs from the vehicle's computer. If no DTCs are present, the programmer will display the following message:



If the vehicle has any DTCs, the programmer will show the total number of DTCs reported from the vehicle's computer. Press 'Show' to see all the DTCs found.



28

1-4: Diagnostic Trouble Codes (Cont'd)


Use the buttons to the right of the screen to scroll up or down and review each DTC. To see a definition of each DTC, press the 'More' button. The programmer will display a description of the DTC. To clear all DTCs, press the 'Clear' button.



NOTE: Necessary repairs must be made to the corresponding DTC code(s) to properly clear the DTC(s). Make these repairs and clear all DTCs with the programmer BEFORE programming the vehicle.

1-5: Setup/Info

From the Main Menu, press the left or right arrow buttons and scroll to the Setup/Info icon. Press 'Select' to enter the Setup/Info menu.



DEVICE INFO

Use the buttons to the right of the screen to highlight Device Info. Press the 'Select' button to display the Device Info menu.

	SETUP / INFO	
DEVICE INF VEHICLE IN BRIGHTNESS	FO	A
		Y
BACK	SELECT	


Use the buttons to the right of the screen to scroll up or down and review the device info.

	DEVICE INFO
STATUS :	TUNED
PART # :	3200
SERIAL #:	3252020
HARDWARE :	176
BOOT ID :	377
APP ID :	1.1.166
ВАСК	

1-5: Setup/Info (Cont'd)

VEHICLE INFO

Use the buttons to the right of the screen to highlight Vehicle Info. Press the 'Select' button to display the Vehicle Info menu. Info menu displays the VIN # of the vehicle that the programmer was last connected to, and the current status of the programmer.



Select 'Settings' to view the current options that are programmed in the vehicle. Select 'Back' button to return to the previous menu. Use the buttons to the right of the screen to view all the settings programmed into the vehicle.

S	ET	TINGS
ENGINE TUNING		
HIGH GEAR SPE LOW GEAR SPEE		
SEATBELT SPEE		45 MPH
PORTAL GEARIN TWO FOOT LIMI		
BACK		

1-5: Setup/Info (Cont'd)

BRIGHTNESS

Use the buttons to the right of the screen to highlight the Brightness feature. Press the 'Select' button to display the Brightness menu.

	SETUP / INFO	
DEVICE IN VEHICLE I BRIGHTNE	INFO	Å
DACK		Y
BACK	SELECT	

Use the buttons to the right of the screen to select Day, Night, or Sensitivity. Press 'Select' to choose.



Use the buttons to the right of the screen to adjust the brightness of the display screen, from 1 to 9. Press the 'Back' button to return to the previous menu.



32

Section 2: Programming Back To Stock, Changing Tuning Options, & Selecting Preset Tunes

Reconnect the programmer to the vehicle as in Section 1 and follow the messages on the screen until the Main Menu appears. Select the Tuning icon from the Main Menu.



PROGRAMMING BACK TO STOCK


To return the vehicle completely to factory stock settings, select Uninstall Tuning from the Tuning menu. Follow the programming instructions from Section 1.



Section 2: Programming Back To Stock, Changing Tuning Options, & Selecting Preset Tunes (Cont'd)

CHANGING TUNING OPTIONS

To change tuning options, select Custom Tuning from the Tuning menu.



To make options changes, follow the Tuning instructions from Section 1.

Note: All tuning options default to 'Stock' settings, regardless of what tuning options are currently programmed in the vehicle. You will need to select each option again, even if you aren't making a change from the current setting.


Section 2: Programming Back To Stock, Changing Tuning Options, & Selecting Preset Tunes (Cont'd)

SELECTING PRESET TUNES

To flash a previously saved tune, use the buttons to the right of the screen on the Tuning Menu and select Preset Tuning. Press the 'Select' button to bring up a list of preset tunes.



Use the buttons to the right of the screen to highlight a Preset Tune, and press 'Select'.



Select 'Change' to make changes to the tuning options. Select 'Accept' to continue with programming. Use the buttons to the right of the screen to review the Preset Tune options. Note: If you select 'Change', all tuning options default to 'Stock' settings, regardless of what tuning options are currently programmed in the vehicle. You will need to select each option again, even if you aren't making a change from the current setting.

REVIEW CHANGES	
ENGINE TUNING: 91 OCTANE REV LIMITER: +200 RPM HIGH GEAR SPE: = 70 MPH	
LOW GEAR SPEE: = 70 MPH SEATBELT SPEE: = 70 MPH TIRE SIZE: 26.50 IN	×
CHANGE	ACCEPT

Section 3: Technical Information & Troubleshooting

3-1: What To Do Before Taking The Vehicle In For Service

Return The Vehicle To The Stock Programming

When the vehicle is taken to a dealership or repair shop for any service, the vehicle's computer must be returned to the original stock calibrations, prior to taking the vehicle for service. To do this, follow the Back To Stock instructions in Section 2. This allows the original factory calibrations to be transferred from their stored location in the programmer and reinstalled into the vehicle's computer. This process returns the computer to factory stock and resets the programmer to allow the user to reprogram the vehicle **AFTER** repairs or service.

Why Is It Necessary To Return To The Stock Tuning?

The reason that this should be done is because the factory diagnostic equipment will only recognize factory calibration information. If that information is not stored it will automatically update the vehicle's computer to the original calibrations or to the most recent updated version, erasing the optimized tuning and other adjustable features that were installed by the programmer.

Reprogramming The Vehicle After Service Or Repair

vehicle After the has been serviced or repaired, you may retune your vehicle. If the factory has reprogrammed the vehicle with a calibration that is new and not recognized by the programmer, the programmer will display a "Update Required" message. If this occurs, the user will be instructed on how to update the programmer. This is a safety feature of the programmer. We do not want to rewrite any information if it is different from the calibrations currently stored in the vehicle. Following the instructions will allow the vehicle to have the latest and most current performance calibration that will match the updated factory version. Call the tech service line that appears on the screen for instructions on how to update the programmer. Due to the factory update of the computer, the programmer will have to be upgraded to match the new calibrations that have been installed in the vehicle's computer. There is no charge for calibration updates.

Section 3: Technical Information & Troubleshooting (Cont'd)

3-2: Troubleshooting Guide

Vehicle Not Supported

The following message is displayed when the programmer does not recognize the vehicle, along with an error code. THIS VEHICLE IS NOT SUPPORTED FOR PROGRAMMING; CALL HYPERTECH AT 800.532.3351. Verify that the vehicle year/make/model/engine shows to be supported with the programmer part number. The part number is located on the label on the back of the programmer, and on the end of the box. If the vehicle is supported, the programmer may need to be updated to the latest revision to work on your vehicle. See Section 4 for instructions on how to update your programmer.

Loss Of Communication

The following message will appear if the programmer is unable to communicate with the vehicle's computer. AN ERROR OCCURRED DURING VEHICLE PROGRAMMING; CALL HYPERTECH AT 800.532.3351.

Follow the steps below to correct the issue.

1. Make sure that the ignition key is in the 'Run' position and that the engine is not running.

2. Make sure that both ends of the cable are securely attached.

3. Wait at least five (5) minutes for the programmer to re-establish communication before restarting the programming process.

4. If the three (3) steps above do not correct the problem, call Hypertech tech service line on the phone number that appears on the programmer screen.

Cable Removed While Programming

The programmer will lose power during programming if the cable is removed for any reason. If this happens, simply reconnect the cable, and follow the messages on the programmer.

Attempting To Program A Different Vehicle

VIN mismatch will appear if attempting to program the computer in another vehicle without first programming the last vehicle it was used on back to stock. Return the previous vehicle back to stock, following the Back To Stock procedure in Section 2.

Section 3: Technical Information & Troubleshooting (Cont'd)

3-2: Troubleshooting Guide (Cont'd)

Update Required

There are several instances where an update may be required to use the programmer. The following codes require an update. The programmer will display a message that it needs to be updated. The programmer can be updated via the internet using the Hypertech Tuner Update Software, and the supplied USB cable. See Section 4 (next page) for instructions on how to update your programmer.

Blank Screen

If the programmer does not power up, make sure that both ends of the cable are fully inserted. If the programmer still does not turn on, check for a blown fuse in the vehicle fuse panel for either the cigarette lighter or the accessory circuit. Replace with the proper amperage fuse.

Section 4: Updating Your Programmer

The programmer may need to be updated if support for the vehicle was added after the manufacture date of the programmer, or if the vehicle has a calibration that is not supported by the programmer. Follow the steps below to update your programmer.

1. Install the Tuner Update Software

The Tuner Update Software can be installed on any Windows based PC. Go to hypertech.com and click "Support" at the top of the page, then scroll down and select "Software Downloads" and follow the instructions. **Note: The Tuner Update Software is not compatible on Apple/MAC operating systems.**

2. Connect the programmer to the PC with the supplied USB cable.

3. Open the Tuner Update Application software from the PC.

Once the update software is installed, there will be a shortcut installed on your desktop. Double click the shortcut to start the program.

4. Click the 'Update Tuner' button and follow the instructions on the screen.

Section 5: Product Warranty & Contact Info

5-1: Factory Direct Limited 1 Year Warranty

(Effective January 1, 2020 replaces and supersedes previous product warranty policy.)

Hypertech products are warranted against defects in materials or workmanship for one (1) year from the date of purchase. Hypertech's liability under this warranty shall be limited to the prompt correction or replacement of any defective part of the product which Hypertech determines to be necessary. This limited one (1) year warranty is to the original purchaser providing all the information requested is furnished. You must retain a copy of your original sales invoice or receipt. Without proper documentation, a service fee will be applied. Third party resellers and resold units are NOT covered under this warranty.

Important Note: The Max Energy Spectrum is designed to use on only one (1) vehicle at a time. In order to use the Max Energy Spectrum on another vehicle, the vehicle it is currently being used on must be returned to stock by following the Back To Stock procedure in Section 2. Once the Max Energy Spectrum has been returned to stock, it can then be used on another vehicle, if that vehicle is supported by the Max Energy Spectrum.

The Max Energy Spectrum is limited for use on a maximum of three (3) vehicles. Each time the Max Energy Spectrum is connected to a vehicle, the VIN # is stored in the Max Energy Spectrum memory. Once the Max Energy Spectrum has a third VIN # stored, it will no longer be able to be reused on another vehicle. Warranty coverage is only for the original purchaser, and on the original vehicle the Max Energy Spectrum was used on. After the third VIN # there will be a service fee applied to reset the unit.

Additional licenses for new vehicles can be purchased from Hypertech. To order, call our Tech Department at 901.382.8888, or email techsupport@hypertech.com, with the serial number off of the programmer.

Section 5: Product Warranty & Contact Info (Cont'd)

5-2: 30-Day Risk-Free, Money Back Guarantee

(Effective January 1, 2020)

The 30-day money back guarantee applys to all Max Energy Spectrum Power Programmers, React Throttle Optimizers, PowerStays, Max Energy 2.0 Power Programmers, Max Energy Power Programmers, Interceptors, Speedometer Calibrators, In-Line Speedometer Calibrator Modules, and Power Chips for GM. The product MUST be returned to the place of purchase within thirty (30) days. All items must be received in a new, unused and ready-to-sell condition (including all original packaging, parts, and paperwork) to receive a refund, excluding any shipping and handling fees. **Units purchased used or reconditioned from a non-authorized Hypertech dealer, or units sold by 3rd-party vendors (i.e. ebay) are NOT covered under this guarantee.**

5-3: Contact Info

Hypertech Tech Department Phone: 901.382.8888 Fax: 901.373.5290 techsupport@hypertech.com Office Hours: Monday-Friday, 8am-5pm Central Time hypertech.com

Hypertech

7375 Adrianne Place Bartlett, Tennessee 38133 hypertech.com

