
DF7600

OLYMPIC WEIGHT TREE

Assembly Manual






Assembly Video Available

Simply scan the QR code below on your phone's camera to access the video




(888) 258-0533


FOR YOUR SAFETY READ ALL INSTRUCTIONS CAREFULLY



BOX CONTENTS




SUPPORT LEG QTY 2



CROSSMEMBER QTY 1



DF7600 ASSEMBLY MANUAL QTY 1



BODY

QTY 1

M12 BOLT QTY 8






M12 WASHER QTY 16




M12 LOCKNUT QTY 8



RUBBER SPACER QTY 6



TRIANGLE FLANE QTY 2




TOOLS REQUIRED:


METRIC SOCKET SET OR WRENCHES

INSTRUCTIONS:

ATTACH THE SUPPORT LEGS (**B**) TO THE CROSSMEMBER (**C**) USING M12 BOLTS (**D**), M12 WASHERS (**E**), AND M12 LOCK NUTS (**F**). DO NOT FULLY TIGHTEN AT THIS TIME.



ATTACH THE TRIANGLE FLANGES (**B**) TO THE CROSSMEMBER USING M12 BOLTS (**D**), M12 WASHERS (**E**), AND M12 LOCK NUTS (**F**). FULLY TIGHTEN.



ATTACH THE BODY TO THE TRIANGLE FLANGES USING M12 BOLTS (**D**), M12 WASHERS (**E**), AND M12 LOCK NUTS (**F**). FULLY TIGHTEN.

SLIDE RUBBER WASHERS (G) ON TO EACH WEIGHT PEG.

NOW SET THE WEIGHT TREE IN THE AREA THAT YOU WILL BE USING IT IN. WHILE MAKING SURE THAT ALL 4 FEET SIT FLAT ON THE FLOOR, FULLY TIGHTEN THE NUTS SECURING THE LEGS TO THE CROSSMEMBER.

SAFETY NOTICE

WARNING: THE USER OF THIS WEIGHT EQUIPMENT ASSUMES THE POSSIBILITY OF INJURY BY EXERCISING ON THIS EQUIPMENT. THE POSSIBILITY OF RISK CAN BE REDUCED BY ALWAYS FOLLOWING THESE SIMPLE RULES:

- 1) BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR DOCTOR FOR A COMPLETE PHYSICAL EXAMINATION AND SUGGESTED EXERCISE PROGRAM SPECIFIC FOR YOU.
- 2) STRETCH BEFORE AND AFTER THE EXERCISE PROGRAM. PROPER STRETCHING WILL PREPARE YOUR JOINTS AND MUSCLES FOR EXERCISE AND HELP AVOID INJURIES.
- 3) IF AT ANY TIME YOU SHOULD FEEL FAINT OR DIZZY, NAUSEOUS OR EXPERIENCE ANY OTHER ABNORMAL SYMPTOMS OR DISCOMFORT DISCONTINUE USE AND CONSULT YOUR DOCTOR.
- 4) DO NOT USE THIS EQUIPMENT WITHOUT QUALIFIED SUPERVISION AND PROPER TRAINING. NEVER WORK OUT ALONE- ALWAYS HAVE A PARTNER.
- 5) SECURELY TIGHTEN ALL BOLTS AND REGULARLY CHECK TO ENSURE ALL BOLTS HAVE NOT LOOSENED.
- 6) WEAR GOOD RUBBER SOLE SHOES ONLY. DO NOT USE BARE FOOTED OR WITH SOCKS ONLY.
- 7) DO NOT WEAR LOOSE CLOTHES SUCH AS ROBES, GOWNS, PANTS, LONG SHIRTS OR JEWELRY WHICH COULD BECOME ENTANGLED IN MOVING PARTS.
- 8) DO NOT STAND OR KNEEL ON SEAT. ALWAYS SIT OR LAY SQUARELY CENTERED.
- 9) KEEP HEAD, LIMBS AND BODY PARTS CLEAR OF MOVING PARTS AND WEIGHT PLATES.
- 10) CHILDREN SHOULD NOT USE EXERCISE EQUIPMENT WITHOUT SUPERVISION BECAUSE OF POSSIBILITY OF INJURY FROM IMPROPER USAGE. THIS EQUIPMENT IS INTENDED FOR HOME USE ONLY.
- 11) REPLACEMENT OF WORN OR DEFECTIVE PARTS MUST BE WITH FACTORY AUTHORIZED PARTS. IF OTHER THAN FACTORY AUTHORIZED PARTS OR ASSESSORS ARE USED ALL WARRANTIES AND LIABILITIES BECOME VOID.