
**SEATED DIP** 

PL-3101



**CAUTION:** Read all precautions and instructions before using this equipment. Save this manual for future reference.

### CONTENTS

- O2 General warnings and maintenance advice
- 03-06 Assembly Instructions

Explained as a series of steps, with each step containing:


- Pictures, descriptions and quantities of the parts required
- Notes
- Diagram showing how the parts fit together
- 07 Part List

# Assembly Instructions Before Your Begin


This exercise equipment is built for optimum safety. Be sure to read the entire manual before you assemble or operate your equipment. Please note the following safety precautions:

- 1. Keep children and pets away from the equipment at all times. Do not leave children unattended in the same room with the equipment.
- 2. Only one person at a time should use the equipment.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the equipment on a clear, level surface. DO NOT use the equipment near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the equipment.
- 7. Use the equipment only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Before using the equipment, always do stretching exercises to properly warm up.
- 9. Never operate the equipment if the equipment is not functioning properly.


## STEP 1




50%







100%



### PARTS LIST

| PART# | DESCRIPTION        | QTY |
|-------|--------------------|-----|
| 1     | Main Frame         | 1   |
| 2     | Handle Frame 1     | 1   |
| 3     | Handle Frame 2     | 1   |
| 4     | Leg press tube     | 1   |
| 5     | Limit tube         | 1   |
| 6     | Linking Frame      | 1   |
| 7     | Seat Support Frame | 1   |
| 8     | Seat ADJ Handle    | 1   |
| 9     | Poster Board       | 1   |
| 10    | Seat Pad           | 1   |
| 11    | Foam Roller        | 2   |
| 12    | 128 Pin            | 1   |
| 13    | ADJ Plate          | 1   |
| 14    | ADJ Handle         | 1   |
| 15    | Foam Cap           | 2   |
| 16    | Foam ring          | 2   |
| 17    | D33 Cap            | 2   |
| 18    | D60 Washer         | 2   |
| 19    | D32 Washer         | 2   |
| 20    | D48 Spring card    | 2   |
| 21    | Shaft              | 1   |
| 22    | Limit Round Iron   | 1   |
| 23    | Spring 1           | 1   |
| 24    | Spring 2           | 1   |
| 25    | Bearing 6700       | 4   |
| 26    | D32 Bushing        | 2   |
| 27    | Spring Washer D10  | 4   |
| 28    | Spring Pin         | 1   |
| 29    | ADJ Plate 1        | 1   |
| 30    | ADJ Plate 2        | 1   |
| 31    | Grip               | 2   |
| 32    | Spring Cover       | 2   |
| 33    | PT Cap 1           | 10  |
| 34    | PT Cap 2           | 1   |
| 35    | D48 Cap            | 2   |
| 36    | D42 Cap            | 2   |
| 37    | D Cap              | 2   |
| 38    | D25 Cap            | 6   |
| 39    | D48 Rubber Block   | 2   |
| 40    | Rubber Cover 1     | 2   |
| 41    | Rubber Cover 2     | 2   |
| 42    | Foot Cover         | 2   |
| 43    | Limit Pad          | 1   |
| 44    | Crash pad          | 1   |
| 45    | Wheel              | 3   |
| 46    | Foam Bushing       | 4   |
| 47    | Lable 1            | 1   |
| 48    | Lable 2            | 1   |

| PART#   | DESCRIPTION                 | QTY |
|---------|-----------------------------|-----|
| 49      | Wave Washer                 | 2   |
| S4-1    | Socket Set Screw M4X3       | 4   |
| S6-2    | Socket Set Screw M6X6       | 4   |
| C5-4    | Cross Pan Head Screw M5X10  | 8   |
| C8-5    | Cross Pan Head Screw M8X25  | 2   |
| C10-5   | Cross Pan Head Screw M10X25 | 3   |
| C10-18  | Cross Pan Head Screw M10X90 | 1   |
| A10-5   | Allen Bolt M10X25           | 4   |
| SC8-7   | Socket Cap Screw M8X35      | 4   |
| SC10-5  | Socket Cap Screw M10X25     | 14  |
| SC10-11 | Socket Cap Screw M10X55     | 1   |
| SC10-18 | Socket Cap Screw M10X90     | 1   |
| SC10-23 | Socket Cap Screw M10X115    | 7   |
| W8      | Washer Ф8                   | 4   |
| W10     | Washer Φ10                  | 41  |
| N10     | Nut M10                     | 18  |