IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

BEFORE USE

Inspect the product for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately

PRODUCT SAFETY

- Prior to the installation of this product, the installation instructions should be read
 and completely understood. The installation instructions must be read to prevent
 personal injury and property damage. Keep these installation instructions in an easily
 accessible location for future reference.
- CAUTION: Do not exceed maximum load capacity. Use with products exceeding the maximum load capacity may cause serious injury. See appliance instructions.
- Do not install on a structure that is prone to vibration, movement or chance of impact.
 Failure to do so could result in damage to the display and/or damage to the stand.
- Do not place near heater, fireplace, air conditioning, in direct sunlight, or any other heat producing source. Failure to do so may result in damage to the display and could increase the risk of fire.
- It is recommended that two people perform the installation. Injury and/or damage can result from dropping or mishandling the display.
- The enclosed instructions are an aid to installation and cannot cover all eventualities, if you have any concerns regarding the mounting of the frame or brackets you should consult an expert.
- CAUTION: Before installation the mounting area should be checked that it is suitable
 for the weight of the bracket and screen and is free from pipes, electric cables or any
 other obstructions.

UNIVERSAL CEILING TV BRACKET



APC-50

















STEP1 Attach the frame to the post



STEP2 Concrete Wall Mounting & Wood Stud Wall Mounting



STEP3 Height adjustment



STEP4 Attach bracket to the screen

