

HEEVE HEAVY DUTY SINGLE FOLD EXTRA WIDE ALUMINIUM WHEELCHAIR RAMP

INSTRUCTION MANUAL

MAXIMUM *OCCUPIED / **UNOCCUPIED HEIGHT LIMIT TO GROUND LEVEL

Ramp Length	Occupied Max Loading Height	Unoccupied Max Loading Height
610mm	100mm	150mm
920mm	150mm	230mm
1220mm	200mm	300mm
1520mm	250mm	380mm
1830mm	300mm	450mm

^{*} Occupied Loading Height must be maintained at a maximum of 1:6 gradient or 9.5 degrees.

I.OPERATION

A. Loading wheelchair:

- 1. Position the wheelchair in the direction of the ramp with the front wheel forward.
- 2. Roll or ride the wheelchair slowly and steadily up the ramp, ensuring that the wheels follow the centre of the ramp.
- 3. Take extra care in wet conditions to ensure the wheels do not slide on the ramp.

B. Unloading wheelchair:

- 1. Position the ramp as detailed above directly behind the rear wheel of the Wheelchair.
- 2. Allow the wheelchair to roll backwards down the ramp, ensuring the wheels follow the centre of the ramp.
- 3. Always have a qualified assistant present when using the ramp.

II. MAINTENANCE

Keep your ramp functioning properly by following these maintenance tips:

A. Check before use:

- 1. It is the user's responsibility to check the loading ramp and components before each use.
- 2. If the ramp is damaged, it should NOT be used.

B. Regular cleaning:

- 1. Maintain the ramp by regular cleaning.
- 2. Periodically lubricate the hinges to keep them working smoothly.

^{**} While unoccupied loading height should be at a maximum of 1:4 gradient or 14.5 degrees.

MAXIMUM WEIGHT CAPACITY IS 400KG

(weight rating is based on an evenly distributed load on 2 axles)

WARNING

- NEVER exceed the rated capacity of your ramp.
- NEVER exceed the maximum height limit listed above.
- Use caution at all times when loading and unloading.
- ONLY load and unload onto a stable, level surface.
- NEVER stand in the path of equipment or vehicles. Keep bystanders and children away.
- DO NOT leave attached ramps unattended.
- Beware of hinged areas. Keep all body parts clear of hinged areas.
- Ramp surfaces will have less traction when wet. Use caution.
- Always fold and secure the ramp with the latches before carrying.
- The ramp is not a toy. DO NOT use the ramp as a jump, scaffold, bridge, ladder or anything other than its designed purpose.
- ALWAYS make sure the top of the ramp attaching lip is secured onto the step, landing or vehicle before using. We strongly recommend using the supplied safety pins to prevent ramp kick-outs.
- ALWAYS follow manufacturer recommendations for chairs or scooters.