

STEP 3


Then adjust balance of this chair, tighten all the screws to 100%.



STEP 4Finally, stick the non-woven fabric back under the seat.



FABRIC CONTENT
MAIN FABRIC 100% POLYESTER
OTHER FABRIC (NON VISIBLE)
NON-WOVEN FABRIC 100% POLYESTER



KY539 CHAIR

Thank you for your purchase. The following care instructions will allow you to make the most of your chair; helping to prolong the look and life of it by preventing wear and damage.

IMPORTANT INFORMATION PLEASE ENSURE YOU READ THIS LEAFLET BEFORE USING YOUR CHAIR. DO NOT DISCARD OF ANY PACKAGING UNTIL YOU HAVE CHECKED THE PRODUCT THOROUGHLY.

CARING FOR YOUR CHAIR

- Pre-brush fabric with a soft brush and then gently vacuum.
- Plump any accent/removable cushions regularly to prevent them becoming mis-shaped or flat.
- Use a microfibre cloth to remove dust from wooden surfaces.
- In the event of a spill or stain, use specialist upholstery cleaner or cleaning services.

SUNLIGHT AND HEAT DAMAGE

- Avoid contact with direct sunlight. If needed move items or change their position to avoid the same area being exposed to repeated sunlight/heat.
- Do not place your chair close to fire places and/or radiators.
- Hot objects such as mugs/plates can permanently mark the fabric and wood, avoid placing these on the chair.

SAFETY WARNINGS

- Do not allow children or pets to climb or jump on the chair or through the arms.
- Avoid contact with sharp objects such as buckles, toys and jewellery as these can easily snag, tear and/or pull the fabric.
- Avoid the risk of entrapment by using the chair as intended; sitting facing forward on the seat.
- Keep small parts away and out of reach of children and pets.

PARTS LIST


PARISLISI			
IMAGE	DESCRIPTION	PART NO.	QTY
	Seat	Α	1
	Front legs	В	2
	Back legs	С	2
	Washer	D	4

ASSEMBLY INSTRUCTIONS

Unpack your chair and check that all the parts on the parts list are present. If any are missing, please contact the retailer from whom you purchased the product.

STEP I

Assemble your chair on a flat and soft surface to prevent any damage. Open the underneath of the chair to find both sets of legs.



STEP 2Put the screws in the holes, tighten the screws to 90%.

