BWA AUTOMOTIVE BILLET BUTTONS

1. Identify the style of connector pins on your button in the images below.

16mm	19mm	22mm	30mm	
				
				
Part No: BWASW-SS-16-L-00-BL-GN BWASW-SS-16-L-00-RD-YW BWASW-SS-16-L-00-WH-OR BWASW-SS-16-M-00-BL-GN BWASW-SS-16-M-00-RD-YW BWASW-SS-16-M-00-WH-OR BWASW-SS-16-M-00-RD-BL	***Part No:*** BWASW-SS-19-L-00-BL-GN BWASW-SS-19-L-00-RD-YW BWASW-SS-19-L-00-WH-OR BWASW-SS-19-M-00-BL-GN BWASW-SS-19-M-00-RD-YW BWASW-SS-16-9-00-WH-OR BWASW-SS-19-M-00-RD-BL	***Part No:*** BWASW-SS-22-L-00-BL-GN BWASW-SS-22-L-00-RD-YW BWASW-SS-22-L-00-WH-OR BWASW-SS-22-M-00-BL-GN BWASW-SS-22-M-00-RD-YW BWASW-SS-22-M-00-WH-OR BWASW-SS-22-M-00-RD-BL	***Part No:*** BWASW-SS-30-L-00-BL-GN BWASW-SS-30-L-00-RD-YW BWASW-SS-30-L-00-WH-OR BWASW-SS-30-M-00-BL-GN BWASW-SS-30-M-00-RD-YW BWASW-SS-30-M-00-WH-OR BWASW-SS-30-M-00-RD-BL	***Part No:***

2. Use 'Normally Open' connections to close circuit when button is pressed. Use 'Normally Closed' connections to open circuit when button is pressed.

3. Optionally, L.E.D. can be wired to illuminated upon button activation. Use the button itself to control L.E.D. See button illumination wiring diagram on page 2.

BWA billet button hole sizes templates



©2017 Bluewire Automotive All rights reserved. Revised 01/04/2017 . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Button L.E.D Illumination Wiring

Illumination Always On



Illumination On With Ignition



Illumination On When Pushed



Button Application Wiring

Controlling Motors

Power Windows, Sunroof, Linear Actuators, Door Locks



Turn Signals & Hazards



Solenoid Control

Power Trunk, Shaved Door, Power Bear Claw



Motor Control Units

Air Command, Window Control



©2017 Bluewire Automotive All rights reserved. . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Engine Start



Momentary Button

Note: Put key in ignition to unlock column and turn on accessory.

Headlights



Cooling Fan



Latching Button

Starter Kill



Airbags



Momentary Button

Battery Kill



Over Drive Off

Negative Trigger



Latching Button

©2017 Bluewire Automotive All rights reserved. Revised 01/04/2017 . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Two Button Push Start



Backup System Override

Negative System



Positive System



©2017 Bluewire Automotive All rights reserved. Revised 01/04/2017 . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.







©2017 Bluewire Automotive All rights reserved. Revised 01/04/2017 . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

©2017 Bluewire Automotive All rights reserved. Revised 01/04/2017 . The above instructions are for reference only. Bluewire Automotive is not responsible for any inaccuracies in the above instructions. Bluewire Automotive is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.