Jump Start Socket

Type-C 5V/2A Input
USB 5V/2A Output
USB/16V/19V Output
On-Off Key
Switch
LED flash light

Power Level

Charging display
5V/2A USB Output
12V/16V/19V Output

# OPERATING INSTRUCTIONS
CHARGING YOUR CTA26

You can charge your CTA26 one of Two ways:

1. Using the supplied 120 Volt main charger.

OR

1. Connect the jumper lead to your CTA26.
2. Connect the +(red clip)to the + on your car battery.
3. Connect the -(black clip)to the - on your car battery.
4. Turn your key to start your vehicle.
5. Once your vehicle is started, disconnect the alligator clip as soon as possible.

Note:
1. After starting your vehicle, Remove the CTA26 as soon as possible
2. DO NOT connect the 2 alligator clip together.
3. DO NOT disassemble the CTA26

CHARGING DIGITAL DEVICES VIA USB

1. You can either use the provided USB Break out lead or your own USB cable suitable for your digital device.
2. Connect either cable to the CTA26.
3. If using the provided USB Break out lead, Select the correct connection for your device.

EXAMPLE BELOW:

STARTING YOUR VEHICLE

Please ensure that your CTA26 is no less than 50% charged. If it is below 50%, you may not be able to jumpstarter your vehicle.

1. Slide the on/off switch to the on position.
2. Slide the power switch and the press the round power botton to turn on your CTA26.
3. Press the round power button to select the correct voltage for your laptop. This will be either 12/16 or 19volts. The Voltage selected will be shown in the LCD Screen of CTA26.
4. Once you have selected the correct voltage, connect the short laptop charging cable to your CTA26. and then to your laptop.
5. If you need to reselect the voltage, turn off the CTA26. Wait 15 seconds and then start from step 1 again.

Take charging for 19v laptop as an example:

TURNING ON YOUR CTA26

Follow 3-step process as below to turn on your CTA26 jump starter:

1. Slide the on/off switch to the on position.
2. Press the round power button.
3. Your CTA26 is now ready to use.

CHARGING YOUR LAPTOP

1. Select the suitable charging plug and connect it to the short laptop charging cable provided.
2. Slide the power switch and the press the round power botton to turn on your CTA26.
3. Press the round power button to select the correct voltage for your laptop. This will be either 12/16 or 19volts. The Voltage selected will be shown in the LCD Screen of CTA26.
4. Once your have selected the correct voltage, connect the short laptop charging cable to your CTA26, and then to your laptop.
5. If you need to reselect the voltage, turn off the CTA26. Wait 15 seconds and then start from step 1 again.

HOW TO USE THE LED TORCH

Note: Ensure the on/ off switch is in the 'on' position
1. Press and hold the round power button for 3 seconds. The LED torch will turn on.
2. Press the round button again will activate the strobe function.
3. Press the round button again will activate the SOS function.

Pressing this button for 3 second can turn on the LED lighting system

CHARGING INDICATOR

1. Press the round power button to see the charge status of the CTA26 LCD Screen.
2. When charging, The LCD Screen will show the specific number range from 0 to 100%.
3. The Input function will stop once the CTA26 is fully charged.

TROUBLE SHOOTING

If the following operations are unable to troubleshoot, please stop using the jump starter and contact with the stores which you bought the jump starter from

| Trouble	Cause	Solution
The power capacity of the device is sho -wn in 100%, but did not fullycharged in charging process	The battery shown 100% in the LCD Screen of CTA26 on means stop charging, and this situation means it is semi-state of charge, which is conducive to long-term storage when the device is not in use for long time.	Pull out the charge plug, then reinsert.
Nothing happens when pressing the switch button	Low voltage protection of the device is started and the device can not be turned on.	Insert the charger plug into the 5V/2A input port to activate

WARNING!

1. After starting your vehicle, Remove the CTA26 as soon as possible
2. DO NOT connect the 2 alligator clip together.
3. DO NOT disassemble the CTA26

⊘ Do not use the product in bathroom or other damp places or places near the water.
⊘ Do not remodel or dismantle the device.
⊘ Keep the product away from the children.
⊘ Do not reverse the connections of output or input.
⊘ Do not throw the product into fire.
⊘ Please don't use the charger whose charging voltage is more than the product to charge.
⊘ The temperature should be kept between 0℃ to 40℃ when the device is being charged.
⊘ Do not hit or throw the product.
⊘ If there is problem with charging, please contact your dealer.
⊘ Keep the product away from the flammable objects.
⊘ If the liquid of the device is splashed into eyes, do not wipe the eyes but wash them with clean water immediately.
⊘ If the product is heating and discolouring, please stop using, as it may lead to liquid, smoke and burn.
⊘ After long term storage or not in use, please ensure that devices will be charged and discharged in every three months.

FREQUENTLY ASKED QUESTIONS

1. How to i turn off the CTA26?
   a.The devices have smart detection, in the case there is no load or charging is finished, the CTA26 will turn itself off.
2. How long does a full charge take?
   a.A full charge will take between 3-5 hours using either the 120V or 9V charging options.
3. How many times can i jump starter my vehichle?
   a.This depend on the different displacements and vehicle engine. The CTA26 can start a vehicle up to 30 times.
4. If not being used, how long can the CTA26 be stored?
   a. It is recommended to charge the CTA26 every 3-6 months. Once the unit drops below 50% we recommend you charge it to ensure you can jump starter your vehicle.
5. The CTA26 won't star my car, Why not?
   a. Pls ensure the unit is charged above 50%.
   b. Ensure the clamps are secure and not connected incorrectly.
   c. Ensure the battery terminals are clean and free from corrosion. If corroded, clean them and reconnect the CTA26 as per the instruction in this manual.

Quality commitment
12 million RMB sum insured

Our product's quality is underwritten by
PICC Property and Casualty Company Limited

Warranty card

We offer 12-month warranty
service for the product from the date of purchasing.

Model No.		Series No.	
Purchase Date		Repair Date	
Customer Name		Tel	
Customer Address			
Sales Unit			
Description of Malfunctions			